




DJI COPILOT

User Manual



Click here to access an up-to-date online version of this document. You will also find the most recent content as well as expandable illustrations, easier navigation, and search capability.

Contents


1 Overview	5
Ports	6
LCD Guide	6
Specifications	18
• Enclosure dimensions	18
• Enclosure weight	18
• Electrical	18
• Temperature ranges	19
• Your device might get warm	19
• If you see a temperature warning screen	19
2 Setup	21
Step 1: Install the Copilot BOSS app	21
Step 2: Prepare and connect the power cable	21
Step 3: Connect your mobile device to DJI Copilot	22
Step 4: Detect your mobile device and launch Copilot BOSS	23
Your setup is complete	24
• Copy and move files with Copilot BOSS	24
• Connect to a PC/Mac	25
• Easy copy with the action button	25
3 Action Button Scanning	27
First push	27
Second push (within 10 seconds of the first push)	27
4 Easy Copy	29
Copying	29
• Canceling an Easy copy	32
Queuing ports for Easy copy	32
Easy copy data naming conventions	32
5 Connections	34
Mobile device port	34
Secure Digital (SD) card port	34
USB Type A port	35
• Recommendations for USB Type A connections	36
• Drones, DSLR, point & shoot cameras, and video devices	36
• iPhone, iPad and Android phone/tablet	36
• USB hub	36
• Computer - Not recommended	36

USB-C port	36
• Recommendations for USB-C connections	37
• Copilot BOSS app and the USB-C connection	37
• Refresh after disconnecting from computer	37
• DJI Copilot hard drive format	38
• Partitioning DJI Copilot's internal drive	38
• Hub - SD card and USB Type A port	38
• Mobile device connection via USB-C	38
• Connecting to PC/Mac during an Easy copy or Copilot BOSS app action	39
Charging your DJI Copilot	39
• Power supply unit	39
• USB-C connection	39
Charging your mobile devices from DJI Copilot	39
• Mobile port	39
• USB Type A port	40
• Slow charging	40
Charging compatible devices from DJI Copilot	40
6 System Events	41
Power-saving mode	41
• Manually wake up DJI Copilot	41
• Manually initiate power-saving mode	42
Operation in progress	42
7 Manual Actions for Undetected Mobile, SD and USB Devices	43
Manually detect a mobile device	43
Manually detect a USB device for Easy copy	43
8 Copilot BOSS App	45
Menus and options	45
Selecting a device	47
Viewing folders and files	48
• View options	48
Selecting folders and files	49
Copying folders and files	49
Moving folders and files	49
Sharing files	49
Deleting files	50
View info	50
Renaming folders and files	51
Rotating images	51
Opening files	51
Confirming Easy copy using your mobile device	52
Viewing Copilot BOSS settings	52

9 Restarting DJI Copilot	54
10 Safety Guidelines	55
Power source	55
Battery safety	55


Overview

DJI Copilot lets you transfer files directly from your drone, camera, phone, and other devices—no laptop needed. View and organize content using the Copilot BOSS app by LaCie (Android and iOS).



1. LCD
2. Action button
3. Removable port cover

Ports



Charge your DJI Copilot. Only use the power supply included with your device.



The USB Type A port allows you to connect a wide range of devices to DJI Copilot. Press the action button to transfer all files (Easy copy), or manage files using the Copilot BOSS app.




The USB-C port connects DJI Copilot to Windows and macOS computers.



Insert a Secure Digital (SD) card or a micro SD card with the adapter. Press the action button to transfer all files (Easy copy), or manage files using the Copilot BOSS app.




Connect a mobile device to DJI Copilot using one of the three custom cables and use the Copilot BOSS app to manage files. Make sure to use the custom cables included with DJI Copilot.



LCD Guide

The LCD provides information and prompts.



1. Connections
2. Storage meter (white = storage used)
3. Prompts and information
4. Action button (actions and status)
5. Press and hold the action button for 3 seconds (long push) to cancel
6. Press the action button for 1 second (short push) to confirm

The LCD is not touch-sensitive—it can't be used to initiate actions or respond to prompts. Always use the action button to confirm or cancel actions.

Connections



Mobile device connected.



SD card inserted.



Computer connected.



USB device connected.



Power supply connected.

Actions



Confirm by pressing the action button for 1 second (short push).



Cancel by pressing and holding the action button for 3 seconds (long push).

Storage meter



Storage used (white) / unused (grey).



Minimal storage remaining (orange) / storage reaching full capacity (red.)



Not enough disk space on DJI Copilot for requested copy.


Use a short push on the action button to confirm and continue.




Prompts and information.




Available storage on DJI Copilot.




Battery charging.



Four bars means 76% or more charge remaining.




Three bars means 51-75% charge remaining.



Two bars means 26-50% charge remaining.



One bar means 11-25% charge remaining.



A red bar means 10% or less charge remaining.



Please wait—an operation is in progress or the system is waking from low power mode.



Prompt to copy files from SD cards and USB-connected devices.

Use a short push on the action button to confirm, or a long push to cancel.




Scanning SD card or USB-connected device.

Use a long push on the action button to cancel.




Progress of copy from SD card or USB-connected device.






Progress of file/folder verification after copying.




Copy transfer speed.

Use a long push on the action button to cancel a copy in progress.



Percentage of copy complete.

Use a long push on the action button to cancel a copy in progress.



Amount of data copied.

Use a long push on the action button to cancel a copy in progress.



Copy from SD card or USB-connected device complete.


Use a short push on the action button to confirm the message.



Prompt to acknowledge that you want to cancel a copy.


Use a short push on the action button to proceed with canceling the copy.

If you don't want to cancel, simply wait for the timer bar to run out, at which point DJI Copilot will resume copying.



Copy from SD card or USB-connected device canceled.

Use a short push on the action button to confirm the message.





Loading.



DJI Copilot is entering power-saving mode.



Prompt to copy when SD and USB devices are connected at the same time.

Use a short push on the action button to confirm that you want to add the highlighted port to a copy queue.



If you don't want to add the highlighted port to a copy queue, use a long push on the action button.



DJI Copilot must refresh its storage capacity. This is required after a reset or when DJI Copilot has been disconnected from a computer.

Use a short push on the action button to confirm the message and refresh.



Prompt to wake up DJI Copilot. For this prompt to appear, apply a short push while DJI Copilot is in power-saving mode, followed by a long push.

At this prompt, use a short push on the action button to confirm or a long push to cancel.



Prompt to put DJI Copilot into power-saving mode. This appears after a long push on the action button.

At this prompt, use a short push on the action button to confirm or a long push to cancel.



The internal clock requires an update from the Copilot BOSS app. Connect your mobile device and Copilot BOSS launches automatically.




System is updating or processing an installation package.



Resetting system to factory defaults.




No SD card or USB-connected device available to copy.



The external drive cannot be read. The drive's format is unknown or it has not been formatted.

Use a short push on the action button to confirm the message.



Copy from an SD card or USB device was interrupted. Possible conditions:

- The SD card was removed or a cable was disconnected.






DJI Copilot cannot access a device. Possible conditions:

- A connected camera, drone or other device is powered off or in power-saving mode.
- A mobile device requires permission to allow DJI Copilot to access its files. Android users should make certain that USB devices are set for data rather than charging. iOS users must confirm when prompted.

After resolving the issue with the connected device, apply a short push to retry the connection.

To cancel, apply a long push.



DJI Copilot's internal drive cannot be found. Possible conditions:

- The internal drive has been divided into multiple partitions. When partitioning the internal drive, make certain that at least one partition is more than half the total capacity. For example, a drive with 1.8TB must have at least one partition greater than 900GB.
- There's a problem with the internal drive.




Internal temperature has exceeded a moderately high temperature threshold.

- Place DJI Copilot in a shaded or low light area to allow it to cool down.
- Use a short push on the action button to confirm the message.



Internal temperature has exceeded a high temperature threshold.

- Place DJI Copilot in a shaded or low light area to allow it to cool down.
- Use a short push on the action button to confirm the message.



Internal temperature has exceeded a critical temperature threshold. DJI Copilot must shut down.

- Place DJI Copilot in a shaded or low light area to allow it to cool down.



Internal temperature has exceeded a critical temperature threshold.

- Place DJI Copilot in a shaded or low light area to allow it to cool down.
- Determine readiness by pushing the action button and seeing that the critical warning is no longer on the LCD.

Specifications

Enclosure dimensions

Side	Dimensions (mm / in)
Side	136 / 5.35
Height	36 / 1.42
Length	110 / 4.33

Enclosure weight

Weight (g / oz)

546 / 19.26

Electrical

Power supply: 12V 1.5A

! When charging the device using the power supply port, use only the power supply provided with your device. Power supplies from other DJI, LaCie, and third-party devices can damage your DJI Copilot. For details on charging the device using the USB-C port, see [Charging your DJI Copilot](#).

Temperature ranges

Ambient environment	Temperature range
Standard (operating)	0 to 35°C

Your device might get warm

Your device might feel warm to the touch when engaged in certain activities:

- Copying or moving a large number of files.
- Copying or moving files while connected to a mobile device.
- Copying or moving files when connected to a PC/Mac.

These conditions are normal. Your device will return to a regular temperature after it's finished copying.

Conditions that lead to a higher ambient temperature may cause the device to change its performance, including:

- Leaving the device in direct sunlight for an extended period of time.
- Leaving the device in a warm enclosed space, such as a car on a hot day.

If you see a temperature warning screen

If the interior temperature of the device exceeds certain temperature thresholds, the LCD will display a series of temperature warnings:



Place DJI Copilot in a shaded or low light area to allow it to cool down.



Setup


You must use the Copilot BOSS app to set up your DJI Copilot. Please follow the steps below in order.

Step 1: Install the Copilot BOSS app


1. Go to the Google Play Store (Android) or the App Store (iOS).
2. Search for and select the Copilot BOSS app.
3. Follow the onscreen instructions to complete the installation

Step 2: Prepare and connect the power cable

1. Press the release tab on the universal power supply to unlock the safety cover. Slide the cover back to remove it.
2. Place the adapter plug for your location into the channel on the power supply. Slide it forward to lock it in place.



3. Connect the power cable to the DJI Copilot power input, and then connect the power supply to a live power outlet.




! Use only the power supply provided with your device. Power supplies from other DJI, LaCie, and third-party devices can damage your DJI Copilot.



Make sure DJI Copilot is connected to power and charging during the installation process.


Step 3: Connect your mobile device to DJI Copilot

DJI Copilot comes with three detachable cables to connect the mobile port to popular mobile devices.




1. Lightning: iOS devices
2. Micro-USB: Android devices with Micro-USB ports
3. USB-C: Android devices with USB-C ports

1. Attach the block end of the appropriate cable to the mobile port on DJI Copilot.
2. Attach the other end of the cable to your mobile device.




Step 4: Detect your mobile device and launch Copilot BOSS

1. Make sure your mobile device is powered on and unlocked.
2. Push the action button to allow DJI Copilot to discover your mobile device.



3. Copilot BOSS opens automatically—this may take up to 20 seconds. If the app doesn't open automatically, tap the Copilot BOSS app on your mobile device.




4. Follow the prompts on Copilot BOSS.

Your setup is complete

You can now put DJI Copilot to work managing and storing your media.


Copy and move files with Copilot BOSS

Use Copilot BOSS to manage files on DJI Copilot and connected storage devices, SD cards, and mobile devices. See [COPILOT BOSS app](#) for details.



Connect to a PC/Mac


DJI Copilot is a large capacity hard drive and hub when connected to your PC/Mac. The hard drive is formatted for no-hassle connections with Windows and Mac computers.



View recommendations for [connecting your computer to the USB-C port](#).

Easy copy with the action button


Copy files from SD cards and USB-connected devices with a simple touch of the action button. See [Easy Copy](#) for details.



Action Button Scanning


First push

The first push of the action button scans the tethered cable for a connected mobile device. The LCD displays the amount of storage capacity currently free.



Second push (within 10 seconds of the first push)

The second push of the action button scans the SD card and USB ports for an SD card or USB-connected device. If an SD card or connected device is detected, you're prompted to [Easy copy](#).



Easy Copy

DJI Copilot lets you easily copy files from an SD card or USB-connected device using just the action button.




Easy copy only supports devices that use common transfer protocols: Media Transfer Protocol (MTP), Picture Transfer Protocol (PTP), and mass storage. Devices using proprietary transfer protocols have not been tested.


Copying

1. Insert an SD card or connect a device (for example, storage, drone, or camera) to the USB port on DJI Copilot.


SD Card



USB Storage




2. Press the action button to display DJI Copilot's status, and then press the action button again (within 10 seconds) to have DJI Copilot search the SD and USB ports.




It can take up to 20 seconds to detect and scan an SD card or connected device.

3. DJI Copilot prompts you to confirm or cancel the copy. Press the action button—use a short push (1 second) to confirm, or a long push (3 seconds) to cancel.



4. Once confirmed, DJI Copilot copies all files. The LCD displays the status of the copy.




1. Operation in progress - please wait
2. Reading
3. Long push (3 seconds) to cancel
4. Copying
5. Complete
6. Short push (1 second) to confirm

5. Once Easy copy is complete, remove the SD card or disconnect the USB device. DJI Copilot always prompts you to Easy copy any card or device it detects.

! An Easy copy always copies everything on the storage device, also referred to as a full copy. Easy copy does not allow for incremental copies.

Canceling an Easy copy

The X icon on the LCD indicates that you can cancel an operation with the action button on DJI Copilot.




Press and hold the action button on DJI Copilot for 3 seconds to cancel a copy.

Queuing ports for Easy copy

If DJI Copilot scans the ports and detects both an SD card and a USB-connected device at the same time, you can queue both ports for Easy copy.

1. Press the action button to confirm or cancel the Easy copy for the highlighted port. Use a short push (1 second) to confirm, or a long push (3 seconds) to cancel.



2. Confirm or cancel the Easy copy from the second port.



Ports can be queued when both an SD card and a USB-connected device are detected at the same time. However, if DJI Copilot is currently performing an Easy copy and then discovers a new card or device, it can't create a queue.

Easy copy data naming conventions

During an Easy copy, DJI Copilot creates folders using the following naming convention:

YYYYMMDD.HHMM.UUID.N

These folders are stored in the Backups folder on the root of the DJI Copilot.

YYYY	Year
MM	Month
DD	Day
HH	Hour (24-hour clock)
MM	Minutes
UUID	Universally unique identifier designating the device from which the files were copied
N	Session number

Take for example the following directory:

20181001.1306.XFGT6G.1


DJI Copilot would have created this directory on October 1, 2018, at 1:06pm. The source of the content was a device with a UUID of XFGT6G. This was the first upload of content from this device on this day.

Connections

The recommendations below provide details on connecting devices to DJI Copilot.

Mobile device port

The mobile device port conforms to Micro-USB measurements. Use one of the three custom cables to connect a mobile device to DJI Copilot.




1. Lightning: iOS devices
2. Micro-USB: Android devices with Micro-USB ports
3. USB-C: Android devices with USB-C ports

! Connections using third-party cables have not been tested and their stability cannot be assured.

Secure Digital (SD) card port


Insert SD cards into the SD card slot. For microSD cards, use the included microSD to SD adapter.



The included microSD to SD UHS-I adapter is compatible with both UHS-I and UHS-II microSD cards. A UHS-II adapter may be required to achieve the highest data transfer performance when copying from UHS-II microSD cards.

USB Type A port

The USB Type A port allows you to connect a wide range of external devices to DJI Copilot. Connect the device to the Type A port on DJI Copilot using a USB cable recommended by the device manufacturer (not included).



Powered devices and USB warning

When connecting powered devices such as desktop storage, drones, or cameras, confirm that they are powered on before pushing DJI Copilot's action button. If the device is powered off, you may receive an error message on DJI Copilot's LCD asking you to check the USB connection.

Some powered devices may not appear on the LCD when they are powered on, even if the Copilot BOSS app recognizes the connection.

Once you've powered the device and connected it to DJI Copilot, follow the [Easy Copy](#) prompts on the LCD, or use the Copilot BOSS app to copy and manage data on the device.

Recommendations for USB Type A connections

Drones, DSLR, point & shoot cameras, and video devices

Photographic equipment with USB ports can connect directly to DJI Copilot. Make certain to use a cable that supports the port on your device as it can differ by model. If you receive a USB error on the LCD, see the note above regarding powered devices.

iPhone, iPad and Android phone/tablet

While USB storage and photographic devices are the expected devices, DJI Copilot can also copy files stored on an iPhone, iPad or Android phone/tablet via the Type A port. Similar to storage devices connected to the Type A port, you can copy all the contents on your mobile device's storage using Easy copy. However, performing an Easy copy also copies all system files on your mobile device. For precision copying, connect your mobile device to DJI Copilot via the dedicated tethered cable and use Copilot BOSS to choose only the files you want.

If you connect your mobile device to the Type A port and select an Easy copy, you may receive an error message on the LCD to check the USB connection. Both Android and iOS require permission to allow connected devices to access files. Many Android and all iOS devices have simple pop-up dialogs to give consent. If you do not see the pop-up on your Android device, navigate to the settings for USB connections to accept sharing files. The default for some Android devices is to allow a connected device with a battery to charge from your mobile device, which is not recommended.

Copies from Android and iOS mobile devices back up media files from the Camera Roll. A copy from the mobile device is not a backup of the device and should not be considered a full backup.

USB hub

While a USB hub can support multiple USB storage devices, it's possible that DJI Copilot only recognizes one of them. Use the Copilot BOSS app to choose which devices to manage on the USB hub.

Computer - Not recommended

While a USB cable can connect a computer to DJI Copilot via the USB Type A port, it's not recommended. Tasks such as copying files are not available to computers when connected to the Type A port. Computers that accept a charge via USB will rapidly drain DJI Copilot's battery if it's not connected to a power outlet. Computer connections should be made via DJI Copilot's USB-C port.


USB-C port

DJI Copilot is a large capacity hard drive and hub when connected to a PC/Mac.

DJI Copilot's USB-C port is meant for connection to a computer. Use computers with the following operating systems:

- macOS 10.12 (Sierra) and higher
- Windows 10 and higher

Connect your computer to DJI Copilot using one of the included cables:



1. USB 3.1 Type C
2. USB 3.0 Type C to A

Recommendations for USB-C connections

Copilot BOSS app and the USB-C connection

To use DJI Copilot as a hard drive for a PC/Mac, make sure DJI Copilot is in power saving mode before connecting it to a computer. Power-saving mode is initiated after two minutes of inactivity, or can be selected from the Copilot BOSS app settings. Make certain that a mobile device is not connected to the tethered cable. In this state, data transfers are managed by the computer—if you reconnect your mobile device to DJI Copilot, the Copilot BOSS app cannot read or write files on DJI Copilot because the computer is managing activities.

- ! If you connect DJI Copilot to a PC/Mac while a mobile device is connected or a copy is in progress, file management is not given to the computer in order to avoid interrupting current activities. You will not see DJI Copilot in the computer's file manager until you disconnect the mobile device.

Refresh after disconnecting from computer

After DJI Copilot has been safely ejected from a computer and the cable is disconnected, you are prompted to refresh by pushing DJI Copilot's action button. Since DJI Copilot's system was in power-saving mode during the connection to the computer, it must wake up to update the status details for available storage and

battery charge.

DJI Copilot hard drive format

While the default storage format used by DJI Copilot (exFAT) is universal for Mac and Windows, you have the potential for better transfer rates by changing it to one of the following:

- macOS: HFS+ (Journaled)
- Windows: NTFS

If you want to change the format, use the default utility for your operating system.

! Formatting deletes all data on the hard drive. Before you format the drive, copy everything on DJI Copilot to another hard drive.

For further information, see the instructions for your operating system.

- [macOS](#)
- [Windows](#)

Partitioning DJI Copilot's internal drive

In general, it's recommended that you organize content on DJI Copilot's internal drive using folders instead of partitions. However, if you choose to partition the internal drive, make sure that at least one volume is greater than 50% of the total 1.8TB storage capacity. DJI Copilot requires one volume that exceeds a minimum 900GB of storage capacity.

Hub - SD card and USB Type A port

When DJI Copilot is connected to a computer via the USB-C port, it serves as a hub—this means that SD cards and USB storage devices connected to DJI Copilot are available to your computer.

Mobile device connection via USB-C

While it's possible to connect Android and iOS mobile devices to DJI Pilot's USB-C port, such connections are non-standard and have not been tested. In addition, extended mobile device connections to the USB-C port can quickly drain the charge from your mobile device's battery or DJI Copilot.

! It's strongly recommended that you connect your mobile device to DJI Copilot using the dedicated tethered cable. This allows you to manage data on DJI Copilot and your mobile device with the Copilot BOSS app.

Connecting to PC/Mac during an Easy copy or Copilot BOSS app action

DJI Copilot can be connected to a PC/Mac while it's performing an Easy copy or Copilot BOSS file management activities such as copying, moving, or deleting files. DJI Copilot's drive becomes available to the PC/Mac when:

1. The action runs to completion.
2. DJI Copilot enters power-saving mode.

A single push is required to connect DJI Copilot to the PC/Mac.

Charging your DJI Copilot

DJI Copilot receives power via:

- The included power supply unit plugged into a power outlet.
- A USB-C connection to a computer or a power delivery charging device such as a USB-C power adapter or an external battery.

Power supply unit

Fully charging DJI Copilot with the included power supply may take several hours. Recharge time may be increased if DJI Copilot is in active use.

- ! When charging the device using the power supply port, use only the power supply provided with your device. Power supplies from other DJI, LaCie, and third-party devices can damage your DJI Copilot. For details on charging the device using the USB-C port, see [USB-C connection](#) below.

USB-C connection

DJI Copilot can receive a charge for its battery when connected via the USB-C port to a computer, charging device, or external battery.

- The charge rate depends on the current from the connected power source.
- It may take several hours to fully charge DJI Copilot.
- Power sources providing less than 1.5A may result in slow or negligible charging rates.

Charging your mobile devices from DJI Copilot

DJI Copilot can charge mobile devices connected to the mobile port or the USB Type A port.

Mobile port

Typically you'll want to connect your mobile device to DJI Copilot's mobile port using the included tethered cable, as this allows you to easily manage your data using the Copilot BOSS app. The mobile port delivers 1.5A for Lightning and USB-C connections and 900mA for Micro-USB connections. When charging iOS devices connected to the mobile port, make certain that DJI Copilot is receiving power from its power supply unit.



Connected iOS mobile devices will receive a charge only when DJI Copilot is receiving power from its power supply unit.

USB Type A port

You can also connect your mobile device to DJI Copilot's USB Type A port. The Type A port delivers 1.5A for Lightning and USB-C connections and 900mA for Micro-USB connections.



The Copilot BOSS app only connects to DJI Copilot when the mobile device uses the tethered cable. The app cannot manage data on DJI Copilot when the mobile device is connected to the USB Type A port.

Slow charging

A "Charging slowly" message on your mobile device means it does not support Charging Downstream Port (CDP). Because DJI Copilot does not support Dedicated Charging Port (DCP) over a USB Type A connection, your mobile device will charge at the slower Standard Downstream Port (SDP) speed of 500mA. Connect your mobile device to DJI Copilot's mobile port for faster charging.

Charging compatible devices from DJI Copilot

Devices with batteries that charge via USB can receive up to 1.5A when connected to DJI Copilot's USB Type A port. Micro-USB devices receive up to 900mA.

System Events

Power-saving mode

When not in use, DJI Copilot conserves energy by putting its processor into power-saving mode. The LCD displays the following when DJI Copilot is entering power-saving mode:



The device wakes up when:

- A mobile device is detected following a push on the action button
- When an Easy copy is launched (Copilot BOSS detected an SD card or USB-connected device following two pushes on the action button).

For more details, see [Action Button Scanning](#) and [Easy Copy](#).



It can take up to 20 seconds to wake up the processor.

Manually wake up DJI Copilot

You can manually wake up DJI Copilot:

1. Apply a short push (1 second) to the action button to display DJI Copilot's status.
2. Within 10 seconds, apply a long push (3 seconds) to the action button. The following prompt appears:



3. Use a short push on the action button to confirm or a long push to cancel.

Manually initiate power-saving mode

When DJI Copilot is active, you can manually initiate power-saving mode:

1. Apply a long push (3 seconds) to the action button. The following prompt appears:



2. Use a short push on the action button to confirm or a long push to cancel.

Operation in progress

The LCD displays the following when DJI Copilot is working on an operation or waking from power-saving mode:



Manual Actions for Undetected Mobile, SD and USB Devices

Using the action button, you can command DJI Copilot to perform certain operations that are normally automated.

Manually detect a mobile device

DJI Copilot is designed to autodetect a wide variety of connected mobile devices, however, some mobile devices may not trigger this automated process.

To manually detect a mobile device:

1. Wait for DJI Copilot to enter power-saving mode (the LCD has no content).
2. Apply a short push (1 second) to the action button to display DJI Copilot's status.
3. Apply a long push (3 seconds) to the action button.
4. The LCD displays a prompt:



Apply a short push to the action button to confirm.

Manually detect a USB device for Easy copy

Some USB devices are not autodetected for Easy copy after pushing the action button twice. The status screen appears but the USB icon is not lit and there is no prompt to copy. You may encounter this issue with USB devices that have an independent power source (such as a power supply or battery).

To manually detect a USB device for Easy copy:

1. Wait for DJI Copilot to enter power-saving mode (the LCD has no content).

2. Apply three short pushes to the action button. The second and third pushes must be within 2 seconds of the previous push.
3. Once DJI Copilot wakes up, the LCD prompts you to confirm or cancel the copy. Apply a short push to the action button to confirm or a long push to cancel.

Copilot BOSS App

Copilot BOSS lets you manage files stored on DJI Copilot as well as devices connected to its SD and USB ports (drones, SD cards, USB storage, cameras, video cameras, and more). Copilot BOSS can be used with:


- Android 4.4 and higher
- iOS 10.3 and higher

Use Copilot BOSS to:

- View files on DJI Copilot, connected SD cards and USB drives, and your mobile device.
- Copy files from connected SD cards and USB drives to DJI Copilot.
- Manage files on DJI Copilot.
- Confirm Easy copy using your mobile device instead of the LCD and action button.
- Queue ports for Easy copy using your mobile device.


Menus and options

Use the Navigation and More menus to manage files and the Copilot BOSS app.



1. Navigation
2. More
3. View

When folders and files are selected, options appear at the bottom of the screen.



1. Share
2. Move
3. Copy
4. Options

Selecting a device

1. Tap the Navigation icon.



2. Tap to select a device.



You can also open the Navigation menu using a gesture to slide it out from the left side of the screen.

Viewing folders and files

Browse folders and files by tapping on a folder to open it. Use the Back icon to navigate back to the previous folder.

View options

Use the view options to:

- View files as a grid of thumbnails or as a list
- Select the sorting order for folders and files

To select from view options:



Tap the View icon



Tap the More icon





Use pinch gestures to switch between grid and list views. Pinch outward for a grid view and inward for a list view.

Selecting folders and files

1. Tap on the More icon.



2. Tap **Select**.
3. Tap on folders and files. To select all files currently listed, tap the More icon again and choose **Select all**. A checkmark indicates selected folders and files.

To deselect all currently selected folders and files, tap the More icon and choose **Clear selection**.

Copying folders and files

1. Select the folders and files you want to copy.
2. Tap the Copy icon. The Navigation menu slides open.
3. Select the destination device.
4. Navigate to the destination folder for the copied data.
5. Tap the Checkmark icon to confirm the copy, or the X icon to cancel.

Moving folders and files

1. Select the folders and files you want to move.
2. Tap the Move icon. The Navigation menu slides open.
3. Select the destination device.
4. Navigate to the destination folder for the moved data.
5. Tap the Checkmark icon to confirm the move, or the X icon to cancel.


Sharing files

1. Select one or more files you want to share.
2. Tap the Share icon.
3. Choose your sharing application.

Deleting files

1. Select folders and files you want to delete.



Tap the Options icon at the bottom of the screen , and then select **Delete**.



Tap the Trash icon at the bottom of the screen.

2. A dialog box appears. Confirm the deletion by tapping **Delete**, or **Cancel** to abort.

View info

You can view the following information on folders and files:

- **Name** - Name of the folder or file.
- **Date** - Date the folder or file was created.
- **Type** - Document type. Folders are listed as FOLDER.
- **Size** - File size. (Not listed for folders.)
- **Path** - The location of the file or folder in the file system.

To view file or folder information:


1. Tap the Options icon next to a folder or file.



2. Select **Info**.
3. Select **Done**.

Renaming folders and files

1. Tap the Options icon next to the folder you want to rename.




2. Select **Rename**.
3. A dialog box appears. Use the virtual keyboard to enter a new name.
4. Select **Rename**.

Rotating images

You can rotate an image 90 degrees clockwise.

1. Tap the Options icon next to an image file.



2. Select **Rotate**.

Opening files

Tap on a file to open a media file.

Copilot BOSS can read and play back media files supported by the mobile platform. If a media file cannot be read, Copilot BOSS prompts you to use an alternative app on your mobile device, or choose an app from

the Google Play Store or Apple's App Store.

Confirming Easy copy using your mobile device

Copilot BOSS can be used to confirm an Easy copy initiated on DJI Copilot.

1. Connect your mobile device to DJI Copilot using the tethered cable.
2. Push the action button to have DJI Copilot scan for the connected mobile device. (It can take up to 20-30 seconds to find a connected device.) The Copilot BOSS app launches automatically
3. Insert an SD card or connect a device (for example, storage, drone, or camera) to the USB port on DJI Copilot.
4. A prompt appears in Copilot BOSS asking you to confirm the Easy copy. Tap **YES** to confirm or **NO** to cancel.



Copilot BOSS will send an Easy copy notification for each SD card and connected device it detects. Confirming an Easy copy will add the card or device to the Easy copy queue.

Viewing Copilot BOSS settings


1. Tap on the Navigation icon.
2. Tap **Settings**.

Rename	Rename DJI Copilot.
Language	Select the language setting for Copilot BOSS.
Letterbox color	Select the letterbox background color behind images and video you're viewing.
Version	View information on your firmware version and download new firmware if available.
Reset	Reset Copilot BOSS to default settings.
Disconnect	Disconnect your mobile device from DJI Copilot.

Power-saving mode	Put DJI Copilot into power-saving mode.
About	Review DJI Copilot details: device name, total storage capacity, free/used storage, battery charge, app version, serial number and firmware version.
Help	Open the online help page in your browser.
Report a problem	Report a problem by sending an email to our support staff.
Enable backup logs	View logs for all Easy copies.
Send logs	Allow log files to be attached to your email message when reporting a problem.
File/Folder verification after ingestion	Enable/disable verification. Verification checks the integrity of files for full copies from USB and SD cards. While it helps limit data corruption, verification increases the time needed to copy files.
Do not sleep when connected to Copilot BOSS	Prevent/allow DJI Copilot to enter power-saving mode when connected to Copilot BOSS.
Send usage statistics	Allow Copilot BOSS to periodically send anonymous usage statistics that help us improve your experience with DJI Copilot and Copilot BOSS.

Restarting DJI Copilot

DJI Copilot is designed to be ready at any time. However, if you need to restart DJI Copilot, follow the steps below.



1. Restart pinhole

1. Find the restart pinhole between the USB and USB-C ports.
2. Insert a thin rigid wire (such as the end of a paperclip) into the pinhole until it pushes the button within the enclosed space.
3. Remove the wire and wait for DJI Copilot to complete the restart sequence.

Safety Guidelines

Power source

Use only the power cable provided with your device. Power cables from other DJI, LaCie, and third-party devices can damage your DJI Copilot.

Battery safety

This product contains a lithium-ion battery that must be disposed of properly. See [this link](#) for information about recycling and proper disposal.

Please follow the battery safety items below:

- Do not dismantle, open or shred secondary cells or batteries.
- Do not expose cells or batteries to heat or fire. Avoid storage in direct sunlight.
- Do not short-circuit a cell or a battery. Do not store cells or batteries haphazardly in a box or drawer where they may short-circuit each other or be short-circuited by, other metal objects.
- When charging the device using the power supply port, use only the power supply provided with your device.
- Do not use any cell or battery which is not designed for use with the equipment.
- Do not mix cells of different manufacture, capacity, size or type within a device.
- Seek medical advice immediately if a cell or a battery has been swallowed.
- Do not subject cells or batteries to mechanical shock.
- In the event of a cell leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice.
- Keep cells and batteries out of the reach of children.
- Keep cells and batteries clean and dry.
- Secondary cells and batteries need to be charged before use. See [Setup](#) for instructions on charging this device.
- Do not leave a battery on prolonged charge when not in use.
- After extended periods of storage, it may be necessary to charge and discharge the cells or batteries several times to obtain maximum performance.
- Secondary cells and batteries give their best performance when they are operated at normal room temperature (20°C+5°C).
- Retain the original product literature for future reference.
- Use only the cell or battery in the application for which it was intended.
- Dispose of this device and its battery per the applicable disposal laws of your locality, region and country.

DJI Copilot is not intended for office use.