

# **NAS HDD**

v2 SATA Product Manual

ST8000VN000 ST6000VN000

100758081, Rev. C Gen 2 - October 2015

## **Document Revision History**

Revision	Date	Pages affected and Description of Change
Rev. A	07/17/2014	Initial release.
Rev. B	09/09/2014	13: Correction: "increase MTBF" to "decrease MTBF"
Rev. C	10/14/2015	All: Applied new page numbering format FC & BC: Applied new Seagate Spiral logo 4: Revised Support URL's 5: Added Host aware bullet 6: Added Section 1.2 Zone Structure 7: Added Case temp max 8: Added Rated Workload Statement 20: Added Temp Checkpoint & Revised Fastener Depth Penetration to ".14 max" in Mechanical Drawing 25: Changed Word 95-104 to reflect Streaming command support 23-24: Added ZAC Mgmt commands, note & log page 25: Added Word 69: Zoned ATA Feature support Deleted Index [no longer required]

#### © 2015, Seagate Technology LLC All rights reserved.

Publication number: 100758081, Rev. C October 2015

Seagate, Seagate Technology and the Spiral logo are registered trademarks of Seagate Technology LLC in the United States and/or other countries. SeaTools are either trademarks or registered trademarks of Seagate Technology LLC or one of its affiliated companies in the United States and/or other countries. All other trademarks or registered trademarks are the property of their respective owners.

No part of this publication may be reproduced in any form without written permission of Seagate Technology LLC. Call 877-PUB-TEK1 (877-782-8351) to request permission.

When referring to drive capacity, one gigabyte, or GB, equals one billion bytes and one terabyte, or TB, equals one trillion bytes. Your computer's operating system may use a different standard of measurement and report a lower capacity. In addition, some of the listed capacity is used for formatting and other functions, and thus will not be available for data storage. Actual quantities will vary based on various factors, including file size, file format, features and application software. Actual data rates may vary depending on operating environment and other factors. The export or re-export of hardware or software containing encryption may be regulated by the U.S. Department of Commerce, Bureau of Industry and Security (for more information, visit www.bis.doc.gov), and controlled for import and use outside of the U.S. Seagate reserves the right to change, without notice, product offerings or specifications.

## Contents

1.0						
1.0		uction				
	1.1	About the SATA interface				
	1.2	Zone Structure				
2.0	Drive	Spacifications				
.0		Specifications				
	2.1	Specification summary tables				
	2.2	Formatted capacity				
	2.2	2.2.1 LBA mode.				
	2.3	Recording and interface technology				
	2.4	Physical characteristics				
	2.5	Seek time				
	2.6	Start/stop times				
	2.7	Power specifications				
		2.7.1 Power consumption				
		2.7.2 Conducted noise				
		2.7.3 Voltage tolerance				
		2.7.4 Power-management modes				
	2.8	Environmental specifications				
		2.8.1 Drive case temperature				
		2.8.2 Ambient Temperature1				
		2.8.3 Temperature gradient				
		2.8.4 Humidity				
		2.8.5 Altitude				
		2.8.6 Shock				
		2.8.7 Non-operating vibration14				
	2.9	Acoustics1				
		2.9.1 Test for Prominent Discrete Tones (PDTs)				
	2.10	Electromagnetic immunity				
	2.11	Reliability - Mean Time Between Failure				
	2.12	Warranty				
	2.13	Agency certification				
	2.13	2.13.1 Safety certification				
		2.13.2 Electromagnetic compatibility				
		· · · · · · · · · · · · · · · · · · ·				
	214					
	2.14	Environmental protection				
		2.14.1 European Union Restriction of Hazardous Substances (RoHS) Directive				
		2.14.2 China Restriction of Hazardous Substances (RoHS) Directive				
	2.15	Corrosive environment				
.0	Confid	Configuring and Mounting the Drive				
. •	3.1	Handling and static-discharge precautions				
	3.2	Configuring the drive				
	3.3	SATA cables and connectors				
	3.4	Drive mounting				
.0	SATA	nterface				
-	4.1	Hot-Plug compatibility				
	4.1					
		SATA device plug connector pin definitions				
	4.3	Supported ATA commands				
		4.3.1 ZAC Supported Capabilities log page				
		4.3.2 Identify Device command				
		4.3.3 Set Features command				
		4.3.4 S.M.A.R.T. commands				

## Figures

Figure 1	Attaching SATA cabling	19
Figure 2	Mounting dimensions (6TB & 8TB)	20

## Seagate® Technology Support Services

For information regarding online support and services, visit: <a href="http://www.seagate.com/contacts/">http://www.seagate.com/contacts/</a>

For information regarding Warranty Support, visit: <a href="http://www.seagate.com/support/warranty-and-replacements/">http://www.seagate.com/support/warranty-and-replacements/</a>

For information regarding data recovery services, visit: <a href="http://www.seagate.com/services-software/seagate-recovery-services/recover/">http://www.seagate.com/services-software/seagate-recovery-services/recover/</a>

For Seagate OEM, Distribution partner portal and reseller portal, visit: <a href="http://www.seagate.com/partners">http://www.seagate.com/partners</a>

## 1.0 Introduction

This manual describes the functional, mechanical and interface specifications for the following: Seagate®NAS HDD model drives:

ST8000VN000

ST6000VN000

These drives provide the following key features:

- Host aware, optimized for SMR performance and capable of ZAC command support
- Off-the-shelf compatibility
- · Rated for 1M hours MTBF
- 24x7 capability
- Performance-tuned for RAID applications
- Balance technology to support multiple drives in a system
- · Quiet acoustic performance
- · Low-RPM spindle speed
- · Low activity and idle power
- Supports ATA8 streaming commands
- TGMR recording technology provides the drives with increased areal density.
- State-of-the-art cache and on-the-fly error-correction algorithms
- Native Command Queuing with command ordering to increase performance in demanding applications
- Full-track multiple-sector transfer capability without local processor intervention
- · Compliant with RoHS requirements in China and Europe
- SeaTools diagnostic software performs a drive self-test that eliminates unnecessary drive returns.
- Support for S.M.A.R.T. drive monitoring and reporting
- Supports latching SATA cables and connectors
- Worldwide Name (WWN) capability uniquely identifies the drive

#### 1.1 About the SATA interface

The Serial ATA (SATA) interface provides several advantages over the traditional (parallel) ATA interface. The primary advantages include:

- Easy installation and configuration with true plug-and-play connectivity. It is not necessary to set any jumpers or other configuration options.
- Thinner and more flexible cabling for improved enclosure airflow and ease of installation.
- Scalability to higher performance levels.

In addition, SATA makes the transition from parallel ATA easy by providing legacy software support. SATA was designed to allow users to install a SATA host adapter and SATA disk drive in the current system and expect all of the existing applications to work as normal.

The SATA interface connects each disk drive in a point-to-point configuration with the SATA host adapter. There is no master/slave relationship with SATA devices like there is with parallel ATA. If two drives are attached on one SATA host adapter, the host operating system views the two devices as if they were both "masters" on two separate ports. This essentially means both drives behave as if they are Device 0 (master) devices.

The SATA host adapter and drive share the function of emulating parallel ATA device behavior to provide backward compatibility with existing host systems and software. The Command and Control Block registers, PIO and DMA data transfers, resets, and interrupts are all emulated.

www.seagate.com Introduction

The SATA host adapter contains a set of registers that shadow the contents of the traditional device registers, referred to as the Shadow Register Block. All SATA devices behave like Device 0 devices. For additional information about how SATA emulates parallel ATA, refer to the "Serial ATA International Organization: Serial ATA Revision 3.2". The specification can be downloaded from <a href="https://www.sata-io.org">www.sata-io.org</a>.

Note

The host adapter may, optionally, emulate a master/slave environment to host software where two devices on separate SATA ports are represented to host software as a Device 0 (master) and Device 1 (slave) accessed at the same set of host bus addresses. A host adapter that emulates a master/slave environment manages two sets of shadow registers. This is not a typical SATA environment.

#### 1.2 Zone Structure

NAS HDD models use SMR (Singled Magnetic Recording Technology), physically formatted containing two types of zones. 64 "Conventional Zones" which are not associated with write pointer, and the media is non-SMR and 29808 Sequential Write preferred Zones which are SMR media. For the sequential write referred zones there is write pointer to indicated preferred write location. For the conventional zone writes can occur randomly for any block size. New commands which report zonal structure, resetting zonal write pointers, as well as managing zonal properties are available for sequential write preferred zones through ZAC commands.

#### **NAS HDD Conventional Zone Structure**

- There are 64 256Bi Conventional Zones. (ie. Not Singled)
- The conventional zone is located at the outer diameter and is 16GBi
- Sequential Read and Writes to this zones will perform at similar data rates.
- Random Write commands can be issued in any order without any performance delay.
- Zone designed specifically for random writes data. For example: logs and meta data.

#### There are 29808 Sequential Write Zones

- Each zone is 2e19 logical blocks in size or 256 MiB each.
- Each zone is a shingled zone.
- To achieve best performance use of ZAC commands is required.
- Re-setting write pointers for each zone is required before reuse.

Optimal number of open sequential write preferred zones

- Advised the largest number of zones that should be open for best performance
- It is reported in Identify Device Data log 0x30 page 0x09

Optimal number of non-sequentially written sequential write preferred zones

Advised the largest number of write preferred zones that should be randomly written for best performance

It is reported in identify device data log 0x30 page 0x0

T-13 standards define the new ZAC commands; REPORT ZONES EXT to query the drive on what zones exist and their current condition, RESET WRITE POINTER EXT to reset the write pointers, OPEN ZONE EXT, CLOSE ZONE EXT, and FINISH ZONE EXT to Open, Close, and Finish zones. To achieve optimal performance, an SMR-aware Host driver will need to write sequentially to all sequential write referred zones.

See the T13 Web Site at http://www.t13.org for ACS-4, T13/BSR INCIT 529 for command details.

## 2.0 Drive Specifications

Unless otherwise noted, all specifications are measured under ambient conditions, at 25°C, and nominal power. For convenience, the phrases *the drive* and *this drive* are used throughout this manual to indicate the following drive models: ST8000VN000

ST6000VN000

## 2.1 Specification summary tables

The specifications listed in Table 1 are for quick reference. For details on specification measurement or definition, refer to the appropriate section of this manual.

Table 1 Drive specifications summary for 8TB models

Drive Specification*	ST8000VN000	ST6000VN000	
Formatted capacity (512 bytes/sector)**	8000GB (8TB)	6000GB (6TB)	
Guaranteed sectors	15,628,053,168	11,721,045,168	
Heads	1	2	
Disks		6	
Bytes per sector	5	12	
Recording density (max)	1950 KFCI		
Track density (avg)	435 Kt	racks/in	
Areal density (avg)	848 (	Gb/in <sup>2</sup>	
Internal data transfer rate (max)	1900	Mb/s	
Maximum sustained data rate, OD read (MB/s)	190	MB/s	
ATA data-transfer modes supported	Multiword DM	des: 0 to 4 A modes: 0 to 2 modes 0 to 6	
I/O data-transfer rate (max)	rate (max) 600MB/s		
Cache buffer	128MB		
Height (max)	26.1mm / 1.028 in		
Width (max)	101.6mm	n /4.010 in	
Length (max)	146.99mn	n / 5.787 in	
Weight (typical)	780g /	1.72 lb	
Average latency	5.5	ōms	
Power-on to ready (max)	30	).0s	
Standby to ready (max)	25.0s		
Average seek, read (typical) Average seek, write (typical)	<12.0ms <12.0ms		
Startup current (typical) 12V	2.0A		
Voltage tolerance (including noise)	Voltage tolerance (including noise) 5V: ±5% 12V: ±10%		
Drive case temperature (max)	70°C		
Ambient temperature (drive case temperature)	$0^{\circ}$ to $60^{\circ}$ C (operating) -40° to $70^{\circ}$ C (non-operating)		
Temperature gradient	20°C per hour max (operating) 30°C per hour max (nonoperating)		
Relative humidity	5% to 90% (operating) 5% to 95% (nonoperating)		
Relative humidity gradient (max)	30% per hour		

 Table 1
 Drive specifications summary for 8TB models (continued)

Drive Specification*	ST8000VN000	ST6000VN000		
Wet bulb temperature (max)	30°C max (operating) 37.7°C max (nonoperating)			
Altitude, operating		o 3048m o 10,000 ft)		
Altitude, non-operating (below mean sea level, max)		−61m to 12,192m (−200ft to 40,000+ ft)		
Operational Shock (max)	70 read / 40 v	vrite Gs at 2ms		
Non-Operational Shock (max)	300 Gs	at 2ms		
Vibration, operating	22Hz to 35	Limited displacement 0Hz: 0.50 Gs 00Hz: 0.25 Gs		
Vibration, non-operating	22Hz to 35	5Hz to 22Hz: 3.0 Gs 22Hz to 350Hz: 3.0 Gs 350Hz to 500Hz: 3.0 Gs		
Drive acoustics, sound power				
Idle***	2.5 bels (typical) 2.6 bels (max)			
Seek		2.6 bels (typical) 2.8 bels (max)		
Non-recoverable read errors	1 per 10 <sup>1</sup>	<sup>4</sup> bits read		
Mean time between failures (MTBF), hours	1	1M		
Rated workload	Average rate of <180TB/year. The AFR specification for the drive assumes the O workload does not exceed the average annualized workload rate limit of 180TB/year. Workloads exceeding the annualized rate may degrade the driv AFR and impact product reliability. The average annualized workload rate limit is in units of TB per year, or TB per 8760 power-on hours. Workload rate limit TB transferred × (8760/recorded power-on hours).			
Warranty	To determine the warranty for a specific drive, use a web browser to access the following web page: <a href="http://www.seagate.com/support/warranty-and-replacements/">http://www.seagate.com/support/warranty-and-replacements/</a> From this page, click on "Check to see if the drive is under Warranty". Users wi be asked to provide the drive serial number, model number (or part number) and country of purchase. The system will display the warrant information for the drive.			
Load/Unload cycles (25°C, 50% rel. humidity)	300,000 at 25°C, 50% rel. humidity			
Supports Hotplug operation per the Serial ATA Revision 3.2 specification	Yes			

<sup>\*</sup>All specifications above are based on native configurations.

## 2.2 Formatted capacity

Model	Formatted capacity*	Guaranteed sectors	Bytes per sector	
ST8000VN000	8000GB	15,628,053,168	512	
ST6000VN000	6000GB	11,721,045,168	512	

<sup>\*</sup>One GB equals one billion bytes and 1TB equals one trillion bytes when referring to hard drive capacity. Accessible capacity may vary depending on operating environment and formatting.

<sup>\*\*</sup> One GB equals one billion bytes and 1TB equals one trillion bytes when referring to hard drive capacity. Accessible capacity may vary depending on operating environment and formatting.

<sup>\*\*\*</sup> During periods of drive idle, some offline activity may occur according to the S.M.A.R.T. specification, which may increase acoustic and power to operational levels.

#### 2.2.1 LBA mode

When addressing these drives in LBA mode, all blocks (sectors) are consecutively numbered from 0 to n–1, where n is the number of guaranteed sectors as defined above.

See Section 4.3.2, "Identify Device command" (words 60-61 and 100-103) for additional information about 48-bit addressing support of drives with capacities over 137GB.

#### **LBA** mode

When addressing these drives in LBA mode, all blocks (sectors) are consecutively numbered from 0 to n-1, where n is the number of guaranteed sectors as defined above.

## 2.3 Recording and interface technology

Interface	SATA
Recording method	TGMR
Recording density	
6TB & 8TB	1950 KFCI
Track density (ktracks/inch avg)	
6TB & 8TB	435
Areal density (Gb/in <sup>2</sup> )	
6TB & 8TB	848
Internal data transfer rate (Mb/s max)	
6TB & 8TB	1900
Maximum sustained data transfer rate, OD read (MB/s)	
6TB & 8TB	190
I/O data-transfer rate (MB/s max)	600

## 2.4 Physical characteristics

Maximum height	26.11mm / 1.028 in
Maximum width	101.6mm / 4.0 in (±0.010 in)
Maximum length	146.99mm / 5.787 in
Typical weight	
6TB & 8TB	780g / 1.72 lb
Cache buffer	128MB

#### 2.5 Seek time

Seek measurements are taken with nominal power at 25°C ambient temperature. All times are measured using drive diagnostics. The specifications in the table below are defined as follows:

- Track-to-track seek time is an average of all possible single-track seeks in both directions.
- Average seek time is a true statistical random average of at least 5000 measurements of seeks between random tracks, less overhead.

Typical seek times (ms)	Read	Write
Track-to-track	1.0	1.2
Average	<12.0	<12.0
Average latency	5.	5



These drives are designed to consistently meet the seek times represented in this manual. Physical seeks, regardless of mode (such as track-to-track and average), are expected to meet the noted values. However, due to the manner in which these drives are formatted, benchmark tests that include command overhead or measure logical seeks may produce results that vary from these specifications.

## 2.6 Start/stop times

The start/stop times listed below are for 8TB models.

Power-on to ready (in seconds)	24 (typical) / 30 (max)	
Standby to ready (in seconds)	20 (typical) / 25 (max)	
Ready to spindle stop (in seconds)	15 (typical) / 20 (max)	

Time-to-ready may be longer than normal if the drive power is removed without going through normal OS powerdown procedures.

## 2.7 Power specifications

The drive receives DC power (+5V or +12V) through a native SATA power connector. Refer to Figure 1 on page 19.

## 2.7.1 Power consumption

Power requirements for the drives are listed in Table 2. Typical power measurements are based on an average of drives tested, under nominal conditions, using 5.0V and 12.0V input voltage at 25°C ambient temperature.

- · Spinup power
  - Spinup power is measured from the time of power-on to the time that the drive spindle reaches operating speed.
- Read/write power and current
  - Read/write power is measured with the heads on track, based on a 16-sector write followed by a 32-ms delay, then a 16-sector read followed by a 32-ms delay.
- Operating power and current
  - Operating power is measured using 40 percent random seeks, 40 percent read/write mode (1 write for each 10 reads) and 20 percent drive idle mode.
- Idle mode power
  - Idle mode power is measured with the drive up to speed, with servo electronics active and with the heads in a random track location.
- · Standby mode
  - During Standby mode, the drive accepts commands, but the drive is not spinning, and the servo and read/write electronics are in power-down mode.

Table 2 DC power requirements (6TB & 8TB)

Power dissipation	Avg (watts 25° C)	Avg 5V typ amps	Avg 12V typ amps
Spinup	_	_	2.0
Idle*†	5.0	0.15	0.38
Operating	7.5	0.35	0.45
Standby	1.0	0.12	0.008
Sleep	1.0	0.12	0.008

<sup>\*</sup> Idle1. During periods of drive idle, some offline activity may occur according to the S.M.A.R.T. specification, which may increase acoustic and power to operational levels.

<sup>†5</sup>W IDLE with DIPLM Enabled

#### 2.7.2 Conducted noise

Input noise ripple is measured at the host system power supply across an equivalent 80-ohm resistive load on the +12 volt line or an equivalent 15-ohm resistive load on the +5 volt line.

- Using 12-volt power, the drive is expected to operate with a maximum of 120 mV peak-to-peak square-wave injected noise at up to 10MHz.
- Using 5-volt power, the drive is expected to operate with a maximum of 100 mV peak-to-peak square-wave injected noise at up to 10MHz.

Note

Equivalent resistance is calculated by dividing the nominal voltage by the typical RMS read/write current.

#### 2.7.3 Voltage tolerance

Voltage tolerance (including noise):

- 5V ±5%
- 12V ±10%

## 2.7.4 Power-management modes

The drive provides programmable power management to provide greater energy efficiency. In most systems, users can control power management through the system setup program. The drive features the following power-management modes:

Power modes	Heads	Spindle	Buffer
Active	Tracking	Rotating	Enabled
Idle	Tracking	Rotating	Enabled
Standby	Parked	Stopped	Enabled
Sleep	Parked	Stopped	Disabled

#### Active mode

The drive is in Active mode during the read/write and seek operations.

· Idle mode

The buffer remains enabled, and the drive accepts all commands and returns to Active mode any time disk access is necessary.

· Standby mode

The drive enters Standby mode when the host sends a Standby Immediate command. If the host has set the standby timer, the drive can also enter Standby mode automatically after the drive has been inactive for a specifiable length of time. The standby timer delay is established using a Standby or Idle command. In Standby mode, the drive buffer is enabled, the heads are parked and the spindle is at rest. The drive accepts all commands and returns to Active mode any time disk access is necessary.

· Sleep mode

The drive enters Sleep mode after receiving a Sleep command from the host. In Sleep mode, the drive buffer is disabled, the heads are parked and the spindle is at rest. The drive leaves Sleep mode after it receives a Hard Reset or Soft Reset from the host. After receiving a reset, the drive exits Sleep mode and enters Standby mode with all current translation parameters intact.

Idle and Standby timers

Each time the drive performs an Active function (read, write or seek), the standby timer is reinitialized and begins counting down from its specified delay times to zero. If the standby timer reaches zero before any drive activity is required, the drive makes a transition to Standby mode. In both Idle and Standby mode, the drive accepts all commands and returns to Active mode when disk access is necessary.

## 2.8 Environmental specifications

This section provides the temperature, humidity, shock, and vibration specifications for NAS HDDs. This section provides the temperature, humidity, shock, and vibration specifications.

## 2.8.1 Drive case temperature

Ambient temperature is defined as the temperature of the environment immediately surrounding the drive. Above 1000ft. (305 meters), the maximum temperature is derated linearly by 1°C every 1000 ft. Drive case temperature should be measured at the location indicated in Figure 2.

## 2.8.2 Ambient Temperature

Operating	0° to 60°C (32° to 140°F)	
Non-operating -40° to 70°C (-40° to 158°F)		

## 2.8.3 Temperature gradient

<b>Operating</b> 20°C per hour (36°F per hour max), without condensation	
Non-operating	30°C per hour (54°F per hour max)

## 2.8.4 Humidity

#### 2.8.4.1 Relative humidity

Operating 5% to 90% non-condensing (30% per hour max)	
Nonoperating 5% to 95% non-condensing (30% per hour max)	

#### 2.8.4.2 Wet bulb temperature

Operating	ng 30°C (86°F max)	
Non-operating	37.7°C (99.86°F max)	

#### 2.8.5 Altitude

Operating	-61m to 3048m (-200 ft. to 10,000 ft.)
Non-operating	-61m to 12,192m (-200 ft. to 40,000+ ft.)

#### 2.8.6 Shock

All shock specifications assume that the drive is mounted securely with the input shock applied at the drive mounting screws. Shock may be applied in the X, Y or Z axis.

#### 2.8.6.1 Operating shock

These drives comply with the performance levels specified in this document when subjected to a maximum operating shock of 70 read / 40 write Gs based on half-sine shock pulses of 2ms during read operations. Shocks should not be repeated more than 2 times per second.

#### 2.8.6.2 Non-operating shock

#### **6TB & 8TB**

The non-operating shock level that the drive can experience without incurring physical damage or degradation in performance when subsequently put into operation is 300 Gs based on a non-repetitive half-sine shock pulse of 2ms duration.

#### 2.8.6.3 Operating vibration

The maximum vibration levels that the drive may experience while meeting the performance standards specified in this document are specified below.

2Hz to 22Hz	0.25 Gs (Limited displacement)	
22Hz to 350Hz	0.50 Gs	
350Hz to 500Hz	0.25 Gs	

All vibration specifications assume that the drive is mounted securely with the input vibration applied at the drive mounting screws. Vibration may be applied in the X, Y or Z axis. Throughput may vary if improperly mounted.

#### 2.8.7 Non-operating vibration

The maximum non-operating vibration levels that the drive may experience without incurring physical damage or degradation in performance when subsequently put into operation are specified below.

5Hz to 22Hz	3.0 Gs (Limited displacement)	
22Hz to 350Hz	3.0 Gs	
350Hz to 500Hz	3.0 Gs	

#### 2.9 Acoustics

Drive acoustics are measured as overall A-weighted acoustic sound power levels (no pure tones). All measurements are consistent with ISO document 7779. Sound power measurements are taken under essentially free-field conditions over a reflecting plane. For all tests, the drive is oriented with the cover facing upward.

Note

For seek mode tests, the drive is placed in seek mode only. The number of seeks per second is defined by the following equation:

(Number of seeks per second = 0.4 / (average latency + average access time

#### Table 3 Fluid Dynamic Bearing (FDB) motor acoustics

	Idle*	Seek
6-Disk	2.5 bels (typical) 2.6 bels (max)	2.6 bels (typical) 2.8 bels (max)

<sup>\*</sup>During periods of drive idle, some offline activity may occur according to the S.M.A.R.T. specification, which may increase acoustic and power to operational levels.

### 2.9.1 Test for Prominent Discrete Tones (PDTs)

Seagate follows the ECMA-74 standards for measurement and identification of PDTs. An exception to this process is the use of the absolute threshold of hearing. Seagate uses this threshold curve (originated in ISO 389-7) to discern tone audibility and to compensate for the inaudible components of sound prior to computation of tone ratios according to Annex D of the ECMA-74 standards.

## 2.10 Electromagnetic immunity

When properly installed in a representative host system, the drive operates without errors or degradation in performance when subjected to the radio frequency (RF) environments defined in Table 4.

Table 4 Radio frequency environments

Test	Description	Performance level	Reference standard
Electrostatic discharge	Contact, HCP, VCP: ± 4 kV; Air: ± 8 kV	В	EN61000-4-2: 95
Radiated RF immunity	80MHz to 1,000MHz, 3 V/m, 80% AM with 1kHz sine 900MHz, 3 V/m, 50% pulse modulation @ 200Hz	А	EN61000-4-3: 96 ENV50204: 95
Electrical fast transient	$\pm$ 1 kV on AC mains, $\pm$ 0.5 kV on external I/O	В	EN61000-4-4: 95
Surge immunity	$\pm$ 1 kV differential, $\pm$ 2 kV common, AC mains	В	EN61000-4-5: 95
Conducted RF immunity	150kHz to 80MHz, 3 Vrms, 80% AM with 1kHz sine	A	EN61000-4-6: 97
Voltage dips, interrupts	5, interrupts 0% open, 5 seconds 0% short, 5 seconds 40%, 0.10 seconds 70%, 0.01 seconds		EN61000-4-11: 94

## 2.11 Reliability - Mean Time Between Failure

The product will achieve a Mean Time Between Failure Rate (MTBF) of 1,000,000 hours when operated in an environment of ambient air temperatures of 25°C. Operation at temperatures outside the specifications shown in Section 2.8 may decrease the product MTBF. MTBF is a population statistic that is not relevant to individual units.

- MTBF specifications are based on the following assumptions for NAS environments:
- 8760 power-on hours per year
- 10,000 average motor start/stop cycles per year
- Operations at nominal voltages
- Temperatures outside the specifications in Section 2.8 may reduce the product reliability.

Operation at excessive I/O duty cycle may degrade product reliability. The NAS environment of power-on hours, temperature, and I/O duty cycle affect the product MTBF. The MTBF will be degraded if used in an enterprise application.

## 2.12 Warranty

To determine the warranty for a specific drive, use a web browser to access the following web page: http://www.seagate.com/support/warranty-and-replacements/

From this page, click on "Check to see if the drive is under Warranty". Users will be asked to provide the drive serial number, model number (or part number) and country of purchase. The system will display the warranty information for the drive.

## 2.13 Agency certification

## 2.13.1 Safety certification

These products are certified to meet the requirements of UL60950-1, CSA60950-1 and EN60950 and so marked as to the certify agency.

## 2.13.2 Electromagnetic compatibility

Hard drives that display the CE mark comply with the European Union (EU) requirements specified in the Electromagnetic Compatibility Directive (2004/108/EC) as put into place 20 July 2007. Testing is performed to the levels specified by the product standards for Information Technology Equipment (ITE). Emission levels are defined by EN 55022, Class B and the immunity levels are defined by EN 55024.

Drives are tested in representative end-user systems. Although CE-marked Seagate drives comply with the directives when used in the test systems, we cannot guarantee that all systems will comply with the directives. The drive is designed for operation inside a properly designed enclosure, with properly shielded I/O cable (if necessary) and terminators on all unused I/O ports. Computer manufacturers and system integrators should confirm EMC compliance and provide CE marking for their products.

#### **Korean RRL**

If these drives have the Korean Communications Commission (KCC) logo, they comply with paragraph 1 of Article 11 of the Electromagnetic Compatibility control Regulation and meet the Electromagnetic Compatibility (EMC) Framework requirements of the Radio Research Laboratory (RRL) Communications Commission, Republic of Korea.

These drives have been tested and comply with the Electromagnetic Interference/Electromagnetic Susceptibility (EMI/EMS) for Class B products. Drives are tested in a representative, end-user system by a Korean-recognized lab.

#### Australian C-Tick (N176)

If these models have the C-Tick marking, they comply with the Australia/New Zealand Standard AS/NZ CISPR22 and meet the Electromagnetic Compatibility (EMC) Framework requirements of the Australian Communication Authority (ACA).

#### 2.13.3 FCC verification

These drives are intended to be contained solely within a personal computer or similar enclosure (not attached as an external device). As such, each drive is considered to be a subassembly even when it is individually marketed to the customer. As a subassembly, no Federal Communications Commission verification or certification of the device is required.

Seagate has tested this device in enclosures as described above to ensure that the total assembly (enclosure, disk drive, motherboard, power supply, etc.) does comply with the limits for a Class B computing device, pursuant to Subpart J, Part 15 of the FCC rules. Operation with non-certified assemblies is likely to result in interference to radio and television reception.

**Radio and television interference.** This equipment generates and uses radio frequency energy and if not installed and used in strict accordance with the manufacturer's instructions, may cause interference to radio and television reception.

This equipment is designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television, which can be determined by turning the equipment on and off, users are encouraged to try one or more of the following corrective measures:

- · Reorient the receiving antenna.
- Move the device to one side or the other of the radio or TV.
- Move the device farther away from the radio or TV.
- Plug the computer into a different outlet so that the receiver and computer are on different branch outlets.

If necessary, users should consult the dealer or an experienced radio/television technician for additional suggestions. Users may find helpful the following booklet prepared by the Federal Communications Commission: *How to Identify and Resolve Radio-Television Interference Problems*. This booklet is available from the Superintendent of Documents, U.S. Government Printing Office, Washington, DC 20402. Refer to publication number 004-000-00345-4.

## 2.14 Environmental protection

Seagate designs its products to meet environmental protection requirements worldwide, including regulations restricting certain chemical substances.

## 2.14.1 European Union Restriction of Hazardous Substances (RoHS) Directive

The European Union Restriction of Hazardous Substances (RoHS) Directive, restricts the presence of chemical substances, including Lead, Cadmium, Mercury, Hexavalent Chromium, PBB and PBDE, in electronic products, effective July 2006. This drive is manufactured with components and materials that comply with the RoHS Directive.

#### 2.14.2 China Restriction of Hazardous Substances (RoHS) Directive 中国限制危险物品的指令

This product has an Environmental Protection Use Period (EPUP) of 20 years. The following table contains information mandated by China's "Marking Requirements for Control of Pollution Caused by Electronic Information Products" Standard.



该产品具有20年的环境保护使用周期 (EPUP)。 下表包含了中国 "电子产品所导致的污染的控制的记号要求"所指定的信息。

		Toxic or Hazardous Substances or Elements有毒有害物质或元素				
Name of Parts 部件名称	Lead 铅(Pb)	Mercury 汞 (Hg)	Cadmium 镉 (Cd)	Hexavalent Chromium 六价铬 (Cr6+)	,	Polybrominated Diphenyl Ether 多溴二苯醚 (PBDE)
PCBA	X	0	0	0	0	0
HDA	X	0	0	0	0	0

<sup>&</sup>quot;O" indicates the hazardous and toxic substance content of the part (at the homogeneous material level) is lower than the threshold defined by the China RoHS MCV Standard.

#### 2.15 Corrosive environment

Seagate electronic drive components pass accelerated corrosion testing equivalent to 10 years exposure to light industrial environments containing sulfurous gases, chlorine and nitric oxide, classes G and H per ASTM B845. However, this accelerated testing cannot duplicate every potential application environment. Users should use caution exposing any electronic components to uncontrolled chemical pollutants and corrosive chemicals as electronic drive component reliability can be affected by the installation environment. The silver, copper, nickel and gold films used in Seagate products are especially sensitive to the presence of sulfide, chloride, and nitrate contaminants. Sulfur is found to be the most damaging. In addition, electronic components should never be exposed to condensing water on the surface of the printed circuit board assembly (PCBA) or exposed to an ambient relative humidity greater than 95%. Materials used in cabinet fabrication, such as vulcanized rubber, that can outgas corrosive compounds should be minimized or eliminated. The useful life of any electronic equipment may be extended by replacing materials near circuitry with sulfide-free alternatives.

<sup>&</sup>quot;O"表示该部件(于同类物品程度上)所含的危险和有毒物质低于中国RoHS MCV标准所定义的门槛值。

<sup>&</sup>quot;X" indicates the hazardous and toxic substance content of the part (at the homogeneous material level) is over the threshold defined by the China RoHS MCV Standard.

<sup>&</sup>quot;X"表示该部件(于同类物品程度上)所含的危险和有毒物质超出中国RoHS MCV标准所定义的门槛值。

## 3.0 Configuring and Mounting the Drive

This section contains the specifications and instructions for configuring and mounting the drive.

#### 3.1 Handling and static-discharge precautions

After unpacking, and before installation, the drive may be exposed to potential handling and electrostatic discharge (ESD) hazards. Observe the following standard handling and static-discharge precautions:

#### Caution

- Before handling the drive, put on a grounded wrist strap, or ground oneself frequently by touching the metal chassis of a computer that is plugged into a grounded outlet. Wear a grounded wrist strap throughout the entire installation procedure.
- Handle the drive by its edges or frame only.
- The drive is extremely fragile—handle it with care. Do not press down on the drive top cover.
- Always rest the drive on a padded, antistatic surface until mounting it in the computer.
- Do not touch the connector pins or the printed circuit board.
- Do not remove the factory-installed labels from the drive or cover them with additional labels. Removal voids the warranty. Some factory-installed labels contain information needed to service the drive. Other labels are used to seal out dirt and contamination.

## 3.2 Configuring the drive

Each drive on the SATA interface connects point-to-point with the SATA host adapter. There is no master/slave relationship because each drive is considered a master in a point-to-point relationship. If two drives are attached on one SATA host adapter, the host operating system views the two devices as if they were both "masters" on two separate ports. Both drives behave as if they are Device 0 (master) devices.

SATA drives are designed for easy installation. It is usually not necessary to set any jumpers on the drive for proper operation; however, if users connect the drive and receive a "drive not detected" error, the SATA-equipped motherboard or host adapter may use a chipset that does not support SATA speed autonogotiation.


#### 3.3 SATA cables and connectors

The SATA interface cable consists of four conductors in two differential pairs, plus three ground connections. The cable size may be 30 to 26 AWG with a maximum length of one meter (39.37 inches). See **Table 5** for connector pin definitions. Either end of the SATA signal cable can be attached to the drive or host.

For direct backplane connection, the drive connectors are inserted directly into the host receptacle. The drive and the host receptacle incorporate features that enable the direct connection to be hot pluggable and blind mateable.

For installations which require cables, users can connect the drive as illustrated in Figure 1.

Figure 1 Attaching SATA cabling




Each cable is keyed to ensure correct orientation. NAS HDD drives support latching SATA connectors.

## 3.4 Drive mounting

Users can mount the drive in any orientation using four screws in the side-mounting holes or four screws in the bottom-mounting holes. Refer to Figure 2 for drive mounting dimensions. Follow these important mounting precautions when mounting the drive:

- Allow a minimum clearance of 0.030 inches (0.76mm) around the entire perimeter of the drive for cooling.
- Use only 6-32 UNC mounting screws.
- The screws should be inserted no more than 0.140 inch (3.56mm) into the bottom or side mounting holes.
- Do not overtighten the mounting screws (maximum torque: 6 inch-lb).

Figure 2 Mounting dimensions (6TB & 8TB)



## 4.0 SATA Interface

These drives use the industry-standard Serial ATA (SATA) interface that supports FIS data transfers. It supports ATA programmed input/output (PIO) modes 0 to 4; multiword DMA modes 0 to 2, and Ultra DMA modes 0 to 6.

For detailed information about the SATA interface, refer to the "Serial ATA: High Speed Serialized AT Attachment" specification.

#### 4.1 Hot-Plug compatibility

NAS HDD drives incorporate connectors which enable users to hot plug these drives in accordance with the SATA Revision 3.2 specification. This specification can be downloaded from <a href="www.serialata.org">www.serialata.org</a>.

## 4.2 SATA device plug connector pin definitions

**Table 5** summarizes the signals on the SATA interface and power connectors.

Table 5 SATA connector pin definitions

iabie 5 SAi	SAIA connector pin definitions					
Segment	Pin	Function	Definition			
	S1	Ground	2nd mate			
	S2	A+	Differential signal pair A from Phy			
	S3	A-	Differential signal pair A from Phy			
Signal	S4	Ground	2nd mate			
	S5	B-	Differential signal pair P from Phy			
	S6	B+	Differential signal pair B from Phy			
	S7	Ground	2nd mate			
Key and spa	acing sep	arate signal and power se	gments			
	P1	V <sub>33</sub>	3.3V power			
	P2	V <sub>33</sub>	3.3V power			
	Р3	V <sub>33</sub>	3.3V power, pre-charge, 2nd mate			
	P4	Ground	1st mate			
	P5	Ground	2nd mate			
	P6	Ground	2nd mate			
	P7	V <sub>5</sub>	5V power, pre-charge, 2nd mate			
Power	P8	V <sub>5</sub>	5V power			
	P9	V <sub>5</sub>	5V power			
	P10	Ground	2nd mate			
	P11	Ground or LED signal	If grounded, drive does not use deferred spin			
	P12	Ground	1st mate.			
	P13	V <sub>12</sub>	12V power, pre-charge, 2nd mate			
	P14	V <sub>12</sub>	12V power			
	P15	V <sub>12</sub>	12V power			

#### **Notes**

- 1. All pins are in a single row, with a 1.27 mm (0.050 in) pitch.
- 2. The comments on the mating sequence apply to the case of backplane blindmate connector only. In this case, the mating sequences are:
  - the ground pins P4 and P12.
  - the pre-charge power pins and the other ground pins.
  - the signal pins and the rest of the power pins.
- 3. There are three power pins for each voltage. One pin from each voltage is used for pre-charge when installed in a blind-mate backplane configuration.
  - All used voltage pins (V<sub>v</sub>) must be terminated.

## 4.3 Supported ATA commands

The following table lists SATA standard commands that the drive supports. For a detailed description of the ATA commands, refer to the Serial ATA International Organization: Serial ATA Revision 3.2 (<a href="https://www.sata-io.org">https://www.sata-io.org</a>).

See "S.M.A.R.T. commands" on page 29 for details and subcommands used in the S.M.A.R.T. implementation.

Table 6 SATA standard commands

Command name	Command code (in hex)
Check Power Mode	E5 <sub>H</sub>
Device Configuration Freeze Lock	B1 <sub>H</sub> /C1 <sub>H</sub>
Device Configuration Identify	B1 <sub>H</sub> /C2 <sub>H</sub>
Device Configuration Restore	B1 <sub>H</sub> /C0 <sub>H</sub>
Device Configuration Set	B1 <sub>H</sub> /C3 <sub>H</sub>
Device Reset	08 <sub>H</sub>
Download Microcode	92 <sub>H</sub>
Execute Device Diagnostics	90 <sub>H</sub>
Flush Cache	E7 <sub>H</sub>
Flush Cache Extended	EA <sub>H</sub>
Format Track	50 <sub>H</sub>
Identify Device	EC <sub>H</sub>
Idle	E3 <sub>H</sub>
Idle Immediate	E1 <sub>H</sub>
Initialize Device Parameters	91 <sub>H</sub>
Read Buffer	E4 <sub>H</sub>
Read DMA	C8 <sub>H</sub>
Read DMA Extended	25 <sub>H</sub>
Read DMA Without Retries	C9 <sub>H</sub>
Read Log Ext	2F <sub>H</sub>
Read Multiple	C4 <sub>H</sub>
Read Multiple Extended	29 <sub>H</sub>
Read Native Max Address	F8 <sub>H</sub>
Read Native Max Address Extended	27 <sub>H</sub>
Read Sectors	20 <sub>H</sub>
Read Sectors Extended	24 <sub>H</sub>
Read Sectors Without Retries	21 <sub>H</sub>
Read Verify Sectors	40 <sub>H</sub>
Read Verify Sectors Extended	42 <sub>H</sub>
Read Verify Sectors Without Retries	41 <sub>H</sub>
Recalibrate	10 <sub>H</sub>
Security Disable Password	F6 <sub>H</sub>
Security Erase Prepare	F3 <sub>H</sub>
Security Erase Unit	F4 <sub>H</sub>
Security Freeze	F5 <sub>H</sub>
Security Set Password	F1 <sub>H</sub>
Security Unlock	F2 <sub>H</sub>
Seek	70 <sub>H</sub>
Set Features	EF <sub>H</sub>
Set Max Address	F9 <sub>H</sub>

Table 6 SATA standard commands (continued)

Command name	Command code (in hex)	)
<b>Note:</b> Individual Set Max Address commands are identified by the value placed in the Set Max Features register as defined to the right.	Address: Password: Lock: Unlock: Freeze Lock:	00 <sub>H</sub> 01 <sub>H</sub> 02 <sub>H</sub> 03 <sub>H</sub> 04 <sub>H</sub>
Set Max Address Extended	37 <sub>H</sub>	1
Set Multiple Mode	C6 <sub>H</sub>	
Sleep	E6 <sub>H</sub>	
S.M.A.R.T. Disable Operations	B0 <sub>H</sub> / D9 <sub>H</sub>	
S.M.A.R.T. Enable/Disable Autosave	BO <sub>H</sub> / D2 <sub>H</sub>	
S.M.A.R.T. Enable Operations	B0 <sub>H</sub> / D8 <sub>H</sub>	
S.M.A.R.T. Execute Offline	BO <sub>H</sub> / D4 <sub>H</sub>	
S.M.A.R.T. Read Attribute Thresholds	BO <sub>H</sub> / D1 <sub>H</sub>	
S.M.A.R.T. Read Data	BO <sub>H</sub> / DO <sub>H</sub>	
S.M.A.R.T. Read Log Sector	BO <sub>H</sub> / D5 <sub>H</sub>	
S.M.A.R.T. Return Status	BO <sub>H</sub> / DA <sub>H</sub>	
S.M.A.R.T. Save Attribute Values	BO <sub>H</sub> / D3 <sub>H</sub>	
S.M.A.R.T. Write Log Sector	BO <sub>H</sub> / D6 <sub>H</sub>	
Standby	E2 <sub>H</sub>	
Standby Immediate	E0 <sub>H</sub>	
Write Buffer	E8 <sub>H</sub>	
Write DMA	CA <sub>H</sub>	
Write DMA Extended	35 <sub>H</sub>	
Write DMA FUA Extended	3D <sub>H</sub>	
Write DMA Without Retries	CB <sub>H</sub>	
Write Log Extended	3F <sub>H</sub>	
Write Multiple	C5 <sub>H</sub>	
Write Multiple Extended	39 <sub>H</sub>	
Write Multiple FUA Extended	CE <sub>H</sub>	
Write Sectors	30 <sub>H</sub>	
Write Sectors Without Retries	31 <sub>H</sub>	
Write Sectors Extended	34 <sub>H</sub>	
Write Uncorrectable	45 <sub>H</sub>	
ZAC Management In command template *	4A <sub>H</sub> / 00 <sub>H</sub>	
ZAC Management Out command template *	9F <sub>H</sub> / 01 <sub>H</sub> , 02 <sub>H</sub> , 03 <sub>H</sub> , 04 <sub>H</sub>	
- '	10 10 10 11 11	

<sup>\*</sup> For specific ZAC command reference refer to the following documentation: T13 INCITS BSR 537, Zoned-device ATA Command Set (ZAC) (planned as ISO/IEC 17760-171)

## 4.3.1 ZAC Supported Capabilities log page

The Supported Capabilities log page (log 30, pg03h) provides a mechanism for the device which defines support for ZAC.

Offset	Туре	Content	
112 - 119	QWord	Supported ZA	AC Capabilities
		Bit	Meaning
		63	Contents of the QWord are valid
		62.5	Reserved
		4	Non-Data Reset Write Pointers Ext Supported bit
		3	Non-Data Finish Zone Ext Supported bit
		2	Non-Data Close Zone Ext Supported bit
		1	Non-Data Open Zone Ext Supported bit
		0	Reset Zones Ext Supported bit
120 - 511		Reserved	

<sup>\*</sup>Additional detail defined by T13 INCITS BSR 537, Zoned-device ATA Command Set (ZAC) (planned as ISO/IEC 17760-171)

## 4.3.2 Identify Device command

The Identify Device command (command code  $EC_H$ ) transfers information about the drive to the host following power up. The data is organized as a single 512-byte block of data, whose contents are shown in on page 22. All reserved bits or words should be set to zero. Parameters listed with an "x" are drive-specific or vary with the state of the drive.

The following commands contain drive-specific features that may not be included in the SATA specification.

Word	Description	Value
0	Configuration information:  • Bit 15: 0 = ATA; 1 = ATAPI  • Bit 7: removable media  • Bit 6: removable controller  • Bit 0: reserved	0C5A <sub>H</sub>
1	Number of logical cylinders	16,383
2	ATA-reserved 0000 <sub>H</sub>	
3	Number of logical heads 16	
4	Retired 0000 <sub>H</sub>	
5	Retired	0000 <sub>H</sub>
6	Number of logical sectors per logical track: 63 003F <sub>H</sub>	
7–9	Retired 0000 <sub>H</sub>	
10–19	Serial number: (20 ASCII characters, 0000 <sub>H</sub> = none) ASCII	
20	Retired	0000 <sub>H</sub>
21	Retired	0400 <sub>H</sub>
22	Obsolete	0000 <sub>H</sub>
23–26	Firmware revision (8 ASCII character string, padded with blanks to end of string)	x.xx
27–46	Drive model number: (40 ASCII characters, padded with blanks to end of string)	
47	(Bits 7–0) Maximum sectors per interrupt on Read multiple and Write multiple (16)	8010 <sub>H</sub>
48	Reserved	0000 <sub>H</sub>
49	Standard Standby timer, IORDY supported and may be disabled	2F00 <sub>H</sub>
50	ATA-reserved	0000 <sub>H</sub>
51	PIO data-transfer cycle timing mode	0200 <sub>H</sub>
52	Retired	0200 <sub>H</sub>
53	Words 54–58, 64–70 and 88 are valid	0007 <sub>H</sub>
54	Number of current logical cylinders	xxxx <sub>H</sub>

Word	Description	Value
55	Number of current logical heads	xxxx <sub>H</sub>
56	Number of current logical sectors per logical track	xxxx <sub>H</sub>
57–58	Current capacity in sectors	xxxx <sub>H</sub>
59	Number of sectors transferred during a Read Multiple or Write Multiple command	xxxx <sub>H</sub>
60-61	Total number of user-addressable LBA sectors available (see Section 2.2 for related information) *Note: The maximum value allowed in this field is: 0FFFFFFF (268,435,455 sectors, 137GB). Drives with capacities over 137GB will have 0FFFFFFFh in this field and the actual number of user-addressable LBAs specified in words 100-103. This is required for drives that support the 48-bit addressing feature.	OFFFFFFh*
62	Retired	0000 <sub>H</sub>
63	Multiword DMA active and modes supported (see note following this table)	<i>xx</i> 07 <sub>H</sub>
64	Advanced PIO modes supported (modes 3 and 4 supported)	0003 <sub>H</sub>
65	Minimum multiword DMA transfer cycle time per word (120 nsec)  0078 <sub>H</sub>	
66	Recommended multiword DMA transfer cycle time per word (120 nsec)	0078 <sub>H</sub>
67	Minimum PIO cycle time without IORDY flow control (240 nsec)	0078 <sub>H</sub>
68	Minimum PIO cycle time with IORDY flow control (120 nsec)	0078 <sub>H</sub>
69	Zoned ATA Feature support 0001 <sub>H</sub>	
70–74	ATA-reserved 0000 <sub>H</sub>	
75	Queue depth	001F <sub>H</sub>
76	SATA capabilities	xxxx <sub>H</sub>
77	Reserved for future SATA definition	xxxx <sub>H</sub>
78	SATA features supported	xxxx <sub>H</sub>
79	SATA features enabled	xxxx <sub>H</sub>
80	Major version number 01F0 <sub>H</sub>	
81	Minor version number	0028 <sub>H</sub>
82	Command sets supported	364B <sub>H</sub>
83	Command sets supported	7F09 <sub>H</sub>
84	Command sets support extension (see note following this table)	4163 <sub>H</sub>
85	Command sets enabled	30xx <sub>H</sub>
86	Command sets enabled	BE09 <sub>H</sub>
87	Command sets enable extension	4163 <sub>H</sub>
88	Ultra DMA support and current mode (see note following this table)	xx7F <sub>H</sub>
89	Security erase time	0039 <sub>H</sub>
90	Enhanced security erase time	0039 <sub>H</sub>
92	Master password revision code	FFFE <sub>H</sub>
93	Hardware reset value xxxx <sub>H</sub>	
94	Automatic acoustic management	8080 <sub>H</sub>
95	Stream Min. Request Size	0000 <sub>H</sub>
96	Streaming Transfer Time - DMA	0000 <sub>H</sub>
97	Streaming Access Latency - DMA and PIO	0000 <sub>H</sub>
98–99	Streaming Performance Granularity	0000 <sub>H</sub>
100–103	Total number of user-addressable LBA sectors available (see Section 2.2 for related information). These words are required for drives that support the 48-bit addressing feature. Maximum value: 0000FFFFFFFFFF.	ST8000VN000 = 15,628,053,168 ST6000VN000 = 11,721,045,168
104	Streaming Transfer Time - PIO	0000 <sub>H</sub>
105–107	ATA-reserved	0000 <sub>H</sub>
108–111	The mandatory value of the world wide name (WWN) for the drive. <b>NOTE:</b> This field is valid if word 84, bit 8 is set to 1 indicating 64-bit WWN support.	Each drive will have a unique value.
112–127	ATA-reserved	0000 <sub>H</sub>
128	Security status	0001 <sub>H</sub>

Word	Description	Value
129–159	Seagate-reserved	xxxx <sub>H</sub>
160-254	ATA-reserved	0000 <sub>H</sub>
255	Integrity word	xxA5 <sub>H</sub>

Note Advanced Power Management (APM) and Automatic Acoustic Management (AAM) features are not supported.

**Note** See the bit descriptions below for words 63, 84, and 88 of the Identify Drive data.

Bit	Word 63
0	Multiword DMA mode 0 is supported.
1	Multiword DMA mode 1 is supported.
2	Multiword DMA mode 2 is supported.
8	Multiword DMA mode 0 is currently active.
9	Multiword DMA mode 1 is currently active.
10	Multiword DMA mode 2 is currently active.
Bit	Word 84
0	SMART error login is supported.
1	SMART self-test is supported.
2	Media serial number is supported.
3	Media Card Pass Through Command feature set is supported.
4	Streaming feature set is supported.
5	GPL feature set is supported.
6	WRITE DMA FUA EXT and WRITE MULTIPLE FUA EXT commands are supported.
7	WRITE DMA QUEUED FUA EXT command is supported.
8	64-bit World Wide Name is supported.
9-10	Obsolete.
11-	2 Reserved for TLC.
13	IDLE IMMEDIATE command with IUNLOAD feature is supported.
14	Shall be set to 1.
15	Shall be cleared to 0.
Bit	Word 88
0	Ultra DMA mode 0 is supported.
1	Ultra DMA mode 1 is supported.
2	Ultra DMA mode 2 is supported.
3	Ultra DMA mode 3 is supported.

5	Ultra DMA mode 5 is supported.
6	Ultra DMA mode 6 is supported.
8	Ultra DMA mode 0 is currently active.
9	Ultra DMA mode 1 is currently active.
10	Ultra DMA mode 2 is currently active.
11	Ultra DMA mode 3 is currently active.
12	Ultra DMA mode 4 is currently active.
13	Ultra DMA mode 5 is currently active.
14	Ultra DMA mode 6 is currently active.

**SATA Interface** www.seagate.com

#### 4.3.3 Set Features command

This command controls the implementation of various features that the drive supports. When the drive receives this command, it sets BSY, checks the contents of the Features register, clears BSY and generates an interrupt. If the value in the register does not represent a feature that the drive supports, the command is aborted. Power-on default has the read lookahead and write caching features enabled. The acceptable values for the Features register are defined as follows:

Table 7 Set Features commands

Tuble /	Set reutures Communus
02 <sub>H</sub>	Enable write cache (default).
03 <sub>H</sub>	Set transfer mode (based on value in Sector Count register). Sector Count register values:
	00 <sub>H</sub> Set PIO mode to default (PIO mode 2).
	01 <sub>H</sub> Set PIO mode to default and disable IORDY (PIO mode 2).
	08 <sub>H</sub> PIO mode 0
	09 <sub>H</sub> PIO mode 1
	0A <sub>H</sub> PIO mode 2
	0B <sub>H</sub> PIO mode 3
	0C <sub>H</sub> PIO mode 4 (default)
	20 <sub>H</sub> Multiword DMA mode 0
	21 <sub>H</sub> Multiword DMA mode 1
	22 <sub>H</sub> Multiword DMA mode 2
	40 <sub>H</sub> Ultra DMA mode 0
	41 <sub>H</sub> Ultra DMA mode 1
	42 <sub>H</sub> Ultra DMA mode 2
	43 <sub>H</sub> Ultra DMA mode 3
	44 <sub>H</sub> Ultra DMA mode 4
	45 <sub>H</sub> Ultra DMA mode 5
	46 <sub>H</sub> Ultra DMA mode 6
06 <sub>H</sub>	Enable the PUIS feature set
07 <sub>H</sub>	PUIS feature set device spin-up
10 <sub>H</sub>	Enable use of SATA features
55 <sub>H</sub>	Disable read look-ahead (read cache) feature
82 <sub>H</sub>	Disable write cache
86 <sub>H</sub>	Disable the PUIS feature set
90 <sub>H</sub>	Disable use of SATA features
$AA_H$	Enable read look-ahead (read cache) feature (default).
F1 <sub>H</sub>	Report full capacity available

Note

At power-on, or after a hardware or software reset, the default values of the features are as indicated above.

#### 4.3.4 S.M.A.R.T. commands

S.M.A.R.T. provides near-term failure prediction for disk drives. When S.M.A.R.T. is enabled, the drive monitors predetermined drive attributes that are susceptible to degradation over time. If self-monitoring determines that a failure is likely, S.M.A.R.T. makes a status report available to the host. Not all failures are predictable. S.M.A.R.T. predictability is limited to the attributes the drive can monitor. For more information on S.M.A.R.T. commands and implementation, see the *Draft ATA-5 Standard*.

SeaTools diagnostic software activates a built-in drive self-test (DST S.M.A.R.T. command for D4<sub>H</sub>) that eliminates unnecessary drive returns. The diagnostic software ships with all new drives and is also available at: <a href="http://seatools.seagate.com">http://seatools.seagate.com</a>.

This drive is shipped with S.M.A.R.T. features enabled. Table 8 below shows the S.M.A.R.T. command codes that the drive uses.

Table 8 S.M.A.R.T. commands

Code in features register	S.M.A.R.T. command
D0 <sub>H</sub>	S.M.A.R.T. Read Data
D2 <sub>H</sub>	S.M.A.R.T. Enable/Disable Attribute Autosave
D3 <sub>H</sub>	S.M.A.R.T. Save Attribute Values
D4 <sub>H</sub>	S.M.A.R.T. Execute Off-line Immediate (runs DST)
D5 <sub>H</sub>	S.M.A.R.T. Read Log Sector
D6 <sub>H</sub>	S.M.A.R.T. Write Log Sector
D8 <sub>H</sub>	S.M.A.R.T. Enable Operations
D9 <sub>H</sub>	S.M.A.R.T. Disable Operations
DA <sub>H</sub>	S.M.A.R.T. Return Status

<b>Note</b> If an appropriate code is not written to the Features Register, the command is aborted and $0x04$ (abort) is written to the Error register.
---



## **Seagate Technology LLC**

AMERICAS Seagate Technology LLC 10200 South De Anza Boulevard, Cupertino, California 95014, United States, 408-658-1000 ASIA/PACIFIC Seagate Singapore International Headquarters Pte. Ltd. 7000 Ang Mo Kio Avenue 5, Singapore 569877, 65-6485-3888 EUROPE, MIDDLE EAST AND AFRICA Seagate Technology SAS 16-18 rue du Dôme, 92100 Boulogne-Billancourt, France, 33 1-4186 10 00

Publication Number: 100758081, Rev. C

October 2015