

FRONT



FreeAgent^{Desk}
EXTERNAL DRIVE

QUICK START GUIDE

FOR
MAC




BACK


THANKS FOR PURCHASING A FREEAGENT™ DESK EXTERNAL HARD DRIVE!

CONTENTS


AC Adaptor




Firewire 800 Cable




Firewire 800 to
Firewire 400 Cable




USB Cable




FreeAgent Desk




POWER



CONNECT



DISCONNECT



WE'RE HERE TO HELP

Technical Support will answer technical and troubleshooting questions regarding your Seagate hard drive during normal call center business hours. Before calling, note your system configuration and model number. These numbers can be used to get help from Seagate Support, register your drive, and look up information on the Seagate web site. Please visit www.seagate.com to obtain the latest comprehensive support information, such as:

KNOWLEDGE BASE
Troubleshooting information, FAQs, and technical documentation.

SOFTWARE DOWNLOADS
Installation software, utilities, and diagnostics.
Visit: www.seagate.com/ww/en-us/support/downloads

PRODUCT INDEX
Current and legacy Seagate products.

WARRANTY SERVICES
Product returns (RMA), warranty status, and warranty information.

PRODUCT SUPPORT
Installation assistance, product specifications, and user manuals.

FCC DECLARATION OF CONFORMANCE
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause unintended operation.

CLASS B
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Any changes or modifications made to this equipment may void the user's authority to operate the equipment.

© 2008 Seagate Technology LLC. All rights reserved. Seagate, Seagate Technology, the Wave logo, and FreeAgent are trademarks or registered trademarks of Seagate Technology LLC, or one of its affiliated companies in the United States and/or other countries. All other trademarks or registered trademarks are the property of their respective owners. When referring to hard drive capacity, one gigabyte, or GB, equals one billion bytes and one terabyte, or TB, equals one thousand billion bytes when referring to hard drive capacity. Your computer's operating system may use a different standard of measurement and report a lower capacity. In addition, none of the listed capacity is used for formatting and other functions, and thus will not be available for data storage.

Seagate Technology LLC
920 10th Drive
Scotts Valley,
CA 95046 U.S.A.

PH: 1000XXXX 0708