

-
-
-
-




Contents


1	Connecting Mobile and Storage Devices to Wi-Fi Networks	4
	Connect from a mobile device	4
	Connect your wireless storage device to a Wi-Fi network (Internet)	4
2	Uploading, Downloading, and Sharing Files	6
	Upload content from your mobile device to your storage device	6
	• Upload content from the Start Page	7
	Download content from your storage device to your mobile device	7
	Share content	7
3	Viewing Media Libraries	9
4	Enjoying Your Media	11
	Play Videos	11
	• Watch a video	11
	• Watch multiple videos back-to-back	11
	• Video player	12
	View Photos	12
	• View a single photo	12
	• Watch a slideshow	12
	• Create and save a slideshow	12
	Listen to Music	13
	• Play a song	13
	• Play multiple music tracks back-to-back	13
	• Create a music playlist	13
	Viewing Documents	14
	• View a document	14
	• Rename a document	14
	• Manage multiple documents	15
	Review Recently Viewed Items	15
5	Using Media App Controls	16
	Start Page	16
	Navigate media libraries	16
	App bar	17
	App bar controls	17
6	Viewing and Filtering Content	18
	View	18



Filter	18
7 Customizing Your Storage Device	19
Charms bar	19
Charms bar settings	19
8 Managing Content on Your Storage Device	21
Copy content	21
Move content	21
Rename content	22
Delete content	22
9 Conserving Battery Life	24
Power settings options	24
Battery performance	24
10 Updating the Media App and the Storage Device	26
Update the media app	26
Review the current version of the media app	26
Update the storage device	26
Review the current version of the storage device's firm ware	26
11 Accessing Multiple Storage Devices on the Same Network	27
Add your devices to your network	27
• Choose the storage device:	27
12 Troubleshooting	30
Files take awhile to appear on the storage device	30
Cannot connect to wireless or network-attached storage devices	30
Connection to wireless storage is lost when the mobile device wakes from sleep	31
Video, song, or file does not play/open	31
Reformatted hard drive for Mac	31

-
-



-








Recent 



Videos 

Photos





Photos





-
-
-
-
-



-
-

•

•

•

•

•


•

•

-
-

-
-


-



-

-

-
-



-
-

-
-

-


-



Recent ▾

Videos ▾

Photos



-


-

-

-

-

-





-
-
-



-
-
-
-

•

•

•

•

•

•

•

•

•


•

•

•


•

-
-
-
-




-
-


-



-
-




-



-

-




-











Seagate Wireless Plus

Seagate Personal Cloud



Seagate Central

Seagate Wireless

-
-
-

-
-
-
-
-

-

-

-

-

-

-

-

