SEAGATE

Game Drive User Manual

Official Licensed Product

Click here to access an up-to-date online version
of this document. You will also find the most recent content as well as expandable illustrations, easier navigation, and search capability.

Contents

1 Connect Game Drive . . . 3

PlayStation® 5 console . . . 3
- Format your drive . . . 4

PlayStation® 4 console . . . 4
- Format your drive . . . 4

Electromagnetic interference . . . 5

Safely remove Game Drive External Hard Drive . . . 6

2 Regulatory Compliance . . . 7

FCC DECLARATION OF CONFORMANCE . . . 7
- CLASS B . . . 7

For Australian Customers Only . . . 7

China RoHS . . . 8

Taiwan RoHS . . . 8

VCCI-B . . . 9

Connect Game Drive

PlayStation® 5 and PlayStation® 4 consoles sold separately.

PlayStation® 5 console

Power on your PS5 console.

1. Connect the USB micro-B end of the cable to the USB micro-B port on Game Drive.
2. Connect the USB-A end of the cable to a USB-A port on your PS5 console.

PS5 Pro (CFI-7000 model group)



PS5 Slim (CFI-2000 model group)



PS5 (CFI-1000 model group)



Format your drive

Game Drive is delivered formatted in the exFAT file format. To use it as an external drive for your PlayStation 5, you must format the drive with your console.

> Formatting erases all data on the drive. Before formatting, be sure to copy any data you might need later.

1. Go to **Settings** > **Storage**.
2. Select **USB Extended Storage** > **Format as USB Extended Storage**.



3. If multiple USB drives are connected to your console, you can change which USB drive you format by selecting **Select Another USB Drive**.

> Do not turn off the power or disconnect the drive while it's being formatted. Doing so can lead to data loss as well as damage to Game Drive and/or your console.

PlayStation® 4 console

Power on your PS4 console.

1. Connect the USB micro-B end of the cable to the USB micro-B port on Game Drive.
2. Connect the USB-A end of the cable to a USB-A port on your PS4 console.



Format your drive

Game Drive is delivered formatted in the exFAT file format. To use it as an external drive for your PlayStation 4, you must format the drive with your console.

> Formatting erases all data on the drive. Before formatting, be sure to copy any data you might need later.

1. Go to **Settings** > **Devices** > **USB Storage Devices**.
2. Select the USB storage device to format and choose **Format as USB Extended Storage**.



> Do not turn off the power or disconnect the drive while it's being formatted. Doing so may cause data loss or damage Game Drive or your console.

Electromagnetic interference

To minimize electromagnetic interference (EMI), place Game Drive at least 10 cm (4 in) from the PlayStation console.

PS5 Pro (CFI-7000 model group)



PS5 Slim (CFI-2000 model group)



PS5 (CFI-1000 model group)



PS4

Safely remove Game Drive External Hard Drive

To protect your data, always follow the safe removal procedures for your operating system when disconnecting your product.

Regulatory Compliance

Equipment Name	External Hard Drive
Regulatory Model Number	SRD0LF0

FCC DECLARATION OF CONFORMANCE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CLASS B

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Any changes or modifications made to this equipment may void the user's authority to operate this equipment.

For Australian Customers Only

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

China RoHS

China RoHS 2 refers to the Ministry of Industry and Information Technology Order No. 32, effective July 1, 2016, titled Management Methods for the Restriction of the Use of Hazardous Substances in Electrical and Electronic Products. To comply with China RoHS 2, we determined this product's Environmental Protection Use Period (EPUP) to be 20 years in accordance with the Marking for the Restricted Use of Hazardous Substances in Electronic and Electrical Products, SJT 11364-2014.

中国 RoHS 2 是指 2016 年 7 月 1 日起施行的工业和信息化部令第 32 号“电力电子产品限制使用有害物质管理办法”。为了符合中国 RoHS 2 的要求，我们根据“电子电气产品有害物质限制使用标识”(SJT 11364-2014) 确定本产品的环保使用期 (EPUP) 为 20 年。

产品中有害物质的名称及含有的信息表
Names and information of hazardous substances in product

	有害物质 Hazardous Substances									
部件名称 Part Name	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr^{6+})	多溴联苯 (PBBs)	多溴二苯醚 (PBDEs)	邻苯二甲酸苯基丁基酯 (DBP)	邻苯二甲酸二异丁酯 (DIBP)	邻苯二甲酸甲苯基丁酯 (BBP)	邻苯二甲酸二(2-乙基己基)酯 (DEHP)
硬盘驱动器 HDD	X	O	O	O	O	O	O	O	O	O
外接硬盘印刷电路板 Bridge PCBA	X	O	O	O	O	O	O	O	O	O
电源 (如果提供) Power Supply (if provided)	X	O	O	O	O	O	O	O	O	O
接口电缆 (如果提供) Interface cable (if provided)	O	O	O	O	O	O	O	O	O	O
其他外壳组件 Other enclosure components	O	O	O	O	O	O	O	O	O	O

注 1: O: 表示该有害物质在该部件所有均质材料中的含量均不超出电器电子产品有害物质限制使用国家标准要求。
X: 表示该有害物质至少在该部件的某一均质材料中的含量超出电器电子产品有害物质限制使用 国家标准要求。
注 2: 以上未列出的部件，表明其有害物质含量均不超出电器电子产品有害物质限制使用国家标准要求。

Note 1: O: Indicates that the content of the hazardous substance in all homogeneous materials of this component does not exceed the requirements of the national standard for the restricted use of hazardous substances in electrical and electronic products.
X: Indicates that the content of the hazardous substance in at least one homogeneous material of this component exceeds the requirements of the national standard for the restricted use of hazardous substances in electrical and electronic products.
Note 2: For components not listed above, their hazardous substance content does not exceed the requirements of the national standard for the restricted use of hazardous substances in electrical and electronic products.

Taiwan RoHS

Taiwan RoHS refers to the Taiwan Bureau of Standards, Metrology and Inspection's (BSMI's) requirements in standard CNS 15663, Guidance to reduction of the restricted chemical substances in electrical and electronic equipment. Beginning on January 1, 2018, Seagate products must comply with the “Marking of presence” requirements in Section 5 of CNS 15663. This product is Taiwan RoHS compliant. The following table meets the Section 5 “Marking of presence” requirements. 台灣RoHS是指台灣標準局計量檢驗局(BSMI)對標準CNS15663要求的減排電子電氣設備限用化學物質指引。從2018年1月1日起，Seagate產品必須符合CNS15663第5節「含有標示」要求。本產品符合台灣RoHS。 下表符合第5節「含有標示」要求。

設備名稱：外接式硬碟，型號: SRD0LF0 Equipment Name: External Hard Drive, Model: SRD0LF0							
單元 Unit		限用物質及其化學符號 Restricted Substance and its chemical symbol					
		鉛 Lead (Pb)	汞 Mercury (Hg)	鎘 Cadmium (Cd)	六價鉻 Hexavalent chromium (Cr^{+6})	多溴聯苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
硬盤驅動器	HDD	—	O	O	O	O	O
外接硬盤印刷電路板	Bridge PCBA	—	O	O	O	O	O
電源 (如果提供)	Power Supply (if provided)	—	O	O	O	O	O
傳輸線材 (如果提供)	Interface cable (if provided)	O	O	O	O	O	O
其他外殼組件	Other enclosure components	O	O	O	O	O	O

備考1. "超出0.1 wt %" 及 "超出0.01 wt %" 係指限用物質之百分比含量超出百分比含量基準值。
Note 1: "Exceeding 0.1 wt %" and "exceeding 0.01 wt %" indicate that the percentage content of the restricted substance exceeds the reference percentage value of presence condition.

備考2. "O" 係指該項限用物質之百分比含量未超出百分比含量基準值。
Note 2: "O" indicates that the percentage content of the restricted substance does not exceed the percentage of reference value of presence.

備考3. "—" 係指該項限用物質為排除項目。
Note 3: The "—" indicates that the restricted substance corresponds to the exemption.

額定電壓/額定電流: 5VDC ⎓ 0.9A　　操作溫度: 5 – 40 °C

VCCI-B

この装置は、クラスB機器です。この装置は、住宅環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。取扱説明書に従って正しい取り扱いをして下さい。VCCI-B

© 2026 Seagate Technology LLC. All rights reserved. Seagate, Seagate Technology and the Spiral logo are registered trademarks of Seagate Technology LLC in the United States and/or other countries.

"", "PlayStation", "PS5", "PS4", and "PlayStation Shapes Logo (gradated)" are registered trademarks or trademarks of Sony Interactive Entertainment Inc. All other trademarks are the property of their respective owners. Manufactured and distributed under license from Sony Interactive Entertainment Inc. or its affiliates. Game Drive is officially licensed by Sony Interactive Entertainment for use with the PS5 and PS4 consoles. When referring to drive capacity, one gigabyte, or GB, equals one billion bytes and one terabyte, or TB, equals one trillion bytes. Your computer's operating system may use a different standard of measurement and report a lower capacity. In addition, some of the listed capacity is used for formatting and other functions, and thus will not be available for data storage. Quantitative usage examples for various applications are for illustrative purposes. Actual quantities will vary based on various factors, including file size, file format, features, and application software. Seagate reserves the right to change, without notice, product offerings or specifications.