

3

EN **Install the Seagate GoFlex™ software on your Mac.**
 To use with a computer running Windows®, go to support.seagate.com/crossplatform to download the HFS+ driver for Windows (drive must be connected during installation).

FR **Installez le logiciel Seagate GoFlex™ sur votre Mac.**
 Pour l'utiliser sur un ordinateur fonctionnant sous Windows®, consultez le site support.seagate.com/crossplatform afin de télécharger le pilote HFS+ pour Windows (le disque doit être connecté durant l'installation).

ES **Instale el software de Seagate GoFlex™ en su Mac.**
 Para usar en un equipo que ejecute Windows®, vaya a support.seagate.com/crossplatform para descargar el controlador HFS+ para Windows (la unidad debe estar conectada durante la instalación).

BR **Instale o software Seagate GoFlex™ no Mac.**
 Para usar com um computador com o Windows® em execução, acesse support.seagate.com/crossplatform para fazer o download do driver do HFS+ para Windows (a unidade deve estar conectada durante a instalação).

EN WWW.SEAGATE.COM

Visit us at our Support pages for assistance with:

- **Installation:** Additional instructions and troubleshooting assistance
- **Knowledge Base:** FAQ's, How to use this product
- **Download Center:** Installation software, utilities and diagnostics
- **Warranty Information**
- And all of your other storage needs

To contact support, visit us at our **Contact Us** page.

NOTE: To protect your data, always follow the safe removal procedures for your operating system when disconnecting your product.

FCC DECLARATION OF CONFORMANCE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


CLASS B

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Any changes or modifications made to this equipment may void the user's authority to operate this equipment.



FR WWW.SEAGATE.COM

Consultez les pages de support technique de notre site pour toute question relative aux points suivants :

- **Installation :** instructions supplémentaires et assistance dépannage
- **Base de connaissances :** FAQ, procédure d'utilisation du produit
- **Centre de téléchargement :** logiciels d'installation, utilitaires et diagnostics
- **Informations sur la garantie**
- Et toutes vos questions relatives au stockage des données

Pour contacter le support technique, consultez la page **Nous contacter**.

REMARQUE : pour protéger vos données, suivez toujours les procédures de retrait sécurisé correspondant à votre système d'exploitation lors de la déconnexion du produit.

ES WWW.SEAGATE.COM

Consulte nuestras páginas de asistencia técnica para recibir ayuda sobre:

- **Instalación:** Instrucciones adicionales y asistencia para la resolución de problemas
- **Base de conocimientos:** Preguntas más frecuentes y modo de utilización de este producto
- **Centro de descargas:** Software de instalación, utilidades y diagnóstico
- **Información de garantías**
- Y todas sus demás necesidades de almacenamiento

Para obtener datos de contacto, consulte nuestra página **Contacto**.

NOTA: Para proteger sus datos, asegúrese de seguir los procedimientos de extracción segura de su sistema operativo siempre que desconecte el producto.

BR WWW.SEAGATE.COM

Visite nossas páginas de Suporte para obter ajuda com:

- **Instalação:** instruções adicionais e assistência para solução de problemas
- **Base de Conhecimento:** perguntas frequentes, Como utilizar este produto
- **Download Center (Centro de downloads):** software de instalação, utilitários e diagnóstico
- **Informações sobre garantia**
- E todas as suas necessidades de armazenamento

Para entrar em contato com o suporte, visite nossa página **Contact Us** (Entre em contato conosco).

NOTA: Para proteger seus dados, sempre siga os procedimentos de remoção segura do seu sistema operacional ao desconectar o produto.



QUICK START GUIDE
GUIDE DE DÉMARRAGE RAPIDE
GUÍA DE INICIO RÁPIDO
GUIA DE INÍCIO RÁPIDO

GoFlex™ For Mac® and
GoFlex™ Pro For Mac®

ULTRA-PORTABLE DRIVE
DISQUE ULTRAPORTABLE



100647128

© 2010 Seagate Technology LLC. All rights reserved. Seagate, Seagate Technology, the Wave logo, and GoFlex are trademarks or registered trademarks of Seagate Technology LLC, or one of its affiliated companies in the United States and/or other countries. All other trademarks or registered trademarks are the property of their respective owners. Seagate reserves the right to change, without notice, product offerings or specifications. The export or re-export of hardware or software containing encryption may be regulated by the U.S. Department of Commerce, Bureau of Industry and Security (for more information, visit www.bis.doc.gov) and controlled for import and use outside of the U.S.

Seagate Technology LLC
920 Disc Drive
Scotts Valley, CA 95066
U.S.A.

