

Seagate® Nytro™ XP6209 Application Acceleration Card




Thank you for purchasing the Seagate Nytro XP6209 Application Acceleration card. Take a few minutes to read this quick installation guide before you install the Seagate Nytro XP6209 card.

For updated documentation, drivers, and utilities, please visit <http://www.seagate.com/support/downloads/> or contact your reseller support representative.

Quick Installation Guide

To install the Seagate® Nytro™ XP6209 card, follow these steps:

- 1. Unpack the card and inspect it for damage.** Unpack the card in a static-free environment, and follow good antistatic grounding procedures. Remove the card from the antistatic bag, and carefully inspect the device for damage. If you notice any damage or if any component is missing, contact Seagate or your reseller support representative.
CAUTION: Back up your data before changing your system configuration.
- 2. Prepare the computer.** Turn off the computer, and disconnect the power cord from the power supply. Remove the cover from the chassis.
WARNING: To avoid electrical shock, disconnect the computer from the main power and from any networks before you install the card.
- 3. Replace the PCI mounting bracket (system dependent).** If required for your system, replace the half-height PCI mounting bracket that ships on the Seagate Nytro XP6209 card with the longer bracket supplied. Save the two screws from the half-height bracket and use the screws to attach the long bracket.
- 4. Insert the Seagate Nytro XP6209 card in an available PCI Express® (PCIe®) slot.** Locate an empty PCIe slot. Remove the blank bracket panel on the computer chassis that aligns with the empty PCIe slot. Save the bracket screw, if applicable. Align the card to a PCIe slot. Press down gently, but firmly, to correctly seat the card in the slot. The following figure shows how to insert the card in a PCIe slot.



NOTE: The card shape, size, and component locations might vary from this figure.

- 5. Secure the bracket to the system's chassis.** Install the bracket screw, if applicable, or engage the system retention mechanism to secure the card to the system's chassis.
- 6. Replace the cover, the power cord, and power up the system.** Replace the system's cover, and reconnect the power cord and any network cables. Turn on the power.

The Seagate Nytro XP6209 card hardware installation is complete. Use the next procedure to install the appropriate operating system drivers.

Windows Driver Installation

The Seagate drivers for Windows Server® 2012 (x86) are available online.

To install the appropriate device driver, follow these steps:

- Follow the links on the Seagate USB drive to download the Windows® driver from the Seagate website, <http://www.seagate.com/support/downloads/>.
- Copy the appropriate driver files onto a disk.

3. Open the file and follow the directions in the `seagate_sss_[OperatingSystemName].txt` file.

To add the Seagate Nytro XP6209 card to a new or existing system installation, refer to the previously mentioned text file for instructions.

Linux Driver Installation

Download the latest Linux® drivers from Seagate website. Consult the Linux ReadMe .txt file available online with the driver. To open the readme file, click the plus sign next to the title of the driver. Go to the following link for Seagate downloads:

<http://www.seagate.com/products/solid-state-flash-storage/accelerator-cards/>

Seagate provides open source drivers in the following ways:

- Precompiled binaries to add to an existing installation using driver update disks or RPMs for selected distributions.
- Fusion-MPT™ source to add or update any distribution.

VMware Driver Installation

VMware ESX4.1, ESX 4.1 U2, ESXi 4.1 U2 x64

Download the latest VMware® ESX4.1 driver from the following Seagate website. (To open the readme file, click the plus sign next to the title of the driver.)

<http://www.seagate.com/products/solid-state-flash-storage/accelerator-cards/>.

VMware ESX5.0 U1, ESXi 5.1 x64

Use the following steps to download the latest VMware ESX5.0 or ESX 5.1 driver from the VMware website:

1. Go to this website:
<http://www.vmware.com/resources/compatibility/detail.php?deviceCategory=io&productid=33764&deviceCategory=io&VID=1000&DID=007E>.
 2. Copy the information string under Device Driver(s).
 3. Go to this website <https://my.vmware.com/web/vmware/downloads> to download the driver.
 4. Enter the information string in the search box.
 5. Click on the topmost link of the search results.
 6. After you download the driver zip file, refer to the *readme.txt* file for all installation instructions.
- You have now completed the installation of your Seagate Nytro XP6209 card.

TECHNICAL SUPPORT

For assistance installing, configuring, or using the Seagate Nytro XP6209 card, contact Seagate Technical Support:

Submit a support ticket here: <http://support2.seagate.com/>

Phone: 1-800-732-4283 (North America)
+00-800-4732-4283 (International)

Website: www.seagate.com

© 2014 Seagate Technology LLC. All rights reserved. Printed in USA. Seagate, Seagate Technology and the Wave logo are registered trademarks of Seagate Technology LLC in the United States and/or other countries. DuraWrite, Nytro, Fusion MPT, and Storage.Networking.Accelerated and SandForce are either trademarks or registered trademarks of Seagate Technology LLC or one of its affiliated companies in the United States and/or other countries. All other trademarks or registered trademarks are the property of their respective owners. Nytro products are not intended for use in life-support appliances, devices, or systems. Use of any Nytro product in such applications without written consent of the appropriate Seagate officer is prohibited. Seagate reserves the right to change, without notice, product offerings or specifications.

Email

support@seagate.com

Website

www.seagate.com

Document number: DB11-000174-02

