

CFA810A/CFA1080A
Intelligent Disk Drive
Product Manual

Production Release Per EC 5687
P/N 00550-001

Revision A
May 1994

CONNOR[®]
The Storage Answer

3081 Zanker Road
San Jose, CA 95134-2128
(408) 456-4500

FCC Notice

This equipment generates and uses radio frequency energy and, if not installed and used properly; that is, in strict accordance with the manufacturer's instructions, may cause interference to radio and television reception. It has been designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment on and off, you are encouraged to try to correct the interference by one or more of the following measures:

- Reorient the receiving antenna.
- Relocate the computer with respect to the receiver.
- Move the computer into a different outlet so that the computer and receiver are on different branch circuits.

If necessary, you should consult the dealer or an experienced radio/television technician for additional suggestions. You may find the following booklet prepared by the Federal Communications Commission helpful:

How to Identify and Resolve Radio-TV Interference Problems

This booklet (Stock No. 004-000-00345-4) is available from the U.S. Government Printing Office, Washington, DC 20402.

Warning: Changes or modifications made to this equipment which have not been expressly approved by Conner Peripherals, Inc. may cause radio and television interference problems that could void the user's authority to operate the equipment.

Further, this equipment complies with the limits for a Class B digital apparatus in accordance with Canadian Radio Interference Regulations.

Cet appareil numérique de la classe B est conforme au Règlement sur le brouillage radioélectrique, C.R.C., ch. 1374.

Conner and the Conner logo are registered trademarks of Conner Peripherals, Inc. All other trademarks mentioned in this manual are property of their respective owners.

Copyright 1994, Conner Peripherals, Inc.
All rights reserved.

Document No. 501-065 5/94

Important Information About this Manual

All information contained in or disclosed by this document is considered proprietary by Conner Peripherals, Inc. By accepting this material, the recipient agrees that this material and the information contained therein are held in confidence and in trust and will not be used, reproduced in whole or in part, nor its contents revealed to others, except to meet the purpose for which it was delivered. It is understood that no right is conveyed to reproduce or translate any item herein disclosed without express written permission from Conner Peripherals, Inc.

Conner Peripherals, Inc. provides this manual "as is," without warranty of any kind, either expressed or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Conner Peripherals, Inc. reserves the right to change, without notification, the specifications contained in this manual.

Conner Peripherals, Inc. assumes no responsibility for the accuracy, completeness, sufficiency, or usefulness of this manual, nor for any problem that might arise from the use of the information in this manual.

Table of Contents

1. Overview of the Drive	1
Description of the Drives	1
Features of the Drive	1
What the Drive is Composed Of	3
Mechanical Design Features	3
Drive Assembly Housing	4
Head Positioning Mechanism	5
Read/Write Heads and Disks	5
Data and Power Connections	5
Electrical Design Features	5
Integrated Circuit	5
Circuit Board	6
Firmware	6
2. Specifications	7
Specifications In This Chapter	7
Drive Capacity	8
Physical Configuration	8
Performance Characteristics	9
Read/Write Characteristics	10
Reliability	10
Power Requirements	11
Environmental Tolerances	11
Safety Standards	12
Physical Characteristics	13
3. How the Drive Operates	15
Functions of the Drive	15
Drive Operational Modes	15
Error Correction	15
Universal Translate Mode	16
Master/Slave Configuration	16
Supported Master/Slave Modes	17
ISA Original Master/Slave	17
Conner Master/Slave	19
ATA/CAM Master/Slave	20
4. Installing the Drive	21
Take These Precautions	21
Installing the Drive	21
Attaching a Data Cable to the Drive	23
Attaching Power to the Drive	25
Mounting the Drive	26

5. Host Interface	27
About the Host Interface	27
Signal Conventions	27
Signal Levels	27
Signal Descriptions	28
ATA/CAM Master/Slave Reset Timing	31
ISA/Conner Master/Slave Reset Timing	33
Host PIO 16-Bit Timing Values	34
Host Demand Mode DMA 16-bit Interface Timing Values	35
6. Register Addresses and Functions	37
Host Address Decoding	37
Addressing the Data	39
Cylinder-Head-Sector (CHS) Mode	39
Logical Block Addressing (LBA) Mode	39
Descriptions of the Registers	40
Data Register	40
Error Register	41
Features Register (formerly Write Precomp Register)	42
Sector Count	42
Sector Number	42
Cylinder Low	43
Cylinder High	43
SDH Register	44
Status Register	45
Alternate Status Register	46
Digital Output Register	47
Drive Address Register	48
Command Register	48
7. Command Set	51
Command Register	51
Conner Specific	52
Get Drive Feature word (00)	53
Read the Drive Switches (02)	54
Power Lock (08)	54
Power Unlock (09)	54
Execute Drive Diagnostic	55
Format Track	56
Marked Bad Sector	56
Assign	56
Identify Drive	58
Initialize Drive Parameters	62
Physical Seek	62
Power Commands	63
Read DMA	64
Read Multiple	65
Read Sector(s)	66
Read Sector Buffer	67
Read Verify Sectors	68
Recalibrate	68
Retry Count	69

Seek	69
Set Features (Set Look Ahead Read)	70
Set Multiple Mode	71
Translate	71
Write DMA	72
Write Caching	72
Write Multiple	73
Write Caching	73
Write Sector(s)	75
Write Caching	76
Write Sector Buffer	77
8. Error Reporting	79
Error and Status Detection	79
Error and Status Messages	79

Overview of the Drive

1

Description of the Drives

The Conner Filepro Advantage CFA810A and CFA1080A are high-performance, low-profile hard disk drives designed to operate with an IBM PC/AT or equivalent host computer system in translate mode. The drive supports advanced ATA PIO Mode 3 and DMA Mode 1 data transfer protocols for superior I/O performance. Logical Block Addressing (LBA) is supported for compatibility with advanced systems (BIOS) which support greater than 528MB capacity IDE drives, as well as Cylinder-Head-Sector (CHS) addressing for backward compatibility. Either a compatible BIOS or a suitable device driver is necessary to access all of the disk's capacity in a DOS environment.

Drive Model:	Form Factor:	Capacity (formatted):	No. of disks/heads:
CFA810A	inch high, 3.5 inch	810MB	3 disk/6 heads
CFA1080A	inch high, 3.5 inch	1080MB	4 disk/8 heads

For simplicity, we often refer to the two drives collectively in this manual as "the drive"

Features of the Drive

The drive provides these features:

- Task File emulation and ATA compatibility allows installation in a wide range of host systems.
- high-performance rotary voice coil actuator with embedded servoing eliminate the need for T-cal
- one-of-seven run-length limited code
- high shock resistance
- sealed head/disk assembly
- automatic actuator latch against inner stop upon power-down
- microprocessor-controlled diagnostic routines that are automatically executed at start-up
- 256KB segmentable cache buffer
- Read Look Ahead and selectable Write Caching
- automatic error correction and retries, single burst ECC on the fly

- supports ATA Standard PIO Mode 3 and DMA Mode 1
- 512-byte block size
- supports both CHS and LBA addressing
- allows daisy-chaining up to two drives on the AT interface
- Auto-Translate (Universal Translate)
- 4-byte ECC diagnostic check in read/write

The drive supports either of the following Master/Slave protocol standards:

- ATA/CAM (AT Attachment/Common Access Method)
- ISA/Conner (Industry-Standard Architecture)

What the Drive is Composed Of

The drive is composed of **mechanical**, **electrical**, and **firmware** elements.

Mechanical Design Features

The drive's hardware includes the components described in the following sections. Figure 1-1 shows the drive top level assembly, which is a combination of the drive's major mechanical and electrical assemblies.

Figure 1-1
Hard Drive Top Level Assembly





Figure 1-2 shows the details of the drive mechanism, which is called the head-disk assembly.

Drive Assembly Housing

The drive assembly housing consists of a die-cast aluminum base on which is mounted a die-cast aluminum cover. Both the base and the cover are coated with a special material designed to seal out contaminants which might degrade head and media reliability. A gasket seals the joint between the base and cover to retard the entry of moisture and environmental contaminants from the assembly.

This assembly, the head-disk assembly, contains an integral 0.3 micron filter, which maintains a clean environment. Critical drive components are contained within this contaminant-free environment.

Figure 1-2
Head-Disk Assembly



Drive Motor and Spindle

A brushless DC direct-drive motor assembly is mounted on the drive's base. The motor rotates the drive's spindle at 4500 RPM. The motor/spindle assembly is dynamically balanced to provide minimal mechanical runout to the disks. A dynamic brake is used to provide a fast stop to the spindle motor and return the heads to the landing zone when power is removed.

Head Positioning Mechanism

The read/write heads are supported by a mechanism coupled to a rotary voice coil actuator.

Read/Write Heads and Disks

Data is recorded on 95mm diameter disks through 3370-type thin film heads.

The CFA810A contains:

- three disks with six data surfaces
- six read/write heads

The CFA1080A contains:

- four disks with eight data surfaces
- eight read/write heads

At power-down, the heads are automatically retracted to the inner diameter of the disk and are latched and parked on a landing zone that is inside the data tracks.

Data and Power Connections

The drive has a single 40-pin data connector, as well as an auxiliary connector which is reserved for factory or evaluation use.

The drive has a standard 4-pin power connector and may optionally have a 3-pin connector, only one of which should be used at a time.

The drive also has a jumper block located next to the auxiliary connector which can be set to specify drive operational parameters. For more information on the drive's connectors and on setting jumpers, refer to chapters 3 and 4.

Electrical Design Features**Integrated Circuit**

A single integrated circuit (IC) is mounted within the sealed hard drive assembly in close proximity to the read/write heads. The IC provides head selection, read pre-amplification, and write drive circuitry.

Circuit Board

The drive's microprocessor-controlled circuit board provides the remaining electronic functions, which include:

- read/write circuitry
- rotary actuator control
- interface control
- spin speed control
- auto-park
- power management

Firmware

The drive's firmware includes a command set which the host uses to control the drive. The command set allows the host to request the following types of actions:

- report drive status
- seek a specific point on the disk
- read and write data

For more information on the drive's command set, refer to chapters 6 and 7.

Specifications In This Chapter

This chapter defines the following specifications for the drive:

- drive capacity
- physical configuration
- performance characteristics
- read/write characteristics
- reliability
- power requirements
- environmental tolerances
- safety standards
- physical characteristics

Drive Capacity

Formatted Capacity:

- CFA810A: 810MB
- CFA1080A: 1080MB

* 1MB = 1 x 10⁶ or 1,000,000 bytes

Physical Configuration

Specification	CFA810A:	CFA1080A:
Disk Type	Sputtered Thin Film	Sputtered Thin Film
Head Type	Thin Film	Thin Film
Actuator Type	Rotary Voice Coil	Rotary Voice Coil
Number of Disks	3	4
Data Surfaces	6	8
Data Heads	6	8
Servo	Embedded	Embedded
Tracks per Surface	2801	2801
Buffer Size	256KB	256KB
Track Density	3200 tpi	3200 tpi
Formatted Track Capacity	36,352 - 57,856 bytes	36,352 - 57,856 bytes
Bytes per Block	512	512
Blocks per Drive	1,585,488	2,113,984
Sectors per Track (User)	71 - 113	71 - 113
Translate	Universal*	Universal*

* Refer to chapter 3 for a definition of Universal Translate Mode

Performance Characteristics

Seek Times (typical)* :

- Track to track: 3.0 ms
 - Average: 10.5 ms read, 11.5 ms write **
 - Maximum: 20 ms
- The timing is measured through the interface with the drive operating at nominal DC input voltage and nominal operating temperature. The timing also assumes that:
 - BIOS and PC system hardware dependency have been subtracted from timing measurements
 - the drive is operated using its native drive parameters
 - the controller overhead is the time it takes to assert +HOST IRQ after the host writes the command register with a READ instruction, for the case where the data already resides in the buffer
- ** The average seek time is determined by averaging the seek time for a minimum of 1000 seeks of random length over the surface of the disk.

Average Latency:

- 6.67 ms

Rotation Speed:

- 4500 RPM ($\pm 0.1\%$)

Average Controller Overhead:

- <500 μ sec

Start Time at Power-Up: *

- 0 RPM to 4500 RPM
 - Typical: 7 seconds
 - Maximum: 12 seconds
- 0 RPM to Ready
 - Typical: 12 seconds
 - Maximum: 20 seconds

- * These numbers assume spin recovery is not invoked. If spin recovery is invoked, the maximum could be 40 seconds. Briefly removing power can lead to spin recovery being invoked.

Stop Time at Power-Down:

- Typical: 15 seconds
- Maximum: 20 seconds

Interleave:

- 1:1

Read/Write Characteristics

Interface:

- Task File

Recording Method:

- 1 of 7 RLL code

Recording Density (ID):

- 65,000 bits per inch

Flux Density (ID):

- 48,340 flux reversals per inch

Data Transfer Rate:

- To/From Media: 3.4 - 5.76 MB/second
- To/From Host: 11.1 MB/second burst, 8.3 MB/second sustained

Reliability

Data Reliability:

- < 1 non-recoverable error in 10^{14} bits read

Component Design Life:

- 5 years

Start/Stop Cycles:

- 20,000 minimum

Mean Time Between Failures:

- 300,000 power-on hours

Mean Time to Repair:

- 10 minutes typical

Preventive Maintenance:

- none

Power Requirements

<i>Mode: *</i>	+5 Volts (typical):	+12 Volts (typical):	Watts (typical):	Watts (maximum):
Read/Write	640 mA	190 mA	5.5 W	6.1 W
Seek (100%)	620 mA	490 mA	9.0 W	10.1 W
Seek (30%)	440 mA	230 mA	5.0 W	5.4 W
Idle	420 mA	180 mA	4.3 W	4.7 W
Standby	380 mA	80 mA	2.9 W	3.3 W
Sleep	260 mA	80 mA	2.3 W	2.5 W
Spin-Up	720 mA	1600 mA	N/A	N/A

* Refer to chapter 3 for the definitions of the modes. Spin-Up Mode current draw is for 7 seconds, maximum. Typical conditions are both voltages at nominal value, room temperature (25° C) ambient to the drive. Maximum power is when the supply voltage is at the worse case condition.

Minimum/Maximum Voltage:

- +5V: $\pm 5\%$
- +12V: $\pm 10\%$

Maximum Peak-to-Peak Noise Allowed (DC to 1 MHz, with equivalent resistive load):

- +5V: 2%
- +12V: 1%

Environmental Tolerances

Temperature:

- Operating: 5° to 55° C
- Non-operating: -40° to 60° C
- Thermal Gradient: 20° C per hour maximum

Relative Humidity (non-condensing):

- Operating: 5 to 95%
- Non-operating: 5 to 95%
- Wet Bulb: 29° C

Altitude (relative to sea level):

- Operating: -200 to 15,000 feet
- Non-operating: 40,000 feet (maximum)
- Altitude Gradient: 1,000 feet/minute

Shock (half-sine pulse, 11 ms duration):

- Operating: 5G without non-recoverable errors
- Non-operating: 75G without non-recoverable errors

Vibration (swept-sine, one octave per minute):

- Operating
 - 5 - 32 Hz: 0.01 inch displacement; double amplitude
 - 32 - 400 Hz: 0.5G without non-recoverable errors
- Non-operating
 - 5 - 28 Hz: 0.10 inch displacement; double amplitude
 - 28 - 400 Hz: 4G peak

Magnetic Field:

- The disk drive will meet its specified performance while operating in the presence of an externally-produced magnetic field under the following conditions:

Field Frequency	Intensity
DC	6 gauss
to 700 Khz	7 milligauss
700 Khz to 1.5 Mhz	3 milligauss

Acoustic Noise:

- The sound pressure level will not exceed 38 dBA in Idle Mode at a distance of 1 meter from the drive. The sound power level measured based on ISO 7779 will not exceed 4.3 Bel in Idle Mode.

Safety Standards

The drive is designed to comply with relevant product safety standards, including:

- UL 478, 5th edition, Standard for Safety of Information Processing and Business Equipment
- UL 1950, Standard for Safety of Information Technology Equipment
- CSA 22.2 #220, Information Processing and Business Equipment
- CSA 22.2 #950, Safety of Information Technology Equipment
- IEC 380, Safety of Electrically Energized Office Machines
- IEC 950, Safety of information Technology Equipment Including Electrical Business Equipment
- VDE 0805, VDE 0805 TIEL 100, and VDE 0806
- Complies with FCC Class B, Part 15, Subpart J

Physical Characteristics

Height:

- 1.0 inch \pm .030

Width:

- 4.0 inches \pm .020


Depth:

- 5.75 inches \pm .020

Weight:

- 1.30 pounds

Figure 2-1
The Drive's Physical Dimensions



Functions of the Drive

This chapter describes certain operational aspects of the drive, including discussions of:

- drive operational modes
- error correction
- Universal Translate Mode
- master/slave configurations

Drive Operational Modes

The drive operates in the following modes:

- **Read/Write Mode** occurs when data is read from or written to the disk.
- **Seek Mode (100%)** occurs when the actuator is in motion.
- **Seek Mode (30%)** is composed of 1/3 stroke seeks with a 30% duty cycle.
- **Idle Mode** occurs when the drive is not reading, writing, or seeking. The motor is up to speed and the **Drive Ready** condition exists. The actuator is residing on the last-accessed track.
- **Standby Mode** occurs when the motor is stopped and the actuator is parked. Standby Mode occurs after a programmable time-out since the last host access occurs. The drive will leave Standby Mode upon receipt of a command which requires disk access, or upon receipt of a spin-up command.
- **Sleep Mode** occurs when all electronics are disabled. The host is required to issue a **Reset** command to exit the Sleep Mode.
- **Spin-Up Mode** occurs while the drive is spun up to speed after being powered on or after exiting Standby or Sleep Mode.

Error Correction

The drive uses a Reed-Solomon code to perform error detection and correction. For each 512-byte block, the software error correction polynomial is capable of correcting:

- one error burst up to 22 bits
- two error bursts up to 11 bits each

Single bursts of 11 bits or less are corrected on the fly (OTF) with no performance degradation.

Universal Translate Mode

Conner has established a Universal Translate Mode which enables you to configure the drive in an AT environment to any cylinder, head, and sector configuration desired. The translate configuration is limited by the maximum capacity of the drive and host system parameters. Upon initial power-up of the drive, it will default to the configuration shown below:

<i>Drive:</i>	<i>No. of Cylinders:</i>	<i>No. of Heads</i>	<i>No. of Sectors:</i>
CFA810A	1572	16	63
CFA1080A	2097	16	63

After the drive is ready, the host system may issue an **Init Drive Params** command (command code 91 hex) to alter the translate configuration (number of heads and number of sectors per track). The drive will then:

- calculate the total number of available logical tracks based upon the entered sector and head values
- save the drive parameters in non-volatile memory for subsequent drive operations

☞ **Note:** BIOS in older systems may be limited to a maximum of 1024 cylinders. It may be necessary to manually enter 1024 cylinders into the User Defined parameter list in this case. Device drivers are available to overcome this limitation and the instructions which accompany the driver should be followed for installation.

Master/Slave Configuration

When two drives are daisy-chained on the host interface, one must be designated as the **master drive** (C: drive) and one as the **slave drive** (D: drive). Commands from the host are written in parallel to both drives.

When the C/D jumper on the drive is closed, the drive will assume the role of a master. When C/D is open, the drive will act as a slave. In single-drive configurations, C/D must remain in the closed (master) position. For more information on setting the C/D jumper, refer to chapter 4.

For each command sent from the host, the DRV bit in the drive/head register selects the master or the slave drive. When the DRV bit is reset (0), the master drive is selected, and when the DRV bit is set (1), the slave drive is selected.

Once the drives receive the command, only the drive with jumper C/D set to the appropriate position will execute the command. For example, if the DRV bit is set, only the slave drive (jumper C/D open) will execute the command.

☞ **Note:** If the command is a diagnostic command, both drives will execute the command and the slave will report its status to the master via the Host PDIAG signal.

Throughout this manual, **drive selection** always refers to the state of the DRV bit and the position of the C/D jumper.

The drive supports two master/slave modes via the A/C jumper. When A/C is closed, ATA/CAM master/slave mode is selected. When A/C is open, Conner master/slave mode is selected. For more information on setting the A/C jumper, refer to chapter 4.

Supported Master/Slave Modes

There are three different master/slave methods that Conner supports.

- ISA Original
- Conner
- ATA/CAM

Of these three methods, the drive supports all except ISA/Original mode, with which it is compatible.

☞ **Note:** The ATA/CAM master/slave method is not compatible with the other two methods. The Conner mode is backward-compatible to the ISA Original mode, but is not compatible with the other.

These three methods are explained in the following sections. For signals followed by a '~', activate means go low and deactivate means go high.

ISA Original Master/Slave

The signals used for master/slave operation and determination are Host DASP~ and Host PDIAG~.

Host DASP~ can be used to:

- drive an activity LED
- indicate that the slave drive is present to the master

The Host PDIAG~ is used to indicate that the slave has passed diagnostics both at power-on reset (POR) and when the diagnostic command is issued.

At power-on time, the slave drive activates Host PDIAG~ and Host DASP~. Host PDIAG~ remains activated from POR until a diagnostic command is issued by the host. Once a diagnostic command is issued by the host, the slave deactivates Host PDIAG~ until either:

- the slave successfully completes the diagnostic command
- the host issues a reset

There are no real timing constraints on Host PDIAG~ and Host DASP~. At POR, they are both activated within a second or two. When the diagnostic command is issued by the host, the slave inactivates Host PDIAG~ within 100-

200 microseconds and is required to reactivate it within 5 seconds (the only timing constraint) if it successfully completes the command.


This scheme works fairly well except for two problems:

- There is no way to tell when the slave becomes ready. If the slave becomes ready much later than the master, the slave will miss any commands that are issued before it goes not busy because the host only polls the master to see if the “controller” is ready.
- In a two-drive configuration, the Host DASP~ line is not available to drive a drive activity indicator.

In this mode of master/slave, master/slave re-configures with either a hardware or software reset. A hardware reset is either a POR or host reset.

This version of master/slave is present on generations 1, 2 and 3 of Conner drives.

Figure 3-1
ISA Original Master/Slave Timings



Conner Master/Slave

To remedy the problem of the host not knowing when the slave was ready, Conner developed a backward-compatible solution, which we call Conner Master/Slave.

In Conner Master/Slave, the use of the Host PDIAG~ signal has been changed slightly during reset so that the slave will indicate when it will go not busy. Its use in the diagnostic command has not been changed.

During POR or any host reset, the slave drive activates Host PDIAG~ within 1ms. The master drive waits slightly longer than 1 ms for Host PDIAG~ to be activated before it determines that no slave is present. The slave then deactivates Host PDIAG~ when it is ready. The master waits:


- up to 14 seconds for the slave to deactivate Host PDIAG~ on either a POR or a host reset
- 450 ms for the slave to deactivate Host PDIAG~ on a host software reset

If the master times out, it goes not busy.

In this mode of master/slave, master/slave re-configures with either a hardware or software reset. A hardware reset is either a Power On Reset (POR) or host bus reset.

This solution was implemented in generations 4 and greater of Conner drives.

Figure 3-2
Conner Master/Slave Timings



* 1.45 s for hardware reset, 450 ms for software reset


ATA/CAM Master/Slave

This industry-standard master/slave solution was developed by the CAM shortly after the development of the Conner Master/Slave. The polarity of Host PDIAG \sim is opposite that of the Conner solution and this is what makes this master/slave scheme incompatible with the Conner scheme.

At power-on time, the slave deactivates Host PDIAG \sim and then activates Host DASP \sim within 1ms of either POR or host reset. Host DASP \sim active indicates that a slave is present. The slave activates Host PDIAG \sim when it is ready to accept commands or after 30 seconds. The drive will inactivate Host DASP \sim when it receives the first command or after 30 seconds, whichever occurs first. This period is reduced to 450ms for a software reset. A hardware reset is either a POR or host bus reset.


This solution was implemented in generations 4.5 and greater of Conner drives and is selectable with the A/C jumper or the CAM bit in the feature word.

Figure 3-3
ATA/CAM Master/Slave Timings



* active until first command or 30 s, whichever is less

Take These Precautions



To protect your equipment from electrostatic damage, perform the installation at a static-safe workstation. If one is not available, follow these guidelines:

1. Work in an uncarpeted area.
2. Before removing the equipment from its anti-static bag, discharge static electricity by touching your computer's metal chassis (or any other grounded object) while touching the anti-static bag.
3. Do not touch circuit boards unless instructed to do so.

0170

Installing the Drive


To install the drive, you must:

- set the drive's jumpers, if desired
- attach a data cable to the drive
- attach power to the drive
- mount the drive

Setting the Drive's Jumpers

Figure 4-1 shows you how to access the drive's jumpers.

Figure 4-1
Jumper Locations




Here is how you can set these jumpers. Pins described as “reserved” should not be used.

<i>Pins:</i>	<i>Signal:</i>	<i>Description</i>
1 and 2	C/D	Open: Drive will act as slave. Closed: Drive will act as master.
3 and 4	A/C	Open: Conner master/slave mode Closed: ATA/CAM master/slave mode
5 to 16	N/A	Reserved

Attaching a Data Cable to the Drive

Attach the data cable from the host to the Task File Interface connector, as shown in figure 4-2. Refer to the table on the following page for pinout information.

Figure 4-2
Attaching a Data Cable



Caution: Do not route the data cable next to the drive PCB or any other high frequency or large current switching signals. Improper drive operation can result from improper cable routing.


Pin:	Signal:	Pin:	Signal:
01	- HOST RESET	02	GND
03	+ HOST DATA 7	04	+ HOST DATA 8
05	+ HOST DATA 6	06	+ HOST DATA 9
07	+ HOST DATA 5	08	+ HOST DATA 10
09	+ HOST DATA 4	10	+ HOST DATA 11
11	+ HOST DATA 3	12	+ HOST DATA 12
13	+ HOST DATA 2	14	+ HOST DATA 13
15	+ HOST DATA 1	16	+ HOST DATA 14
17	+ HOST DATA 0	18	+ HOST DATA 15
19	GND	20	KEY
21	+ DMARQ	22	GND
23	- HOST IOW	24	GND
25	- HOST IOR	26	GND
27	+ IOCHRDY	28	+Spindle Sync or Cable Select
29	- DACK	30	GND
31	+ HOST IRQ14	32	- HOST IO16
33	+ ADDR1	34	- HOST PDIAG
35	+ ADDR0	36	+ ADDR2
37	- HOST CS0	38	- HOST CS1
39	- HOST SLV/ACT	40	GND

The recommended mating connector for the Task File Interface is Molex P/N 15-47-5401 or equivalent. You may daisy-chain two drives on this connector. The maximum cable length is 18 inches.

Attaching Power to the Drive

The drive has a standard 4-pin DC power connector and may have an optional, smaller, 3-pin connector. Power must only be supplied at one source.

Figure 4-3
Attaching a Power Cable



Caution: Do not route the power cable next to the drive PCB or any other high frequency or large current switching signals. Improper drive operation can result from improper cable routing.

The following table describes the 4-pin power connector pins:

Pin:	Signal:
1	+12 Volts
2	GND
3	GND
4	+5 Volts

The mating connector for the 4 pin connector is AMP 1-480424-0 (housing) and AMP 60619-4 (loose piece) or 61117-4 (strip) contacts.

The following table describes the 3-pin power connector pins:

<i>Pin:</i>	<i>Signal:</i>
1	+5 Volts
2	+12 Volts
3	GND

The mating connector for the 3-pin connector is Molex series 54-84 (header), Molex part number 39-01-0033 (housing), and terminal part number 39-00-0031 (loose) or 39-00-0023 (strip).

Mounting the Drive

You can mount the drive either vertically or horizontally. The drive will meet all performance specifications when mounted at any orientation.



Caution: The surface(s) on which you mount the drive should be flat and parallel to prevent uneven pressure on the drive. Mounting the drive on an uneven surface could cause the drive's base to deform, degrading drive performance.



Caution: When using the side mounting holes, verify the screw length to ensure clearance from the drive's printed circuit board before tightening the screw.

Refer to figur 2-1 in chapter 2 for dimensions and the location of mounting screw holes.

About the Host Interface

The interface between the drive adapter and the drive is called the **host interface**. The set of registers in the I/O space of the host that are controlled through the host interface is known as the **task file**.

The physical interface from the drive to the host is called the **task file interface** and is implemented using a 40-pin connector. The pin assignments were described in chapter 4.

Definitions of signals are listed beginning on the next page under **Signal Descriptions**.

Signal Conventions

The following conventions are used in the discussions that follow:

- All signals on the host interface shall have the prefix HOST.
- All negatively-active signals shall be further prefixed with a “-” designation.
- All positive-active signals shall be prefixed with a “+” designation.
- Signals whose source is the host are said to be “outbound” and those whose source is the drive are said to be “inbound.”

Signal Levels

All signal levels are TTL compatible. A logic “1” is >2.0 Volts. A logic “0” is from 0.00 Volts to 0.70 Volts. The drive capability of each of the inbound signals is described below.

Signal Descriptions

The following table describes signals on the task file interface.

Signal Name:	Dir:	Pin:	Description:
-HOST RESET	O	1	Reset signal from the host system which is active low during power-up and inactive thereafter.
GND	O	2, 19, 22, 24, 26,30, 40	Ground between the drive and the host.
+HOST DATA	I/O	3 - 18	16-bit bi-directional data bus 0 - 15 between the host and the drive. The lower 8 bits, HD0 - HD7, are used for register and ECC access. All 16 bits are used for data transfers. These are tri-state lines with 24 mA drive capability.
KEY	N/C	20	An unused pin clipped on the drive and plugged on the cable. Used to guarantee correct orientation of the cable.
+DMARQ	I	21	Host DMA request handshake signal.
-HOST IOW	O	23	Write strobe, the rising edge of which clocks data from the host data bus, HD0 - HD15, into a task file register or the data register on the drive.
-HOST IOR	O	25	Read strobe, which when low enables data from the Task File on the drive onto the host data bus, HD0 - HD15. The rising edge of -HOST IOR latches data from the drive at the host.
+IOCHRDY	I	27	This signal is negated to extend host transfer cycles when the controller is not ready to respond.
+SPINDLE SYNC/CABLE SELECT	I/O	28	Optional. This signal may optionally be used for two functions. Drives are shipped with the interface pin not connected to either signal unless otherwise requested. <ul style="list-style-type: none"> • Spindle Sync is a signal used by the drives which are interconnected on the same cable to synchronize their spindle rotation with each other.. • Cable Select routes the C/D select to this pin. When set high, drive D: is selected; when set low, drive C: is selected.
-DACK	O	29	Host DMA acknowledge handshake signal.

Signal Name:	Dir:	Pin:	Description:
+HOST IRQ14	I	31	<p>Interrupt to the host system, enabled only when the drive is selected and the host activates the -IEN bit in the Digital Output register. When the -IEN bit is inactive or when the drive is not selected, this output is in a high impedance state, regardless of the state of the IRQ bit.</p> <p>IRQ is reset to zero by a host read of the Status register after completion of a data transfer phase or a write to the Command register. This signal is a tri-state line with 8 mA drive capacity.</p>
-HOST IO16	I	32	<p>Indication to the host system that the 16-bit data register has been addressed and that the drive is prepared to send or receive a 16-bit data word. This line is tri-state line with 24 mA drive capacity.</p>
-HOST PDIAG	I	34	<p>ISA Original Mode. Passed diagnostic. At POR, the slave will activate -PDIAG within 1 ms. If the master doesn't see -PDIAG active after 4 ms, it will assume no slave is present PDIAG will remain active until the slave is ready to go not busy or 14.0 seconds on a POR. The master will wait 14.5 seconds or until the slave deactivates -PDIAG on POR before it goes not busy. The slave will de-activate -PDIAG and go not busy if it is not ready after the 14.0 seconds. Neither drive will set ready or seek complete until they have reached full spin speed and are ready to read/write.</p> <p>During a software reset, -PDIAG will be activated by the slave within 1 ms. If the master doesn't see -PDIAG active after 4 ms it will assume no slave is present. The slave will not de-activate -PDIAG until it is ready to go not busy or 400 ms. The master will only wait 450 ms or until the slave deactivates -PDIAG before it goes not busy. The slave will only wait 450 milliseconds before it activates -PDIAG and goes not busy. The slave will not set ready or seek complete until those states are achieved.</p> <p>After reset, -PDIAG will be used for the diagnostic command in the following manner. It is output by the drive if it is the slave drive, input to the drive if it is the master drive. This low true signal indicates to a master that the slave has passed its internal diagnostic command. This line is only inactive high during execution of the diagnostic command.</p>


Signal Name:	Dir:	Pin:	Description:
-HOST PDIAG	I	34	<p>ATA/CAM Mode. This signal shall be asserted by the slave to the master that it has completed diagnostics. A 10K ohm pull-up resistor shall be used on this signal by each drive.</p> <p>Following a POR, a software reset, or a RESET-, the slave will negate PDIAG- within 1 ms (to indicate to the master that it is busy). The slave will then assert PDIAG- within 30 seconds to indicate that it is no longer busy and is able to provide status. After the assertion of PDIAG-, the slave may be unable to accept commands until it has finished its reset procedure and is ready (DRDY =1).</p> <p>Following the receipt of a valid Execute Drive Diagnostics command, the slave will negate PDIAG- within 1 ms to indicate to the master that it is busy and has not yet passed its drive diagnostics. If the slave is present, then the master will wait for up to 5 seconds from the receipt of a valid Execute Drive Diagnostics command for the slave to assert PDIAG-. The slave should clear BSY before asserting PDIAG-, as PDIAG- is used to indicate that the slave has passed its diagnostics and is ready to post status.</p> <p>If DASP- was not asserted by the slave during reset initialization, the master will post its own status immediately after it completed diagnostics and clear the slave status register to 00 hex. The master may be unable to accept commands until it has finished its reset procedure and is Ready (DRDY = 1).</p>
+HOST A0,A1,A2	O	35, 33, 36	Bit binary coded address used to select the individual registers in the task file.
-HOST CS0	O	37	Chip select decoded from the host address bus. Used to select some of the host-accessible registers. Note: This signal should be disabled by the host when data transfers are in progress.
-HOST CS1	O	38	Chip select decoded from the host address bus. Used to select three of the registers in the task file.
-HOST SLV/ACT	I	39	ISA Mode. Signal from the drive used either to drive an activity LED whenever the disk is being accessed.

Signal Name:	Dir:	Pin:	Description:
-DASP	I	39	<p>ATA/CAM Mode. DASP- (drive active/slave present). This is a time-multiplexed signal which indicates that a drive is active, or that the slave is present. This signal is an open-collector output and each drive has a 10K pull-up resistor.</p> <p>During power-on initialization or after RESET is negated, DASP- shall be asserted by the slave within 400 ms to indicate that the slave is present.</p> <p>The master shall allow up to 450 ms for the slave to assert DASP-. If the slave is not present, the master may assert DASP- to drive an activity LED.</p> <p>DASP- shall be negated following acceptance of the first valid command by drive 1 or after 31 seconds, whichever comes first.</p> <p>Any time after negation of DASP-, either drive may assert DASP- to indicate that a drive is active.</p>

ATA/CAM Master/Slave Reset Timing

Figure 5-1 illustrates the reset sequence for the ATA/CAM Master/Slave method.

Figure 5-1
ATA/CAM Reset Sequence



<i>Description</i>	<i>Label</i>	<i>POR Value</i>	<i>Soft Reset Value</i>
-Reset width (min)	T_M	25 μ s	N/A
-DASP asserted (max)	T_S	31s	31s
-DASP after Reset (max)	T_R	450ms	N/A
Slave DIAG complete (max)	T_Q	30s	30s
Drive BSY (max)	T_B	31s	31s
-DASP after -PDIAG (min)	T_D	>0	N/A
BSY status after Reset (max)	T_N	400ns	400ns
-PDIAG after Reset (max)	T_A	N/A	1ms


Notes:

1. -DASP is asserted by both the master and the slave. The signal on the bus is the “wired OR” of -DASP from both drives. The master de-asserts -DASP within 1ms after reset and waits for up to 450ms for the slave to assert -DASP to signal its presence.
2. During a reset condition, the host BIOS checks drive 0 for BSY to be reset. Drive 0 monitors the -PDIAG signal from the slave. When the slave completes its diagnostics, it clears its BSY and asserts -PDIAG. The master will wait for up to 31 seconds for -PDIAG, then clears its BSY and de-asserts -DASP.

ISA/Conner Master/Slave Reset Timing

Figure 5-2 illustrates the reset sequence for the ISA and Conner Master/Slave methods.

Figure 5-2
ISA and Conner Reset Sequence



Description	Label	POR Value	Soft Reset Value
-Reset width (min)	T_M	25 μ s	N/A
Slave DIAG complete (max)	T_Q	14s	450ms
Drive BSY (max)	T_B	14.5s	450ms
BSY status after Reset (max)	T_N	400ns	400ns
-PDIAG after Reset (max)	T_P	1ms	1ms


Host PIO 16-Bit Timing Values

The values* in the table below refer to the timing diagram in figure 5-3.

Symbol	Parameter Units	Min:	Max:	Unit:
T ₁	A[0:2] valid until -IOCS16 valid		15	ns
T ₂	-IOCS16 valid after A[0:2] invalid	14		ns
T ₃	A[0:2] valid until -IOR or -IOW valid	5		ns
T ₄	A[0:2] valid after -IOR or -IOW invalid	10		ns
T ₅	-CS0 or -CS1 valid until -IOR or -IOW valid	10		ns
T ₆	-CS0 or -CS1 valid after -IOR or IOW invalid	10		ns
T ₇	-IOW or -IOR pulse width	60		ns
T ₈	Read Data valid after -IOR valid		25	ns
T ₉	Read Data valid after -IOR invalid	20		ns
T ₁₀	Write Data valid until -IOW invalid	5		ns
T ₁₁	Write Data valid after -IOW invalid'	5		ns
T ₁₂	-IOR or -IOW valid until -IOCHRDY valid		15	ns
T ₁₃	-IOCHRDY pulse width		1,250	ns
T ₁₄	-IOR/-IOW cycle time (w/ IOCHRDY)	180s		ns

* Under conditions equivalent to a 330 ohm pullup and a 56pf load. Cable type and length may affect the values measured at the drive or host interface.

Figure 5-3
Interface PIO Timing Diagram




Host Demand Mode DMA 16-bit Interface Timing Values

The values* in the table below refer to the timing diagram in figure 5-4.

Symbol:	Parameter:	Min:	Max:	Unit:
T ₁	-IOR/-IOW valid to +DMARQ invalid		40	ns
T ₂	-IOR/-IOW invalid to -DACK invalid	5		ns
T ₃	-DACK valid to -IOR/-IOW valid	0		ns
T ₄	-IOR/-IOW pulse width	60		ns
T ₅	-IOR/-IOW cycle time	150		ns
T ₆	-IOR/-IOW high	50		ns
T ₇	-IOR valid until HDB[15:0] valid		25	ns
T ₈	-IOR invalid to HDB[15:0] invalid	20		ns
T ₉	HDB[15:0] valid until -IOW invalid	5		ns
T ₁₀	HDB[15:0] valid after -IOW invalid	5		ns

* Under conditions equivalent to a 330 ohm pull-up and a 56pf load. Cable type and length may affect the values measured at the drive or host interface

Figure 5-4
Interface DMA Timing Diagram



0243

Host Address Decoding

The host computer addresses the drive using programmed I/O. This method requires that:

- a proper **chip select** be asserted
- the desired **register address** be placed on the three host address lines (HA2 - HA0)
- a **Read** or **Write** strobe (-HOST IOR/-HOST IOW) is given to the chip

The host generates two independent chip selects on the interface.

- The high order chip select, -HOST CS1, is used to access register 3F6 or 3F7.
- The low order chip select, -HOST CS0, is used to address registers 1F0 through 1F7.

ECC bytes are transferred on bits 7 - 0.

The host data bus 15 - 8 is only enabled when:

- -IO16 is active
- the host is addressing the data register for transferring data
- the host is not transferring ECC bytes, which are only transferred if the operation is a **Read Long** or **Write Long**

The I/O map on the next page defines all of the register addresses and the functions for these I/O locations.

The sections that follow the I/O map describe each of the registers.

Addr*	-CS0	-CS1	HA2	HA1	HA0	Read Function	Write Function
	1	1	x	x	x	No Operation	No Operation
	0	0	x	x	x	Invalid Address	Invalid Address
	1	0	0	x	x	High Impedance	Not Used
	1	0	1	0	x	High Impedance	Not Used
1F0	0	1	0	0	0	Data Register	Data Register
1F1	0	1	0	0	1	Error Register	Features Register
1F2	0	1	0	1	0	Sector Count	Sector Count
1F3	0	1	0	1	1	Sector Number	Sector Number
1F4	0	1	1	0	0	Cylinder Low	Cylinder Low
1F5	0	1	1	0	1	Cylinder High	Cylinder High
1F6	0	1	1	1	0	SDH Register	SDH Register
1F7	0	1	1	1	1	Status Register	Command Register
3F6	1	0	1	1	0	Alternate Status Register	Digital Output Register
3F7	1	0	1	1	1	Drive Address Register	Not Used

x = don't care

* These I/O port addresses are listed for programmer reference. They are a function of I/O decoding in the Host Adapter. These addresses are required for compatibility with most AT BIOS.

Addressing the Data

There are two methods of addressing the sectors on the disk drive.

Cylinder-Head-Sector (CHS) Mode

The first method, which is the traditional approach, uses Cylinder-Head-Sector (CHS) addressing. Most disk drives today exceed the number of cylinders limit of DOS or use zone recording (different number of sectors per track in each zone) so the parameters reported by the drive in the **Identify Drive** command are logical translations done by the drive. BIOS CHS-toCHS translation allows the task file registers to address up to 8GB of data.

Logical Block Addressing (LBA) Mode

The second method uses Logical Block Addressing (LBA), which is common to SCSI. This method re-defines the content of the Task File registers, which are described later in this chapter. This drive operates with either CHS or LBA addressing by responding to the switch in the **SDH** register. The registers affected by LBA mode are the **Sector Number**, **Cylinder Low**, **Cylinder High**, and **SDH**. The use of these registers allows a 28-bit address space capable of handling up to 128GB of data.

In LBA mode, the sectors on the disk are linearly mapped with the first logical block (LBA 0) defined as Cylinder 0, Head 0, Sector 1. The subsequent logical blocks are defined by the formula:

$$\text{LBA} = [(\text{cylinder} * \text{no. of heads} + \text{heads}) * \text{sectors/track}] + (\text{sector} - 1)$$

Descriptions of the Registers

The following sections describe the registers used for read and write functions. In these descriptions, unused write bits should be treated as “don’t cares” and other unused bits should be read as zeroes.

Data Register

Port Select:	1F0
Chip Select:	HOST CS0
Register Address:	0
Function:	Read/Write

Description: This is the register:

- through which all data is passed on **Read** and **Write** commands
- to which the sector table is transferred during **Format** commands
- to which data associated with the **Identify** command is transferred

All transfers are high speed 16-bit I/O operations except for ECC bytes transferred during **R/W Long** commands, which are slower 8-bit operations that occur after the transfer of the data.

Data is stored on the disk with the Least Significant Byte (LSB) first, then the Most Significant Byte (MSB) for each word. This is important to remember when testing the ECC circuitry.

Error Register

Port Address: 1F1
Chip Select: -HOST CS0
Register Address: 1
Function: Read only

Description: This register contains status from the last command executed by the drive.

The contents of this register are only valid when the error bit (ERR) is set in the Status Register, unless the drive has just powered up or completed execution of its internal diagnostic, in which case the register contains a status code. The status codes are discussed in chapter 7 in the description of the **Diagnostic** command.

The bits in the register are defined below:

<i>Bit 7</i>	<i>Bit 6</i>	<i>Bit 5</i>	<i>Bit 4</i>	<i>Bit 3</i>	<i>Bit 2</i>	<i>Bit 1</i>	<i>Bit 0</i>
BBK	UNC	not used	IDNF	not used	ABRT	TK0	not used

where:

- **BBK** indicates that a bad block mark was detected in the requested sector's ID field. A bad block mark is not created in the factory, but only when requested in the format command.
- **UNC** indicates that a non-correctable data error has been encountered.
- **IDNF** indicates that the requested sector's ID field could not be found.
- **ABRT** indicates that the requested command has been aborted due to a drive status error (not ready, write fault, etc.) or because the command code is invalid.
- **TK0** indicates that track 0 has not been found during a recalibrate command.

For other drives Bit 0 is AMNF (Address Mark Not Found.) This is not used on Conner drives.

Features Register (formerly Write Precomp Register)

Port Address: 1F1
Chip Select: -HOST CS0
Register Address: 1
Function: Write only

Description: This register was previously used to set write precompensation in non-intelligent (pre-IDE) disk drives. This drive uses this register for commands EF and F1 through F6. The ATA specification defines this register as the **Features** register.

Sector Count

Port Address: 1F2
Chip Select: -HOST CS0
Register Address: 2
Function: Read/Write

Description: This register defines the number of sectors of data to be transferred on read or write commands.

If the value in this register is zero, a count of 256 sectors is specified. This count is decremented as each sector is read, such that the register contains the number of sectors left to access in the event of an error in a multi-sector operation.

The contents of this register define the number of sectors per track when executing an **Initialize Drive Parameters** command. This register is also used in the power commands to provide the power-down time-out parameter and status.

Sector Number

Port Address: 1F3
Chip Select: -HOST CS0
Register Address: 3
Function: Read/Write

CHS Description: This register contains the starting sector number for any disk access.

LBA Description: This register contains bits 0-7 of the logical block address.

At the completion of each sector and at the end of the command, this register is updated to reflect the last sector read correctly or the sector on which an error occurred. During multiple sector transfers, this register is updated to point at the next sector to be read/written if the previous sector's operation was successful.

Cylinder Low

Port Address: 1F4
Chip Select: -HOST CS0
Register Address: 4
Function: Read/Write

CHS Description: This register contains the low-order 8 bits of the starting cylinder number for any disk access.

LBA Description: This register contains bits 8-15 of the logical block address.

At the completion of each sector and at the end of the command, this register is updated to reflect the current drive address.

Cylinder High

Port Address: 1F5
Chip Select: -HOST CS0
Register Address: 5
Function: Read/Write

CHS Description: This register contains the high-order bits of the starting cylinder number for any disk access. Most BIOS will only use the first two bits of this register, forming a 10-bit cylinder address.

LBA Description: This register contains bits 16-23 of the logical block address.

At the completion of each sector, and at the end of the command, this register is updated to reflect the current drive address.

SDH Register

Port Address: 1F6
Chip Select: -HOST CS0
Register Address: 6
Function: Read/Write

Description: This register contains the drive and head numbers, as defined below:

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
1	LBA	1	DRV	HEAD			

where:

- **DRV** is the binary encoded drive select number. When this bit is reset, the master drive is selected, and when this bit is set, the slave drive is selected. While both drive's Task File registers are always written, this bit selects which drive will respond and execute a command.
- **LBA** is the binary coded address mode select. When L = 0, addressing is by CHS mode. When L = 1, addressing is by LBA mode. This bit was RSVD (reserved) for use by the host and set to 0.
- **HEAD**

CHS Description: This is the four-bit binary encoded head select number.

LBA Description: This register contains bits 24-27 of the logical block address.

At the completion of each sector and at the end of the command, this register is updated to reflect the currently selected head.

Status Register

Port Address: 1F7
Chip Select: -HOST CS0
Register Address: 7
Function: Read only

Description: This register contains the drive/controller status. The contents of this register are updated at the completion of each command.

If the Busy bit is active, no other bits are valid. The host reading this register when an interrupt is pending is considered to be the interrupt acknowledge, and any pending interrupt is therefore cleared whenever this register is read.

The bits in this register are defined below:

<i>Bit 7</i>	<i>Bit 6</i>	<i>Bit 5</i>	<i>Bit 4</i>	<i>Bit 3</i>	<i>Bit 2</i>	<i>Bit 1</i>	<i>Bit 0</i>
BSY	DRDY	DWF	DSC	DRQ	CORR	IDX	ERR

where:

- **BSY** is the Busy bit, which is set whenever the drive has access to the Task File registers and the host is locked out from accessing the Task File. This bit is set under any the following circumstances:
 - At activation of the Host Reset pin in the interface, or at activation of the software reset bit in the digital output register.
 - Immediately upon host write of the command register with a **Read**, **Read Long**, **Read Buffer**, **Seek**, **Recalibrate**, **Initialize Drive Parameters**, **Read Verify**, **Identify**, or **Execute Drive Diagnostic** command.
 - Immediately following transfer of 256 words of data after host write of the command register with a **Write**, **Format Track**, or **Write Buffer** command.
 - Immediately following transfer of 256 words of data and the ECC bytes after a host write of the Command register with a **Write Long** command.

When BSY is active, any host read of a Task File register is inhibited and the Status register is read instead.

- **DRDY** is the drive ready indication. When there is an error, this bit is not changed until the Status register is read by the host, at which time the bit again indicates the current readiness of the drive. This bit will be reset at power-up and remain reset until the drive is up to speed and ready to accept a command.

- **DWF** is the drive write fault bit. When there is an error, this bit is not changed until the Status register is read by the host, at which time the bit again indicates the current write fault status.
- **DSC** is the drive seek complete bit. It is an indication that the actuator is on track. When there is an error, this bit is not changed until the Status register is read by the host, at which time the bit again indicates the current readiness of the drive. This bit will be reset at power-up and will remain reset until the drive is up to speed and ready to accept a command.
- **DRQ** is the data request bit, which indicates that the drive is ready for transfer of a word or a byte of data between the host and the Data register.
- **CORR** is the corrected data bit, which is set:
 - when a correctable data error has been encountered and the data has been corrected
 - on a read verify if any sector was corrected the bit is valid

This condition will not terminate either a **Multi-Sector Read** or a **Read Multiple** command.
- **IDX** is the index bit which is set once per disk revolution.
- **ERR** is the error bit, which indicates that the previous command ended in some type of error. The other bits in the Status register, as well as the bits in the Error register, will have additional information as to the cause of the error.

Alternate Status Register

Port Address: 3F6
Chip Select: -HOST CS1
Register Address: 6
Function: Read only

Description: This register contains the same information as the Status register in the Task File. The only difference is that reading this register does not imply interrupt acknowledge to reset a pending interrupt.

The bits in this register are defined below:

<i>Bit 7</i>	<i>Bit 6</i>	<i>Bit 5</i>	<i>Bit 4</i>	<i>Bit 3</i>	<i>Bit 2</i>	<i>Bit 1</i>	<i>Bit 0</i>
BSY	DRDY	DWF	DSC	DRQ	CORR	IDX	ERR

See the description of the Status register for definitions of the bits in this register.

Digital Output Register

Port Address: 3F6
Chip Select: -HOST CS1
Register Address: 6
Function: Write only

Description: This register contains two control bits as follows:

<i>Bit 7</i>	<i>Bit 6</i>	<i>Bit 5</i>	<i>Bit 4</i>	<i>Bit 3</i>	<i>Bit 2</i>	<i>Bit 1</i>	<i>Bit 0</i>
not used	not used	not used	not used	not used	SRST	-IEN	not used

where:

- **SRST** is the host software reset bit. The drive is held reset when this bit is active, and enabled when this bit is inactive.
- **-IEN** is the enable bit for this disk drive interrupt to the host.
 - When this bit is active (=0) and the drive is selected, the host interrupt, +IRQ, is enabled through a tri-state buffer to the host.
 - When this bit is inactive (=1), or the drive is not selected, the +IRQ pin will be in a high impedance state, regardless of the presence or absence of a pending interrupt.

Drive Address Register

Port Address: 3F7
Chip Select: -HOST CS1
Register Address: 7
Function: Read only


Description: This register loops back the drive select and head select addresses of the currently selected drive.

The bits in this register are as follows:

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
RSVD	-WTG	-HS3	-HS2	-HS1	-HS0	-DS1	-DS0

where:

- **RSVD** is reserved and negated by the drive. When the host reads the drive address register, this bit must be in a high impedance state.
- **-WTG** is the write gate bit, which is active when writing to the disk drive is in progress.
- **-HS3 through -HS0** are the one's complement of the binary coded address of the currently-selected head. For example, if -HS3 through -HS0 are 1 1 0 0, respectively, head 3 is selected.
- **-DS1** is the drive select bit for drive 1, and should be active when drive 1 is selected and active.
- **-DS0** is the drive select bit for drive 0, and should be active when drive 0 is selected and active.

 **Note:** Bit 7 is not driven for compatibility with the floppy drive address space. If your system is different, you may have to drive this bit when this register is read.

Command Register

Port Address: 1F7
Chip Select: -HOST CS0
Register Address: 7
Function: Write only

Description: The eight-bit code written to this register passes the command from the host to the drive. Command execution begins immediately after this register is written.

Refer to chapter 7 for a list of executable commands with the command codes and necessary parameters for each command.

This I/O map defines the register addresses and functions for these I/O locations. For ease of reference, the commands are listed in alphabetical order.

Command:	Command Code								Parameters:				
	b7	b6	b5	b4	b3	b2	b1	b0	SC	SN	CY	SDH	PR
Conner Specific	1	0	0	1	1	0	1	0	y	y	y	d	n
Execute Drive Diagnostic	1	0	0	1	0	0	0	0	n	n	n	d	n
Format Track	0	1	0	1	x	x	x	x	n	n	y	y	n
Identify Drive	1	1	1	0	1	1	0	0	n	n	n	d	n
Init. Drive Parameters	1	0	0	1	0	0	0	1	y	n	n	y	n
Physical Seek	1	1	1	1	0	0	1	0	y	y	y	y	y
Power Commands	1	1	1	0	0	p	p	p	y	n	n	d	n
Read DMA	1	1	0	0	1	0	0	r	y	y	y	y	n
Read Multiple	1	1	0	0	0	1	0	0	y	y	y	y	n
Read Sector(s)	0	0	1	0	0	0	L	r	y	y	y	y	n
Read Sector Buffer	1	1	1	0	0	1	0	0	e	n	e	d	n
Read Verify Sector(s)	0	1	0	0	0	0	0	r	y	y	y	y	n
Recalibrate	0	0	0	1	x	x	x	x	n	n	n	d	n
Seek	0	1	1	1	x	x	x	x	n	n	y	y	n
Set Features	1	1	1	0	1	1	1	1	y	n	n	d	y
Set Multiple Mode	1	1	0	0	0	1	1	0	y	n	n	d	n
Translate	1	1	1	1	0	0	0	1	n	y	y	y	y
Write DMA	1	1	0	0	1	0	1	r	y	y	y	y	n
Write Multiple	1	1	0	0	0	1	0	1	y	y	y	y	n
Write Sectors	0	0	1	1	0	0	L	r	y	y	y	y	n
Write Sector Buffer	1	1	1	0	1	0	0	0	e	n	e	d	n

where:

- **L** is the long bit, if 1, **R/W Long** commands are executed, if 0, normal R/W commands are performed.
- **r** is the retry bit; 0 = retries are enabled, 1 = retries are disabled. Retries that may be enabled/disabled are those on ECC and data errors. When retries are disabled at the start of a command, they are always automatically enabled at the end of the command.
- **SC** is the sector count register.
- **SN** is the sector number register.
- **CY** is the cylinder registers.
- **SDH** is the drive/head register.
- **PR** is the features (write precomp) register.
- **y** means the register contains a valid parameter for this command. For the drive/head register, y means that both the drive and head parameters are used.

- **n** means the register does not contain a valid parameter for this command.
- **d** means only the drive parameter is valid and not the head parameter.
- **p** is a valid bit for power commands E0 - E3 and E5 - E6.
- **e** means the registers contain valid parameters when performing extended commands.
- **x** = don't care.

Command Register

All commands are decoded from the Command Register. The drive's host interface shall be programmed by the host computer to perform commands and will return status to the host at command completion.

To issue a command, the host must:

- load the pertinent registers in the Task File
- activate the interrupt enable bit, -IEN, in the Digital Output register
- write the command code to the Command register

Execution begins as soon as the Command register is written.

The following sections describe the drive's supported command set. For ease of reference, the commands are listed in alphabetical order.

Conner Specific

Command Number: 9A hex

Description: The Conner drive provides vendor-unique commands to allow for certain operations not provided by the standard command set. The Sector Number register must be set to 9A hex and the specific command in the Sector Count register. The Cylinder High and Low registers are used to pass any bytes used in a write operation.

The Conner specific command has the following decodes:

Decode:	Description:
00 hex	Get Feature Word
01 hex	Reserved
02 hex	Read drive switches
03 hex	Abort command
04 hex	Reserved
05 hex	Reserved
06 hex	Abort command
07 hex	Abort command
08 hex*	Power lock
09 hex*	Power unlock
0A-FF hex	Reserved

* only valid on drives which implement Conner Power commands

The following sections describe these decodes in more detail.

Get Drive Feature word (00)

This command fetches the drive feature word and returns it in the Cylinder High and Cylinder Low registers. The bit meaning is as follows:

Bit:	Description:
15	Reserved
14	Reserved
13	Customer Reserved
12	Customer Reserved
11	Enable PIO Mode 2 at power on
10	Reserved
9	Reserved
8	ATA/CAM mode = 1
7	Reserved
6	Customer Reserved
5	Reserved Enable no spin on POR
4	Reserved
3	Disable Read Look Ahead Caching
2	Enable Write Caching
1	Reserved
0	Customer Reserved

It is important to read the Feature word and then only change the bits of interest leaving the other bits unaffected using specific commands supported by this drive.

Read the Drive Switches (02)

This command returns the drive switches in the Cylinder Low Register. The bit meaning is as follows:

Bit:	Description:
7	Reserved
6	Reserved
5	-C/D
4	Reserved
3	Reserved
2	Reserved
1	Reserved
0	Reserved

Power Lock (08)

This command prevents the drive from spinning down, and spins the drive up if the drive had been spun down.

Power Unlock (09)

This allows the drive to respond to the **Power** command and re-enables the power down time if applicable.

Execute Drive Diagnostic

Command Number: 90 hex

Description: This command performs the internal diagnostic tests implemented by the drive. The diagnostic tests are only executed upon receipt of this command.


The drive sets BSY immediately upon receipt of the command. If the drive is a master, the drive performs the diagnostic tests and saves the results. It then checks to see if a slave drive is present and waits up to 5 seconds for the slave to complete its diagnostics. If the slave successfully completes its diagnostics, it asserts -HOST PDIAG. If unsuccessful, the master drive resets BSY in the Status register and generates an interrupt. The Error bit (ERR) is set in the Status register and the Error register is updated.

The value in the Error register should be viewed as a unique 8-bit code and not as the single-bit flags defined previously. The interface registers are set to initial values except for the Error register.

The table below details the codes in the Error register and a corresponding explanation:

Error Code:	Description:
01 hex	No error detected
02 hex	Format device error
03 hex	Sector buffer error
8x hex	Slave drive failed

Additional codes may be implemented at the manufacturer's option.

 **Note:** If the slave drive fails diagnostics, the master drive shall "OR" 80 hex with its own status and load that code into the Error register. If the slave drive passes diagnostics or there is no slave drive connected, the master drive shall set bit 7 of the Error register in the Task File to 0.

Format Track

Command Number: 50 hex

Description: This command provides a means by which a defective sector may either be marked bad or reassigned. This command has been used on other drives to do the low level formatting job of putting the header and creating the data fields for all tracks on the drive.

It is not necessary to execute a **Format** command prior to operating the drive on the host PC because the drive is a hard-sectored drive and all required low-level formatting is done when built. Conner supports the **Format** command only to allow any sectors that become defective to be handled in a fashion required by different operating systems. It should be noted that the **Format** command operates on one single logical track at a time and that all sectors on that track are filled with zeroes.

There are two methods provided to handle defective sectors.

Marked Bad Sector

When a sector is marked bad, the ID field of the sector is updated to indicate a bad block. Any time that sector is accessed thereafter, the drive will return bad block status in the Error register. It is also possible to format a bad block good and use sectors previously formatted bad. The total capacity of the drive is reduced when sector is formatted bad.

Assign

The second method, Assign, allows a spare sector on the drive to be used to replace the specified sector. Following this operation, the drive performance will be degraded slightly when the sector is accessed due to the drive automatically going to the new sector. It is also possible to unassign an alternate. When a sector or sectors on a single track are unassigned, the first spare sector is the only one recoverable. Creating a diagnostic routine that performs large scale assign and unassign is not recommended.

The **Format Track** command is like a **Write** command, i.e., the Task File is written, the Command register is written to begin the command, and the drive responds by activating DRQ in the Status register. This indicates a request for 1 sectors (512 bytes) worth of data that is used to describe the operations to be performed on each sector of the track specified by the Task File. After the data is written to the Data register, the drive analyzes the information for each sector and performs the requested action to each sector. When the command is complete, the drive raises Interrupt Request with ending status in the Task File.

The data in the sector buffer must conform to a specified format. There must be one word, two bytes, for each sector. The words must be contiguous and begin at the start of the sector. Unlike some drives where the order of the words is used to determine the interleave, the order of the words is not significant because the drive's interleave cannot be changed. The MSB of each word must contain the

sector number. The LSB must contain a descriptor byte that indicates what is to be done to each sector. There are four possible descriptor bytes:

- 00 hex = format sector good
- 80 hex = format sector bad
- 40 hex = assign this sector to an alternate location
- 20 hex = unassign the alternate location for this sector

The drive will return an ID not found under any of the following conditions:

- There is a missing word for any sector along the track.
- The words are not contiguous from the start of the sector.
- There is more than one (1) word per sector.
- The Task File calls for an illegal cylinder and/or head register.

A utility program to handle defective sectors should provide some interface to obtain the defective sectors. The program should build a 512 byte block with a word for each sector for the track. These words must be in the first contiguous words of the block. The MSB of each block should contain the sector number. Then the defective sectors descriptor byte should be set to either 80 hex or 40 hex, depending on whether or not the sector is to be formatted bad or reassigned. All the remaining sectors should have a descriptor byte of 0 hex, which means to format the sector good. Once the data byte block is created, the **Format** command can be executed by interfacing it to the BIOS.

It is important to remember that all data on the track is lost. The drive formats to the logical track that is the power-on reset default, or to the values issued by the last **Initialize Drive Parameters** command.

Identify Drive

Command Number: EC hex

Description: This command allows the host to receive parameter information from the drive.

When the command is issued, the drive sets BSY, stores the required parameter information in the sector buffer, sets the DRQ bit, and generates an interrupt. The host may then read the information out of the sector buffer.

The parameter words in the buffer are arranged as follows. All reserved bits or words should be zeroes. All numbers are given in hexadecimal format, right-justified.

Word (hex):	Description:
0	General configuration bit significant information (0C5A)
1	Default number of cylinders
2	Number of removable cylinders
3	Default number of heads
4	Feature Word 134 ATA switch = <ul style="list-style-type: none"> • 0: Number of unformatted bytes per physical track • 1: Number of unformatted bytes per logical track
5	Number of bytes per sector
6	Default number of sectors per track
7	Number of bytes in the inter-sector gaps
8	Number of bytes in the Sync fields
9	0000
10-19	Feature Word 134 ATA switch = <ul style="list-style-type: none"> • 0: Serial number left justification • 1: Serial number right justification
20	Controller type 0003 dual-ported multiple sector buffer with Look Ahead Read
21	Controller buffer size in 512-byte increments
22	Number of ECC bytes on R/W long commands

Word (hex):	Description:
23-26	Controller firmware revision
27-46	Model number
47	Number of sectors per interrupt on Multiple commands: <ul style="list-style-type: none"> bits 15-8: 80 hex bits 7-0: 00 hex means Read/Write multiple not implemented; xx hex is the maximum number of sectors that can be transferred per multiple command
48	Double word transfer flag. 0 = not capable, 1 = capable
49	Capabilities definitions <ul style="list-style-type: none"> bits 15-12 0 = (reserved) bit 11 1 = IOCHRDY supported bit 10 1 = IOCHRDY can be disabled bit 9 1 = LBA supported bits 8 1 = DMA supported bits 7-1 0 = (reserved) bits 0 1 = assign alternate supported
50	Modes supported
51	Feature Word 134 ATA switch = <ul style="list-style-type: none"> 0: Features supported 1: 15-8 PIO data transfer cycle timing mode 7-0 vendor unique
52	Feature Word 134 ATA switch = <ul style="list-style-type: none"> 0: Features supported 1: bits 15-8 = DMA data transfer timing mode
53	bits 15-2: Reserved <ul style="list-style-type: none"> bit 1: 1 = the fields reported in words 64-70 are valid 0 = the fields reported in words 64-70 are not valid bit 0: 1 = the fields reported in words 54-58 are valid 0 = the fields reported in words 54-58 are not valid
54	Number of current logical cylinders
55	Number of current logical heads
56	Number of current sectors per logical track

Word (hex):	Description:	
57	Current capacity in sectors (LSW)	
58	Current capacity in sectors (MSW)	
59	bits 15-9 bit 8 bits 7-0	Reserved 1 = Multiple sector setting is valid xx = current setting for number of sectors per transfer in multiple mode
60	LSW Total number of user addressable sectors (LBA mode only)	
61	MSW Total number of user addressable sectors (LBA mode only)	
62	bits 15-8 bits 7-0	Single word DMA transfer mode active Single word DMA transfer mode supported
63	bits 15-8 bits 7-2 bit 1 bit 0	01 hex = Multiword DMA transfer mode active reserved for future Multiword DMA transfer modes** 1 = Multiword DMA transfer Mode 1 supported 0 = Multiword DMA transfer Mode 1 NOT supported 1 = Multiword DMA transfer Mode 0 supported 0 = Multiword DMA transfer Mode 0 NOT supported
64	bits 15-8 bits 7-2 bit 1 bit 0	Reserved reserved for future Advanced PIO Modes*** 1 = PIO Mode 4 supported 0 = PIO Mode 4 not supported 1 = PIO Mode 3 supported 0 = PIO Mode 3 not supported
65	Minimum multiword DMA transfer cycle time per word (ns)	
66	Recommended multiword DMA transfer cycle time (ns)	
67	Minimum PIO transfer cycle time without flow control (ns)	
68	Minimum PIO transfer cycle time with IOCHRDY flow control (ns)	
69-127	Reserved	

*	Mode 0	Mode 1	Mode 2
PIO Timing Parameters	(nsec)	(nsec)	(nsec)
Cycle Time	600	383	240
**	Mode 0	Mode 1	
Multiword DMA Timing	(nsec)	(nsec)	
Cycle Time	480	>= 150	
***			Mode 3
Advanced PIO Timing			(nsec)
Cycle Time			>= 180

128	Native number of Cylinders
129	Native number of Heads Sectors
130	Current logical number of Cylinders
131	Current logical number of Heads Sectors
132	Feature Word
133	Power commands supported (FFFF if supported)
134	bit 15-2: reserved bit 1: ATA/CAM compliant bit 0: 1= current logical numbers, 0 = default logical numbers
135	MSB = drive age LSB = drive program
136-255	Reserved

Initialize Drive Parameters

Command Number: 91 hex

Description: This command enables the host to set the head switch and cylinder increment points for multiple sector operations.

In the Translate mode, the logical head and sector numbers in the Task File will be translated to their native physical values as part of execution of the command.

The sector and head values in the Task File are not checked for validity by this command. If they are invalid, no error will be reported until an illegal access is made by some other command. Cylinder head increments on subsequent commands will occur after access of the maximum sector and maximum head specified by this command. Upon receipt of the command, the drive sets BSY, saves the parameters, resets BSY, and generates an interrupt.

Conner has established a Universal Translate Mode which enables the you to configure the drive in an AT environment to any cylinder, head, and sector configuration desired (refer to chapter 3).

Physical Seek

Command Number: F2 hex

Description: This command uses parameters passed to the drive in the Cylinder High, Cylinder Low, and Drive Head registers.

The parameters are checked for validity and, if correct, a **Seek** is performed to that physical location on the drive. An interrupt will be sent at the start of the **Seek** and BSY cleared. When the **Seek** is complete the Seek Complete (DSC) bit in the Status register will be set.

Valid cylinder parameters will be:

- 5 to max cylinder (from ID command word 128) if the Sector Count register contains any value other than FF hex
- An offset of 8 will be added to the value in the Cylinder registers if the Sector Count register contains FF hex.

Valid head parameter will be from 0 to max head - 1 (from ID command word 129 most significant byte). An AA hex must be loaded in the Precomp register or an Aborted Command error will result.


Power Commands

Command Number: Ex hex

Description: The **Power** commands are supported on some Conner drives, including the CFA810A and CFA1080A. If a **Power** command is issued to a drive that does not support the **Power** commands, an Abort status will be returned to the host in the Error register.

Commands E0 through E3 and E5-E6 constitute the **Power** commands. The following table describes these commands:

Error Code:	Description:
E0 hex	The drive enters Standby Mode immediately
E1 hex	The drive enters Idle Mode immediately
E2 hex	The drive enters Standby Mode immediately. If the Sector Count register is non-zero, then the Auto Power-Down feature is enabled and will take effect when the drive returns to Idle Mode. If the Sector Count register is zero, then the Auto Power-Down feature is disabled.
E3 hex	The drive enters Idle Mode immediately. If the Sector Count register is non-zero, then the Auto Power-Down feature is enabled and will take effect immediately. If the Sector Count register is zero, then the Auto Power-Down feature is disabled.
E5 hex	Puts FF hex in the Sector Count register if the drive is in Idle Mode. Puts 00 hex in the Sector Count register if the drive is in, going to, or recovering from the Standby Mode. Puts BB hex in the Sector Count register if power lock is enabled.
E6 hex	The drive enters Sleep Mode. A reset is required to bring the drive out of Sleep Mode.

 **Note:** Minimum power off/on cycle time is 60 seconds.

All of the **Power** commands except command E6 will execute immediately and return the ending interrupt after the spin up/down sequence is initiated. Please note that if the drive is already spinning (Idle Mode) and a spin-up command is issued from the host, the spin-up sequence is not initiated.

Similarly, if the drive is in Standby Mode and the host issues a spin-down command, the spin-down sequence is not initiated.

Return of the ending interrupt does not mean that the drive has fully transitioned to the desired operating mode. The Sleep command is the exception. In command E6, the drive is spun down and when it is stopped, the drive returns the ending interrupt and the Sleep Mode begins.

When enabling the Auto Power-Down feature, the value in the Sector Count register specifies the time-out value as shown in the table below. If the drive does not receive a command within the specified time, the drive will enter Standby Mode. The minimum time-out value is 60 seconds, which means the smallest value for the Sector Count register is 12 when enabling the Auto Power-down feature. If a number between 1 and 11 inclusive is specified in the Sector Count register, a value of 12 is used. This prevents overheating of the drive during spin-up/down sequences.

Sector Count Register Contents		Timeout Period
0	(00 _H)	Time-out disabled
1 to 12	(01 _H) to (0C _H)	(12 * 5 = 60) seconds
12 to 240	(0C _H) to (F0 _H)	(value * 5) seconds
241 to 251	(F1 _H) to (FB _H)	((value - 240) * 30) minutes
252	(FC _H)	(value * 5) seconds
253	(FD _H)	10 hours
254	(FE _H)	(value * 5) seconds
255	(FF _H)	(value * 5) seconds

Assertion of Host Reset will only affect the current state of the Sleep Mode. If the drive is in Sleep Mode and Host Reset is asserted, the drive wakes up into Standby Mode. Please note that the drive will not return to the state it was in when the host issued the Sleep command. The default power-on condition of the drive is Idle Mode.

Read DMA

Command Number: Cx hex

Description: This command enables the controller to do EISA Type B Demand Mode DMA reads. These are two versions of this command, as shown below:

Command Number:	Command Name
C8 hex	DMA Read with retries
C9 hex	DMA Read without retries

When the command is received, the drive will go busy and read the data into the buffer from the disk. When a sector is in the buffer, the drive will go not busy and activate Host DMA Request to initiate the transfer. The drive will then place data on the Host Data Bus whenever the host activates -Host IOR and -Host DMA ACK.

The drive will leave Host DMA Request active as long as there is data to transfer. When waiting for more data to be placed in the buffer, the drive will inactivate Host DMA Request until there is enough data in the buffer to transfer again. When the transfer is complete, the drive will become busy, verify no errors, and then go not busy and activate the Host IRQ line.

If the command is performed with the retries disabled bit active retries will be disabled.

Read Multiple

Command Number: C4 hex

Description: This command is identical to the **Read Sector** operation but several sectors are transferred to the host as a block without intervening interrupts and only requiring DRQ qualification of the transfer on the first sector of the block of sectors to be transferred. Long transfers are not permitted.

The block count, which is the number of sectors to be transferred as a block, is programmed by the **Set Multiple** mode command which must be executed prior to the **Read Multiple** command. When the **Read Multiple** command is issued, the Sector Count register will contain the number of sectors (not the number of blocks or the block count) requested.

If this sector count is not evenly divisible by the block count, as many full blocks as possible are transferred, followed by a final, partial block transfer. The partial block transfer will be for N sectors, where:

$$N = (\text{sector count}) \bmod (\text{block count})$$

If the **Read Multiple** command is attempted before the **Set Multiple** mode command has been executed or when multiple commands are disabled, the multiple operation will be rejected with an Aborted Command Error.

Disk errors encountered during multiple commands will be reported at the beginning of the block or partial block transfer, but DRQ will still be set and the transfer will take place as it normally would, including transfer of corrupt data, if any. Subsequent blocks or partial blocks will only be transferred if the error was a correctable data error. All other errors will cause the command to stop after transfer of the block which contained the error. Interrupts are generated when DRQ is set at the beginning of each block or partial block.

Read Sector(s)

Command Number: 2x hex

Description: This command will read from 1 to 256 sectors as specified in the Task File (a sector count of 0 is a request for 256 sectors), beginning at the specified sector. There are four versions of this command, as shown below:

Command Number:	Command Name
20 hex	Read with retries
21 hex	Read without retries
22 hex	Read long with retries
23 hex	Read long without retries

As soon as the Command register is written, the drive sets the BSY bit and begins execution of the command.

Upon execution, the Error bit (ERR) is set in the Status register and the Error register is updated. Also:

- If bits 2 and 3 of the Command register are not equal to zero, then the Aborted Command bit (ABRT) is set.
- If incorrect Task File parameters are passed, the ID Not Found Error (IDNF) is set.

If the drive is not already on the desired track, an implied **Seek** is performed. Once at the desired track, the drive begins searching for the appropriate ID field.

- If the ID is read correctly, the data field is read into the sector buffer.
- Error Bits are set if an error was encountered.

The DRQ bit is set and an interrupt is generated. The DRQ bit is always set regardless of presence or absence of an error condition at the end of the sector. Upon command completion, the Task File registers contain the cylinder, head, and sector number of the last sector read. The sector count is zero after successful execution of the command.

Multiple sector reads set DRQ and generate an interrupt when the sector buffer is filled at the completion of each sector and the drive is ready for the data to be transferred to the host. DRQ is reset and BSY is set immediately after the host empties the sector buffer.

If no error is detected, the cylinder, head, and sector registers are updated to point to the next sequential sector.

If either a correctable data error or a non-correctable data error occurs, the flawed data is loaded into the sector buffer.

- The read does not terminate if the error was a correctable data error.
- If a non-correctable data error occurs during a multiple sector read, the read will terminate at the sector where the error occurs. The Task File Registers will contain the cylinder, head, and sector number of the sector where the error occurred. The host may then read the Task File to determine what error has occurred, and on which sector.

A **Read Long** may be executed by setting the long bit in command code. The **Read Long** command returns the data and the ECC bytes contained in the data field of the desired sector. During a read long, the drive does not check the ECC bytes to determine there has been any type of data error. Data bytes are 16-bit transfers and ECC bytes are 8-bit transfers.

Read Sector Buffer

Command Number: E4 hex

Description: The **Read Buffer** command allows the host to read the current contents of the drive's sector buffer. Only the Command register is valid for this command.

When this command is issued, the drive will set BSY, set up the sector buffer for a read operation, set DRQ, reset BSY, and generate an interrupt. The host may then read up to 512 bytes of data from the buffer.

An option provided by Conner is to perform an extended **Read Buffer** command. If 599A hex is placed in the Cylinder register, then the Sector Count register is used to pass that many sectors out of the buffer. If the requested sector count is larger than the buffer, an Aborted Command error status is returned.

Read Verify Sectors

Command Number: 4x hex

Description: This command functions similarly to the **Read Sectors** command, except that no data is transferred to the host and at completion of the command. There are two versions of this command, as shown below:

Command Number:	Command Name
40 hex	Read Verify with retries
41 hex	Read Verify without retries

The CORR bit is set if software ECC correction was required. The drive remains Busy until all data is verified. If Look Ahead Read is active, the **Verify** command will also work the same as when a **Read** is performed.

Recalibrate

Command Number: 10 hex

Description: This command will move the read/write heads from anywhere on the disk to cylinder 0.

Upon receipt of the command, the drive sets BSY, resets DSC, and executes a **Seek** to cylinder zero. The drive then waits for the **Seek** to complete before updating status, resetting BSY, setting DSC, and generating an interrupt.

If the drive cannot reach cylinder 0, the Error Bit (ERR) is set in the Status register and the track 0 (TK0) bit is set in the Error register.

If the drive is not spinning or is not on track, an aborted command (ABRT) response will be given in the Error register.

Upon successful completion of the command, the Task File registers will be as follows:

Register:	Value:
Error	00
Sector Count	Unchanged
Sector Number	Unchanged
Cylinder Low	00
Cylinder High	00
SDH	Unchanged

Retry Count

Command Number: F4 hex

Description: This command returns the number of retries attempted after a **Read**, **Read Verify**, or **Read Multiple** command.

The count is returned in the Sector Count register and an interrupt is generated at the completion of the command. AA hex must be loaded in the Precomp register or an Aborted Command error will result.

Seek

Command Number: 70 hex

Description: This command initiates a **Seek** to the track and selects the head specified in the Task File.

When the command is issued, the drive sets BSY in the Status register, resets Seek Complete (DSC), initiates the **Seek**, resets BSY, and generates an interrupt. Only the Cylinder register and Drive Head register are valid for this command.

The drive does not wait for the **Seek** to complete before returning the interrupt. Seek Complete (DSC) will be set upon completion of the command.

If a new command is issued to a drive while a **Seek** is being executed, the drive will wait, with BSY active, for the **Seek** to complete before executing the new command. No checks are made on the validity of the Sector number in the Task File. The Error Bit (ERR) in the Status register and the ID Not Found (IDNF) bit in the Error register of the Task File will be set if an illegal cylinder number is passed.

Set Features (Set Look Ahead Read)

Command Number: EF hex

Description: This command is used by the host to establish the following parameters which affect the execution of certain drive features as shown below:

- 02 hex enables write cache.
- 82 hex disables write cache.
- AA hex enables Read Look Ahead.
- 55 hex disables Read Look Ahead.
- 03 Set Transfer Mode

Any other values in the Features (Write Precompensation) register will result in the Error bit set in the Status Register and the ABRT (abort) bit set in the Error Register. The default state on power up (Power On Reset) is determined by the value of the Feature Word, which is factory set. The drive will retain the settings through both soft and hard resets.

The Set Transfer Mode command set the current transfer mode according to the content of the Sector Count Register. The valid Sector Count Register values are shown in the table below:

Sector Count Register	Transfer Mode
00 hex	Set default PIO transfer mode
01 hex	Disable IOCHRDY
08 hex	Enable Mode 0 PIO with IOCHRDY enabled
09 hex	Enable Mode 1 PIO with IOCHRDY enabled
0A hex	Enable Mode 2 PIO with IOCHRDY enabled
0B hex	Enable Mode 3 PIO with IOCHRDY enabled
20 hex	Enable Multiword DMA Mode 0
21 hex	Enable Multiword DMA Mode 1

One transfer mode subcommand may be issued for each SET FEATURES Command.

Set Multiple Mode

Command Number: C6 hex

Description: This command enables the controller to perform **Read Multiple** and **Write Multiple** operations and establishes the block count for these commands. Prior to command issuance, the Sector Count register should be loaded with the number of sectors per block. Block counts supported are multiples of 2 up to the buffer size of each drive, e.g. 1,2,4,8.

Upon receipt of the command, the controller sets BSY and looks at the Sector Count register contents. If the register contents are valid and a supported block count is supplied, that value is loaded for all subsequent **Read Multiple** and **Write Multiple** commands and execution of these commands is enabled. Any unsupported block count in the register will result in an Aborted Command Error and any **Read Multiple** and **Write Multiple** commands will be disabled.

If the Sector Count register contains 0 when the command is issued, any **Read Multiple** and **Write Multiple** commands will be disabled. Once the appropriate action has been taken, the controller resets BSY and generates an interrupt. At power-up the default is for **Read Multiple** and **Write Multiple** to be disabled.

The state of **Read Multiple** and **Write Multiple** is maintained through both hardware and software resets when the drive is in ISA/Conner mode.

Translate

Command Number: F1 hex

Description: The command uses parameters passed to the drive in the Cylinder High, Cylinder Low, head drive, and Sector Number Registers. These values are then translated into the physical location on the drive and values are passed back through their respective registers and an interrupt is sent. An AA hex must be loaded in the Precomp Register or an Aborted Command error will result.

Write DMA

Command Number: Cx hex

Description: This command allows the drive to perform write operations using EISA DMA Demand Type B transfers. These are two versions of this command, as shown below:

Command Number:	Command Name
CA hex	DMA Write with retries
CB hex	DMA Write without retries

When the command is received, the drive will go busy and activate Host DMA Request. The drive will then accept data into its Data register whenever the host activates both -Host IOW and -Host DMACK. Host DMA Request will remain active until all data has been transferred.

Following the completion of the data transfer, the drive will go busy. When all the data is on the disk and the operation is complete, the drive will go not busy and activate Host IRQ.

If the command is performed with the retries disabled bit active, retries will be disabled.

Write Caching

Write caching is activated by setting the Feature Word bit 2. Once write caching is active, the **Write DMA** command is cached. This command is then referred to as a “cached write.”

When a cached write command is received, the data is taken from the host and ending status is posted before the data has been written to the disk.

- If the next command is a cached write and the data is logically sequential, the data is taken from the host immediately.
- If the next command is a cached write that is **not** logically sequential, the drive will wait for the previous write to finish before taking the data from the new write. Read commands work similarly; the previous write is allowed to finish before the read operation starts.

In addition to caching, dynamic sparing of bad sectors has been implemented for write commands. This ensures that cached data that has already been reported as written successfully gets written, even if an error should occur.

If a sector cannot be written, the drive will dynamically assign an alternate sector and continue writing the data. A limit of 100 spares has been set and if reached, the drive will drop out of write caching and report the error as an ID Not Found. If the write command is still active on the AT interface, the error is reported during that command; otherwise, it is reported on the next command.

Write Multiple

Command Number: C5 hex

Description: This command performs similarly to the **Write Sector** command except that the controller sets BSY immediately upon receipt of the command, data transfers are multiple sector blocks, and the long bit is not valid. Several sectors are transferred to the host as a block without intervening interrupts and only requiring DRQ qualification of the transfer at the start of the block, not on each sector. There is no IRQ prior to the first block transfer.

The block count, which is the number of sectors to be transferred as a block, is programmed by the **Set Multiple** mode command, which must be executed prior to the **Write Multiple** command. When the **Write Multiple** command is issued, the Sector Count register will contain the number of sectors (not the number of blocks or the block count) requested.

If this sector count is not evenly divisible by the block count, as many full blocks as possible are transferred, followed by a final, partial block transfer. The partial block transfer will be for N sectors, where:

$$N = (\text{sector count}) \bmod (\text{block count})$$

If the **Write Multiple** command is attempted before the **Set Multiple** mode command has been executed or when **Write Multiple** commands are disabled, the **Write Multiple** operation will be rejected with an Aborted Command Error.

All disk errors encountered during **Write Multiple** commands will be reported after the attempted disk write of the block or partial block is transferred. The write operation will end with the sector in error, even if it was in the middle of a block. Subsequent blocks will not be transferred in the event of an error. Interrupts are generated when DRQ is set at the beginning of each block or partial block.

Write Caching

Write caching is activated by setting the Feature Word bit 2. Once write caching is active, the **Write Multiple** command is cached. This command is then referred to as a “cached write.”

When a cached write command is received, the data is taken from the host and ending status is posted before the data has been written to the disk.

- If the next command is a cached write and the data is logically sequential, the data is taken from the host immediately.
- If the next command is a cached write that is **not** logically sequential, the drive will wait for the previous write to finish before taking the data from the new write. Read commands work similarly; the previous write is allowed to finish before the read operation starts.

In addition to caching, dynamic sparing of bad sectors has been implemented for write commands. This ensures that cached data that has already been reported as written successfully gets written, even if an error should occur.

If a sector cannot be written, the drive will dynamically assign an alternate sector and continue writing the data. A limit of 100 spares has been set and if reached, the drive will drop out of write caching and report the error as an ID Not Found. If the write command is still active on the AT interface, the error is reported during that command; otherwise, it is reported on the next command.

Write Sector(s)

Command Number: 3x hex

Description: This command will write from 1 to 256 sectors as specified in the Task File (a sector count of 0 is a request for 256 sectors), beginning at the specified sector. There are four versions of this command, as shown below:

Command Number:	Command Name
30 hex	Write with retries
31 hex	Write without retries
32 hex	Write long with retries
33 hex	Write long without retries

As soon as the Command register is written, the drive waits for the host to fill the sector buffer with the data to be written. No interrupt is generated to start the first buffer fill operation. Once the buffer is full, the drive sets BSY and begins command execution.

- If bits 2 and 3 of the Command register are on, the command terminates with Aborted Command.
- If incorrect task file parameters are passed, an H ID Not Found error is returned.

If the drive is not already on the desired track, an implied **Seek** is performed. Once at the desired track, the drive begins searching for the appropriate ID field.

- If the ID is correct, the data loaded in the buffer is written to the data field of the sector, followed by the ECC bytes.
- Error bits are set if an error was encountered.

Upon command completion, the Task File registers contain the cylinder, head, and sector number of the last sector written. The sector count is zero after successful execution of the command.

Multiple sector writes set DRQ and generate an interrupt each time the buffer is ready to be filled. DRQ is reset and BSY is set immediately when the host fills the sector buffer.

If no error is detected, the cylinder, head, and sector registers are updated to point at the next sequential sector.

If an error occurs during a multiple sector write, it will terminate at the sector where the error occurs. The Task File indicates the location of the sector where the error occurred. The host may then read the Task File to determine what error has occurred, and on which sector.

A **Write Long** may be executed by setting the long bit in the command code. The **Write Long** command writes the data and the ECC bytes directly from the sector buffer; the drive will not generate the ECC bytes itself for the **Write Long** command. Data byte transfers are 16-bit transfers and ECC bytes are 8-bit transfers.

Write Caching

Write caching is activated by setting the Feature Word bit 2. Once write caching is active, the **Write Sector(s)** command is cached. This command is then referred to as a “cached write.”

When a cached write command is received, the data is taken from the host and ending status is posted before the data has been written to the disk.

- If the next command is a cached write and the data is logically sequential, the data is taken from the host immediately.
- If the next command is a cached write that is **not** logically sequential, the drive will wait for the previous write to finish before taking the data from the new write. Read commands work similarly; the previous write is allowed to finish before the read operation starts.

In addition to caching, dynamic sparing of bad sectors has been implemented for write commands. This ensures that cached data that has already been reported as written successfully gets written, even if an error should occur.

If a sector cannot be written, the drive will dynamically assign an alternate sector and continue writing the data. A limit of 100 spares has been set and if reached, the drive will drop out of write caching and report the error as an ID Not Found. If the write command is still active on the AT interface, the error is reported during that command; otherwise, it is reported on the next command.

Write Sector Buffer

Command Number: E8 hex

Description: The **Write Buffer** command allows the host to overwrite the contents of the drive's sector buffer with any data pattern desired. Only the Command register is valid for this command.

When this command is issued, the drive will set BSY, set up the sector buffer for a write operation, set DRQ, reset BSY. The host may then write up to 512 bytes of data to the buffer.

An option provided by Conner is to perform an extended **Write Buffer** command. If 599A hex is placed in the Cylinder Register, the Sector Count register is used to determine how many sectors will be written. If the Sector Count is larger than the buffer, an Aborted Command error status is returned.

Error and Status Detection

In general, status and errors are detected in the following fashion by the drive microprocessor.

At the start of the execution of the command, the command register is checked for conditions that would lead to an aborted command. If an error is found, an error message is returned in the error register. Otherwise, the operation is attempted.

If the operation is attempted and fails, a message is returned. Any error terminates the command at the point that it is discovered.

Error and Status Messages

The error and status bits that are valid for each command are summarized below. The definitions of each of these messages are found in chapter 6.

Command	Error Type Valid
Recalibrate	ABRT, TKO, DRDY, DWF, DSC, ERR
Read Sector(s)	BBK, UNC, IDNF, ABRT, DRDY, DWF, DSC, CORR, ERR
Read Long	BBK, IDNF, ABRT, DRDY, DWF, DSC, ERR
Write Sector(s)	BBK, IDNF, ABRT, DRDY, DWF, DSC, ERR
Write Long	BBK, IDNF, ABRT, DRDY, DWF, DSC, ERR
Verify Sectors	BBK, UNC, IDNF, ABRT, DRDY, DWF, DSC, CORR, ERR
Format Track	IDNF, ABRT, DRDY, DWF, DSC, ERR
Seek	IDNF, ABRT, DRDY, DSC, ERR
Execute Drive Diag.	ABRT, ERR
Init Drive Parm	ABRT, ERR
Read Multiple	BBK, UNC, IDNF, ABRT, DRDY, DWF, DSC, CORR, ERR
Write Multiple	BBK, IDNF, ABRT, DRDY, DWF, DSC, ERR
Set Multiple	ABRT, ERR
Read Buffer	ABRT, ERR
Write Buffer	ABRT, ERR

Identify Drive	ABRT, ERR
Set Look Ahead Read	ABRT, ERR
Translate	ABRT, ERR
Physical Seek	IDNF, ABRT, DRDY, DSC, ERR
Retry Count	ABRT, ERR
Defect List	ABRT, ERR
Enable Index	ABRT, ERR
Invalid Command Code	ABRT, ERR

* See Command Description in chapter 7 for error byte decoding.