

Maxtor OneTouch™ II Small Business Edition Quick Start Guide

For more detailed information, please refer to the User's Guide located on the Install CD (also available at www.maxtor.com).

1 Insert the Installation CD into your CD-ROM drive



Windows 2000 and XP

You must have Administrative Privileges. Refer to chapter 2 of the User's Guide on the Install CD for more information.

To install the Maxtor OneTouch II Small Business Edition software and the Dantz® Retrospect® Express HD Server software:



1. Insert the Installation CD.
2. Wait for the Maxtor screen to appear.
3. Follow the on-screen instructions to install the software. For details, refer to Chapter 2 in the User's Guide, on the Installation CD.
4. After completing installation, eject the CD.



Do not remove the CD until all steps of the installation are complete.



This Installation describes the Full Installation with Dantz Retrospect Express HD Server. If you wish to install your drive without Dantz Retrospect Express HD Server, choose the 'Install Drivers' option to install the Maxtor software only. For more information, go to Chapter 2 of the User's Guide on the Install CD. The Maxtor OneTouch feature will not work unless you install Dantz Retrospect Express HD Server.

2 Connect the drive to your computer

Plug in the power adapter, turn the power switch on and plug in the USB cable. For details, refer to the Connecting the Drive section in Chapter 2 of the User's Guide.




Allow up to 2 minutes for your computer to recognize the drive.

3 Set up the OneTouch feature



If you did not install Dantz Retrospect Express HD Server, you may skip this step.

1. Push the button on the front of your drive.



Maxtor OneTouch Button

The EMC Dantz Retrospect Express HD Server registration screen will appear.

2. Complete the registration form.

Note: In order to register, you must be connected to the internet.

3. After you complete the registration, the Retrospect Express HD Server welcome screen will appear, displaying the automated backup settings for your computer.

You may back up your computer immediately by clicking **Back up now**, let Retrospect Express HD Server do it automatically at the next scheduled backup time, or do it at any time by pressing the button on the front of your drive or clicking **Back up now**.

Your installation is complete!

Restoring your System

Windows 2000 and XP

If your system is damaged and you need to restore it from your backup copy, follow the steps below:

To restore your Windows system

Note: The drive MUST be disconnected from the system during the OS installation.

1. Prepare your internal hard drive.

Partition, if necessary, and format.

Note: Do not partition or reformat the Maxtor OneTouch II Small Business Edition drive that your system is stored on.

2. Install your operating system.

The following services packs need to be installed:

- Windows XP: Service Pack 1 or later.
- Windows 2000: Service Pack 3 or later.

Microsoft Internet Explorer 5.01 or later is required for all Windows operating systems.

3. Re-install the Maxtor OneTouch II software including EMC Dantz Retrospect Express HD Server.

4. Open Retrospect Express HD Server.

5. Set up the Restore.

Click **Restore**.

A calendar window will appear showing all of your restore points.

6. Select your restore point.

Click the **restore point** that you wish to restore and click **Next**.

Note: For more information about restore points and using Retrospect Express HD, see 'Using Retrospect Express HD Server' in chapter 5 of the User's Guide on the Install CD.

You are now asked which files and folders you would like to restore.

7. Select your entire computer for restore.

Place a check next to **My Computer** and click **Next**.

8. Select the location of your restore.

You will now select where you want to restore your files.

Select **To Their Original Location On**, to restore them to the exact location from which they were originally copied.

Note: All data will be replaced at the location you have chosen to restore with the files and folders you have chosen to restore.

9. Start the Restore.

Click **Restore**.

Retrospect Express HD Server will start restoring files on your computer. A status bar will show the progress until the restore is finished.

10. Exit Retrospect Express HD Server.

If your system restore was successful, you can exit Retrospect Express HD Server. Click the **red 'X'** in the upper right corner of the window.

11. Finishing the restore.

Restart your computer.



Your system may require more than one restart. Follow any additional on-screen instructions, if necessary, to complete your system restore.

©2005 Maxtor Corporation. Maxtor and the Maxtor stylized logo are registered trademarks and Maxtor OneTouch is a trademark of Maxtor Corporation. Dantz and Retrospect are either registered trademarks or trademarks of EMC Corporation. Specifications subject to change without notice.

www.maxtor.com

Maxtor P/N: 20278300